

## IX Series

IP network-compatible intercom

# IX Support Tool Setting Manual

**Software version: 5.0.0.0 or later**

### Important

- Before configuring and using the system, read "Setting Manual" and "Operation Manual" carefully.
- For the installation and connection of each device, refer to "Installation Manual."
- Begin installation after reading and understanding the procedures for system configuration.
- The setting data is required for after-sales service and other such services. Write the setting data to a CD-R or other media and be sure to give it to the customer.
- The illustrations and images in this manual may vary from the actual ones.

# Table of contents

## Introduction

1. Notational symbols in this manual .....	9
2. Device type .....	10
3. Product manuals .....	11
4. Station description .....	12
4.1 Master Station IX-MV7-* .....	12
4.2 Master Station IX-MV .....	14
4.3 Handset Sub Station IX-RS-* .....	16
4.4 Video Door Station (IX-DA)/Audio Only Door Station (IX-BA) .....	18
4.5 Video Door Station (IX-DV, IX-DVF(-*), IX-SSA(-*)) .....	20
4.6 Door Station (IX-SS-2G) .....	25
4.7 I/O Adaptor (IXW-MA) .....	26
5. Configuring the system .....	27
6. Flowcharts for configuring the system .....	28
6.1 For static IPv4 Address .....	30
6.2 For IPv4 address with DHCP .....	37
6.3 For static IPv6 Address .....	46
6.4 For stateless IPv6 address .....	55
6.5 For IPv6 address with DHCP .....	64

## Startup and Configuration

1. System requirements .....	74
2. Installing IX Support Tool .....	75
3. Login and registration of the station .....	77
4. How to configure .....	79
4.1 Settings window .....	79
4.2 How to configure .....	81
4.3 Copy settings (Settings (Station View)) .....	83
5. System settings list .....	85

## Menu bar

1. File .....	123
1.1 Create new system/import setting data .....	123
1.2 Select Existing System .....	141
1.3 Delete Existing System .....	141
1.4 Update Settings .....	142

1.5	Download Settings From Station .....	143
1.6	Upload Settings To Station .....	145
1.7	Upload SSL certificate .....	148
1.8	Import Setting File .....	149
1.9	Exporting the IX Support Tool System Configuration .....	150
1.10	Export To Line Supervision Software .....	151
1.11	Exit .....	151
2.	Edit .....	152
2.1	Table View .....	152
2.2	Station View .....	152
2.3	Master Station Address Book .....	153
2.4	Creating VoIP Phone Address Books .....	153
2.5	Register Network Camera .....	153
2.6	Network Camera Integration .....	154
2.7	Master Station Group Settings .....	154
2.8	Door Station Group Settings .....	155
2.9	Location Registry .....	155
2.10	Manual Date / Time Setup .....	156
2.11	IX Support Tool Settings .....	156
3.	Language .....	158
4.	Tools .....	159
4.1	Station Search .....	159
4.2	Association Settings .....	160
4.3	Station Replacement .....	162
4.4	Restore System Settings .....	164
4.5	System Configuration .....	166
5.	Help .....	167
5.1	Update Firmware .....	167
5.2	About .....	168

**System Settings (Table View)**

1.	Station Information .....	170
1.1	Identification .....	170
1.2	ID and Password .....	175
1.3	Time .....	177
1.4	Expanded System .....	179

2. Network Settings .....	180
2.1 IP Address .....	180
2.2 DNS .....	185
2.3 SIP (except IXW-MA) .....	186
2.4 Multicast Address (For IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*)) .....	190
2.5 Video (for IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*)) .....	192
2.6 Audio (except IXW-MA) .....	200
2.7 Packet Priority .....	204
2.8 NTP .....	206
3. System Information .....	208
3.1 Location Registry (for IX-MV7-* and IX-MV) .....	208
3.2 Address Book (for IX-MV7-* and IX-MV) .....	208
3.3 Group (for Master) (for IX-MV7-* and IX-MV) .....	217
3.4 Custom Sound Registry (except IXW-MA) .....	221
4. Call Settings .....	224
4.1 Station Information (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G) .....	224
4.2 Called Stations (Master Stations) (for IX-MV7-* and IX-MV) .....	224
4.3 Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) .....	225
4.4 Call Origination (except IXW-MA) .....	228
4.5 Incoming Call (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA) .....	237
5. Option Input/Relay Output Settings .....	241
5.1 Option Input .....	241
5.2 Relay Output .....	244
6. Paging Settings .....	254
6.1 Paging Origination (for IX-MV7-* and IX-MV) .....	254
6.2 All Page (for IX-MV7-* and IX-MV) .....	256
6.3 Option Input Page (for IX-MV7-*) .....	257
7. Function Settings .....	259
7.1 Door Release (for IX-MV7-* and IX-MV) .....	259
7.2 Network Camera Integration (for IX-MV7-* and IX-MV) .....	261
7.3 Paging Settings (except IX-MV7-*, IX-MV, and IXW-MA) .....	267
7.4 Bathroom Call (for IXW-MA) .....	268
7.5 Email .....	269
7.6 CGI .....	279
7.7 SIF .....	280
7.8 Record (for IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*)) .....	295

7.9	Communication Audio Messages (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G)	302
7.10	Chime (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA)	304
7.11	CSR	308
7.12	SSL Certificate	309
7.13	IEEE 802.1X (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	313
7.14	Display Mode (for IX-MV7-*)	317
7.15	Bathroom Link	327
8.	Transfer Settings	328
8.1	Absent Transfer (for IX-MV7-* and IX-MV)	328
8.2	Delay Transfer (for IX-MV7-* and IX-MV)	330
8.3	Schedule Transfer (for IX-MV7-* and IX-MV)	332
8.4	Lock Transfer (for IX-MV7-*)	337
9.	Station Settings	338
9.1	Speed Dials / Favorites (for IX-MV7-* and IX-MV)	338
9.2	Privacy (for IX-MV7-* and IX-MV)	345
9.3	Volume / Tone (except IXW-MA)	346
9.4	Communication (except IXW-MA)	355
9.5	Monitor (except IXW-MA, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	357
9.6	Master Station Display (for IX-MV7-* and IX-MV)	361
9.7	Camera (for IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*))	363
9.8	Door Release Assignment (for IX-RS-*)	365
9.9	Line Supervision (for IX-MV7-*)	367
10.	Maintenance	369
10.1	Firmware Update	369
10.2	Initialization	370
10.3	Settings File Backup	371
10.4	syslog (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	373

## **System Settings (Station View)**

1.	Station Information	375
1.1	Identification	375
1.2	ID and Password	376
1.3	Time	378
1.4	Expanded System	380
2.	Network Settings	381

2.1 IP Address .....	381
2.2 DNS .....	384
2.3 SIP (except IXW-MA) .....	385
2.4 Multicast Address (for IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*)) .....	389
2.5 Video (for IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*)) .....	390
2.6 Audio (except IXW-MA) .....	398
2.7 Packet Priority .....	402
2.8 NTP .....	404
3. System Information .....	406
3.1 Location (for IX-MV7-* and IX-MV) .....	406
3.2 Address Book (for IX-MV7-* and IX-MV) .....	406
3.3 Group (for Master) (for IX-MV7-* and IX-MV) .....	414
3.4 Custom Sound Registry (except IXW-MA) .....	416
4. Call Settings .....	418
4.1 Station Information (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G) .....	418
4.2 Called Stations (Master Stations) (for IX-MV7-* or IX-MV) .....	418
4.3 Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) .....	419
4.4 Call Origination (except IXW-MA) .....	422
4.5 Incoming Call (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA) .....	431
5. Option Input/Relay Output Settings .....	436
5.1 Option Input .....	436
5.2 Relay Output .....	439
6. Paging Settings .....	450
6.1 Paging Origination (for IX-MV7-* and IX-MV) .....	450
6.2 All Page (for IX-MV7-* and IX-MV) .....	452
6.3 Option Input Page (for IX-MV7-*) .....	453
7. Function Settings .....	455
7.1 Door Release (for IX-MV7-* and IX-MV) .....	455
7.2 Network Camera Integration (for IX-MV7-* and IX-MV) .....	456
7.3 Paging Settings (except for IX-MV7-*, IX-MV, or IXW-MA) .....	461
7.4 Bathroom Call (for IXW-MA) .....	462
7.5 Email .....	463
7.6 CGI Integration .....	473
7.7 SIF Integration .....	474
7.8 Record (for IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*)) .....	485

7.9	Communication Audio Messages (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G)	489
7.10	Chime (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA)	491
7.11	CSR	495
7.12	SSL Certificate	497
7.13	IEEE 802.1X (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	498
7.14	Display Mode (for IX-MV7-*)	500
7.15	Bathroom Link	510
8.	Transfer Settings	511
8.1	Absent Transfer (for IX-MV7-* and IX-MV)	511
8.2	Delay Transfer (for IX-MV7-* and IX-MV)	513
8.3	Schedule Transfer (for IX-MV7-* and IX-MV)	515
8.4	Lock Transfer (for IX-MV7-*)	518
9.	Station Settings	519
9.1	Speed Dials / Favorites (for IX-MV7-* and IX-MV)	519
9.2	Privacy (for IX-MV7-* and IX-MV)	526
9.3	Volume / Tone (except IXW-MA)	527
9.4	Communication (except IXW-MA)	535
9.5	Monitor (except IXW-MA, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	536
9.6	Master Station Display (for IX-MV7-* and IX-MV)	539
9.7	Camera (for IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*))	541
9.8	Door Release Assignment (for IX-RS-*)	543
9.9	Line Supervision (for IX-MV7-*)	545
10.	Maintenance	546
10.1	Firmware Update	546
10.2	Initialization	547
10.3	Settings File Backup	548
10.4	syslog (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))	552

# Introduction

This manual describes the IX Support Tool in detail.

The IX Series offers a separate manual for Installation, Settings, and Operations. Refer to the relevant manual.

# 1. Notational symbols in this manual

---

The following symbols identify important information concerning operational procedures.

 Warning	Negligence could cause death or serious injury.
 Caution	Negligence could result in injury to people or damage to property.
 Important	Indicates what should be known before operation. Please read and understand before proceeding.
 Note	Indicates tips and additional information for operation.

- Terms displayed on master station and PC screens are indicated as **[XXXX]**.
- Page reference are shown as "[Title \(→ page XX\)](#)," [\(→ page XX\)](#), or [page XX](#).
- The illustrations and screen shots in this manual may vary from the actual ones.


## 2. Device type

The stations are shown as below.

	Device Type	Example Model Name
Master Stations	IX-MV	IX-MV
	IX-MV7-*	IX-MV7-HW, IX-MV7-W, IX-MV7-HB, IX-MV7-B
Video Stations	IX-DV, IX-DVF(-*)	IX-DV, IX-DVF, IX-DVF-P, IX-DVF-2RA, IX-DVF-RA
	IX-DA, IX-DF(-*)	IX-DA, IX-DF, IX-DF-HID, IX-DF-RP10, IX-DF-2RA
Audio Stations	IX-SSA(-*)	IX-SSA, IX-SSA-2RA, IX-SSA-RA
	IX-SS-2G	IX-SS-2G
	IX-BA, IX-SS(-*)	IX-BA, IX-SS, IX-SS-2RA, IX-SS-RA
	IX-RS-*	IX-RS-W, IX-RS-B
Others	IXW-MA	IXW-MA

## 3. Product manuals


Read the "Installation Manual," "Setting Manual," and "Operation Manual" as needed. Have the person who installs or configures the product refer to the relevant manuals.

 <p>Installation Manual</p>	<p><b>Installation Manual (comes with each station.)</b> Refer to when installing and connecting each station. (For installers)</p>
<p>Manuals can be downloaded from our web site. "<a href="https://www.aiphone.net/product/support/">https://www.aiphone.net/product/support/</a>." Refer to these manuals as necessary.</p>	<p><b>IX Support Tool Setting Manual (Electronic format (PDF file).)</b> Describes how to configure and maintain the system using IX Support Tool. (For system administrator)</p>
	<p><b>Monitoring Software (IX Supervision Tool) Operation Manual (Electronic format (PDF file).)</b> Describes how to use the Monitoring Software. (For system administrator)</p>
	<p><b>Operation Manual (Electronic format (PDF file).)</b> Describes how to use each station. (For user)</p>
	<p><b>Web Setting Manual (Electronic format (PDF file).)</b> Describes how to set up each station for the Internet connection. (For system administrator)</p>
	<p><b>Installation Manual (Electronic format (PDF file).)</b> Describes how to install each station. (For installer)</p>

# 4. Station description

## 4.1 Master Station IX-MV7-\*

### ■ Part names





1	Handset	10	microSD card slot*1
2	Camera	11	3.5 mm 4-pole mini jack
3	Privacy mask lever (top)	12	MAC address
4	Status indicator (orange/blue)	13	Camera angle adjustment lever
5	Speaker	14	Option connector terminal
6	Liquid crystal display (touch panel)	15	Low voltage cable connection terminal
7	Home button	16	Tabletop fastening screw hole
8	Microphone	17	LAN terminal
9	Reset button*1*2		

\*1 Found by opening cover.

\*2 Press and hold the reset button for at least 1 second (less than 5 seconds), then release to restart (reset).

## ■ Indicators

: ON    : OFF

Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing 	Booting
		Fast flashing 	Device error, Startup error
		Long OFF time flashing 	Communication failure, Line supervision and device check error
		Long irregular flashing 	Firmware version updating
		Long irregular flashing 	Initializing
	Blue light		Standby(Depends on setting)




### Note


- For a status other than those noted here, refer to "Operation Manual."
- The default language for the master station's display is English.

## 4.2 Master Station IX-MV

### ■ Part names



Back




1	Handset	13	SETTING button / Setting indicator (blue)
2	Hook switch	14	Select button
3	Speaker	15	ADJUST button
4	Keypad	16	Up/Down and L/R buttons
5	MONITOR button	17	Microphone
6	Color LCD monitor	18	Door Release button
7	Status indicator (orange/blue)	19	TALK button / Talk indicator (blue)
8	Speed Dial buttons (x 6)	20	OFF button
9	PRIVACY button / Privacy indicator (blue)	21	MAC address
10	TRANSFER button / Transfer indicator (orange)	22	Weak electrical current line connection terminal
11	LIST button / List indicator (blue)	23	LAN terminal
12	Reset button (beneath the name plate)*1		

\*1 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

## ■ Indicators

: ON    : OFF


Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing 	Booting
		Fast flashing 	Device error
		Long OFF time flashing 	Communication failure
		Long irregular flashing 	Firmware version updating
		Long irregular flashing 	Initializing
	Blue light		Standby(Depends on setting)

### Note

- For a status other than those noted here, refer to "Operation Manual."
- The display language is English by default.

## 4.3 Handset Sub Station IX-RS-\*

### ■ Part names



1	Handset	8	Door Release button Only displayed when configured.
2	Speaker	9	Call/TALK button Can be used to call or answer depending on configuration. <a href="#">“Call Button Function (→page 224)”</a>
3	Microphone	10	Ringtone/call volume* <sup>1</sup>
4	Status indicator (orange/blue)	11	MAC address
5	Call indicator (green) LED lit during operation.	12	LAN terminal
6	Communication indicator (orange) LED lit during operation.	13	Weak electrical current line connection terminal
7	Door release indicator (green) LED lit during operation.	14	Reset button* <sup>2</sup>

\*1 The volume can be adjusted for each of the following.

– Volume can be changed during an incoming call or in standby:

Ringtone... 0 (Off), 1 (Low) - 10 (High) (a tone is played each time it is adjusted)

– Volume can be changed during calls:


Handset Receive... 1 (Low) - 10 (High)

Hands-free Receive (also changes the paging reception and ringback tone volume)...1 (Low) - 10 (High)

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

## ■ Indicators

: ON    : OFF


Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing 	Booting
		Fast flashing 	Device error, Startup error
		Long OFF time flashing 	Communication failure
		Long irregular flashing 	Firmware version updating
		Long irregular flashing 	Initializing
	Blue light		Standby

### Note

- For a status other than those noted here, refer to "Operation Manual."

## 4.4 Video Door Station (IX-DA)/Audio Only Door Station (IX-BA)

### Part names




1	Call indicator (orange)	10	MAC address (beneath the panel)
2	Camera	11	Panel
3	Microphone	12	Main unit
4	Communication indicator (green)	13	Mounting frame
5	Speaker	14	MAC address
6	LED for night illumination	15	Camera angle adjustment lever (IX-DA only)
7	Call Button	16	Reset button <sup>*1*2</sup>
8	Status indicator (red)	17	LAN terminal <sup>*1</sup>
9	Drain holes (4)	18	Option connector <sup>*1</sup>

\*1 Accessible when terminal cover is opened.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

## ■ Indicators

: ON    : OFF

Name	Status (pattern)		Description
Status indicator	Red flashing	Normal flashing 	Booting
		Fast flashing 	Device error
		Long OFF time flashing 	Communication failure
		Long irregular flashing 	Firmware version updating
		Long irregular flashing 	Initializing
	Red light		Standby



### Note


- For a status other than those noted here, refer to "Operation Manual."

## 4.5 Video Door Station (IX-DV, IX-DVF(-\*), IX-SSA(-\*))


### Part Names

#### IX-DV

Front




Back




#### IX-DVF

Front



Back




1	Status indicator (orange/blue)	10	Camera angle adjustment lever
2	Call indicator (green)	11	MAC address
3	Communication indicator (orange)	12	Terminal cover
4	Camera	13	Option connector terminal* <sup>1</sup>
5	Microphone	14	LAN2 terminal (PoE/PSE)* <sup>1</sup>
6	Door release indicator (green)	15	LAN1 terminal (PoE/PD)* <sup>1</sup>
7	LED for night illumination	16	Reset button* <sup>1,2</sup>
8	Speaker	17	microSD card slot* <sup>1</sup>
9	Call button Surrounding area is lit up with blue light	18	microSD card release button* <sup>1</sup>


\*<sup>1</sup> Accessible when terminal cover is opened.

\*<sup>2</sup> Press and hold the reset button for 1 - 4 seconds, then release to restart station.

## IX-DVF-2RA



## IX-DVF-RA




1	Status indicator (orange/blue)	11	Urgent call button
2	Call indicator (green)	12	Camera angle adjustment lever
3	Communication indicator (orange)	13	MAC address
4	Camera	14	Terminal cover
5	Microphone	15	Option connector terminal*1
6	Door release indicator (green)	16	LAN2 terminal (PoE/PSE)*1
7	LED for night illumination	17	LAN1 terminal (PoE/PD)*1
8	Speaker	18	Reset button*1*2
9	Call button Surrounding area is lit up with blue light	19	microSD card slot*1
10	Braille	20	microSD card release button*1


\*1 Accessible when terminal cover is opened.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

IX-DVF-P



IX-DVF-L




1	Status indicator (orange/blue)	12	Hearing aid (T mode) compatible microphone
2	Call indicator (green)	13	Camera angle adjustment lever
3	Communication indicator (orange)	14	MAC address
4	Camera	15	Terminal cover
5	Microphone	16	Option connector terminal* <sup>1</sup>
6	Door release indicator (green)	17	LAN2 terminal (PoE/PSE)* <sup>1</sup>
7	LED for night illumination	18	LAN1 terminal (PoE/PD)* <sup>1</sup>
8	Speaker	19	Reset button* <sup>1</sup> * <sup>2</sup>
9	Call button Surrounding area is lit up with blue light	20	microSD card slot* <sup>1</sup>
10	HID reader	21	microSD card release button* <sup>1</sup>
11	Nameplate (with backlight)	22	Hearing aid unit


\*1 Accessible when terminal cover is opened.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.


IX-SSA



IX-SSA-2RA



IX-SSA-RA





1	Status indicator (orange/blue)	10	MAC address
2	Call indicator (green)	11	Terminal cover
3	Communication indicator (orange)	12	Option connector terminal*1
4	Microphone	13	LAN2 terminal (PoE/PSE)*1
5	Door release indicator (green)	14	LAN1 terminal (PoE/PD)*1
6	Speaker	15	Reset button*1*2
7	Call button Surrounding area is lit up with blue light.	16	microSD card slot*1
8	Braille	17	microSD card release button*1
9	Urgent call button		

\*1 Accessible when terminal cover is opened.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

## ■ Indicators

: ON, : OFF


Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing 	Booting
		Fast flashing 	Device error, Startup error
		Long OFF time flashing 	Communication failure
		Long initial light ON flashing 	Firmware version updating
		Long initial light ON flashing 	Mounting/ unmounting microSD card
		Long initial light ON flashing 	Initializing
	Blue light		Standby

### Note

- For a status other than those noted here, refer to "Operation Manual."

## 4.6 Door Station (IX-SS-2G)

### Part names



1	Speaker	7	MAC address
2	Microphone	8	LAN terminal*1
3	Call Button	9	Reset button*1*2
4	Status indicator (orange/blue)	10	Low voltage cable connection terminal*1
5	Communication indicator (orange)	11	Terminal cover
6	Call indicator (green)		

\*1 Found by opening terminal cover.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

### Indicators

: ON  : OFF


Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing 0.75sec → <input type="checkbox"/> 0.75sec	Booting
		Fast flashing 0.25sec → <input type="checkbox"/> 0.25sec	Device error, Startup error
		Long OFF time flashing 0.5sec → <input type="checkbox"/> 4sec	Communication failure
		Long irregular flashing 1sec → <input type="checkbox"/> 0.25sec →  0.25sec → <input type="checkbox"/> 0.25sec →  0.25sec → <input type="checkbox"/> 0.25sec	Firmware version updating
		Long irregular flashing 1sec → <input type="checkbox"/> 0.25sec →  0.25sec → <input type="checkbox"/> 0.25sec	Initializing
Blue light		Standby	

#### Note

- For a status other than those noted here, refer to "Operation Manual."

## 4.7 I/O Adaptor (IXW-MA)

### ■ Part names



1	MAC address*1	4	Status indicator (orange/blue)*1
2	Panel	5	Option connector terminal
3	Reset button*1*2	6	LAN terminal

\*1 The panel must be removed to access it.

\*2 Press and hold the reset button for 1 - 4 seconds, then release to restart station.

### ■ Indicators

☀: ON □: OFF

Name	Status (pattern)		Description
Status indicator	Orange flashing	Normal flashing ☀ 0.75sec → □ 0.75sec	Booting
		Fast flashing ☀ 0.25sec → □ 0.25sec	Device error, Startup error
		Long OFF time flashing ☀ 0.5sec → □ 4sec	Communication failure
		Long irregular flashing ☀ 1sec → □ 0.25sec → ☀ 0.25sec → □ 0.25sec → ☀ 0.25sec → □ 0.25sec	Firmware version updating
		Long irregular flashing ☀ 1sec → □ 0.25sec → ☀ 0.25sec → □ 0.25sec	Initializing
	Blue light	☀	Standby

## 5. Configuring the system

After installing and connecting all stations, the system will need to be fully configured before it will be operational. IX system can be configured in one of the two methods below. Choose one method. Using the "IX Support Tool" (1) is recommended.

- (1) Configure the system using the "IX Support Tool" application
  - Install the application on a PC and use to create the configuration for all stations.
  - Search for IX stations on the network; assign and upload configuration data for the system.
- (2) Configure each station through a Web browser (WEB Settings Access)
  - Access each station through a Web browser and enter setting data.
  - When using the Web browser method, each station must be configured separately.

### Important

- Once the system has been configured through a browser, the settings cannot be transferred to the IX Support Tool. Using the IX Support Tool is the recommended method to manage settings.
- If web browser configuration is used to change the "Identification" "[Number♦ \(→page 170\)](#)", "ID and Password" "[Administrator ID♦ \(→page 175\)](#)" and "[Administrator Password♦ \(→page 175\)](#)", "IPv4 Address" "[IP Address♦ \(→page 182\)](#)", IPv6 Address" "[IP Address♦ \(→page 183\)](#)", "Address Book" "[Station List \(→page 209\)](#)", and "Call Settings" "[Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)](#)" after configured using the IX Support Tool, it will not be applied to the IX Support Tool settings.
- Save the settings after configuring the system.

## 6. Flowcharts for configuring the system

When configuring the system using IX Support Tool, follow the flowchart that fits the application.

Save the settings after configuring the system. Otherwise, it may become impossible to restore the settings after maintenance or after-sales servicing.

Flowcharts are for configuration using IX Support Tool.

To configure a station through a Web browser, refer to "Web Setting Manual" for each station.

### For Static IPv4 Address



- ["Creating new data \(→page 30\)"](#)
- ["Change the settings \(For static IPv4 address\) \(→page 32\)"](#)
- ["Add a station \(For static IPv4 address\) \(→page 34\)"](#)
- ["Delete a station \(For static IPv4 address\) \(→page 35\)"](#)
- ["Replace a station \(For static IPv4 address\) \(→page 36\)"](#)

### For IPv4 Address with DHCP



- ["Creating new data \(→page 37\)"](#)
- ["Change the settings \(For IPv4 address with DHCP\) \(→page 39\)"](#)
- ["Add a station \(For IPv4 address with DHCP\) \(→page 41\)"](#)
- ["Delete a station \(For IPv4 address with DHCP\) \(→page 43\)"](#)
- ["Replace a station \(due to malfunction, etc.\) \(For IPv4 address with DHCP\) \(→page 44\)"](#)

### For Static IPv6 Address



- ["Creating new data \(→page 46\)"](#)
- ["Change the settings \(For static IPv6 address\) \(→page 48\)"](#)
- ["Add a station \(For static IPv6 address\) \(→page 50\)"](#)
- ["Delete a station \(For static IPv6 address\) \(→page 52\)"](#)
- ["Replace a station \(due to malfunction, etc.\) \(For static IPv6 address\) \(→page 53\)"](#)

**For stateless IPv6 Address**



- [“Creating new data \(→page 55\)”](#)
- [“Change the settings \(For stateless IPv6 address\) \(→page 57\)”](#)
- [“Add a station \(For stateless IPv6 address\) \(→page 59\)”](#)
- [“Delete a station \(For stateless IPv6 address\) \(→page 61\)”](#)
- [“Replace a station \(due to malfunction, etc.\) \(For stateless IPv6 address\) \(→page 62\)”](#)

**For IPv6 Address with DHCP**



- [“Creating new data \(→page 64\)”](#)
- [“Change the settings \(For IPv6 address with DHCP\) \(→page 66\)”](#)
- [“Add a station \(For IPv6 address with DHCP\) \(→page 68\)”](#)
- [“Delete a station \(For IPv6 address with DHCP\) \(→page 70\)”](#)
- [“Replace a station \(due to malfunction, etc.\) \(For IPv6 address with DHCP\) \(→page 71\)”](#)

## 6.1 For static IPv4 Address

### ! Important

- Save the setting file after configuring the system. Refer to [“Exporting the IX Support Tool System Configuration \(→page 150\)”](#). If the settings are not saved, it may be impossible to restore them after maintenance or after-sales servicing.

### 6.1.1 Creating new data

Use flowchart to create new configuration, e.g., when installing a new system.

#### 1. Set the language.

[“Language \(→page 158\)”](#)



#### 2. Perform the "Create New System" procedure

[“Create new system/import setting data \(→page 123\)”](#)

If using the Wizard function to create a new system, refer to [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#) for further instructions and continue from Step 8.



#### 3. Configure using "Table View"

Follow the instructions for each setting item and perform setup. [“System Settings \(Table View\) \(→page 169\)”](#)



#### 4. Install all stations.

Note the MAC addresses of all the stations.



#### 5. Associate the created setting data to the station.

[“Association Settings \(→page 160\)”](#)



#### 6. Upload the setting data to all stations.

[“Upload Settings To Station \(→page 145\)”](#)



#### 7. Set the time for all stations.

[“Time \(→page 177\)”](#)





**8. Set the display language for each station (IX-MV7-\*, IX-MV).**  
Refer to each station's Operation Manual.



**9. Complete**

## 6.1.2 Change the settings (For static IPv4 address)

Use this flowchart when changing the settings.

### 1. Set the language.

["Language \(→page 158\)"](#)



### 2. Retrieve the setting data for all the stations.

["Download Settings From Station \(→page 143\)"](#)



### 3. Perform setup.

Follow the instructions for each setting item and perform setup.

["System Settings \(Table View\) \(→page 169\)"](#) ["System Settings \(Station View\) \(→page 374\)"](#)



**Were any of the following changed? "Number," "Name," "Location," "IP Address," "Location Registry," "Camera Name"**

YES



NO



**Was "IP Address" changed from among these options?**

YES



NO



**4. Because the setting data for the station whose IP address was changed is no longer associated, re-associate the data.**

["Association Settings \(→page 160\)"](#)

The station will be restarted, and the changed IP Address will be reflected in the station.




**4. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)



**5. Complete**





**5. Upload the setting data to all stations.**

["Upload Settings To Station  
\(→page 145\)"](#)



**5. Complete**



**6. Complete**

---

---

### 6.1.3 Add a station (For static IPv4 address)

---

---

Use flowchart to add a station.

**1. Set the language.**

[“Language \(→page 158\)”](#)



**2. Retrieve the setting data for all the stations.**

[“Download Settings From Station \(→page 143\)”](#)



**3. Add the setting data.**

[“System Settings \(Table View\) \(→page 169\)”](#)

First, add the station data to [“Station Information \(→page 170\)”](#).



**4. Install the additional station.**



**5. Associate the setting data with the additional station.**

[“Association Settings \(→page 160\)”](#)



**6. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**7. Set the time for the additional station.**

[“Time \(→page 177\)”](#)



**8. Set the display language for the additional station (IX-MV7-\*, IX-MV only).**

Refer to the Operation Manual for each station.



**9. Complete**

---

---

## 6.1.4 Delete a station (For static IPv4 address)

---

---

Use flowchart to delete a station.

### Important

- If a page is placed without deleting the station from the system, the operation may be delayed.

#### 1. Set the language.

["Language \(→page 158\)"](#)



#### 2. Retrieve the setting data for all the stations.

["Download Settings From Station \(→page 143\)"](#)



#### 3. Delete the data of the station to be deleted.

["Remove Station \(→page 173\)"](#)



#### 4. Upload the setting data to all stations.

["Upload Settings To Station \(→page 145\)"](#)



#### 5. Complete

## 6.1.5 Replace a station (For static IPv4 address)

Use flowchart to replace a station.

### 1. Set the language.

[“Language \(→page 158\)”](#)



**Can the setting data of the station to be replaced be retrieved?**

YES



NO



### 2. Retrieve the setting data from the station to be replaced.

[“Download Settings From Station \(→page 143\)”](#)



### 2. Replace the station.

Note the MAC address of the station to be replaced.



### 3. Replace the station.

Note the MAC address of the station to be replaced.



### 3. Replace the setting data.

\*If the settings were changed with the station, they cannot be reflected.

[“Station Replacement \(→page 162\)”](#)



### 4. Replace the setting data.

[“Station Replacement \(→page 162\)”](#)



### 4. Set the display language for the replaced station (IX-MV7-\*, IX-MV).

Refer to the Operation Manual for each station.



### 5. Set the display language for the replaced station (IX-MV7-\*, IX-MV).

Refer to the Operation Manual for each station.



### 5. Complete

### 6. Complete

## 6.2 For IPv4 address with DHCP

### ! Important

- Due to the architecture of the IX system, DHCP configuration is only recommended for network environments utilizing managed (static) IP address leasing.
- Save the setting file after configuring the system. Refer to [“Exporting the IX Support Tool System Configuration \(→page 150\)”](#). If the settings file is not saved, it may be impossible to restore if post-installation service or maintenance is required.

### 6.2.1 Creating new data

Use flowchart to create new configuration, e.g., when installing a new system.

#### 1. Set up the DHCP server.



#### 2. Set the language.

[“Language \(→page 158\)”](#)



#### 3. "Create New System"

[“Create new system/import setting data \(→page 123\)”](#)

If using the Wizard function to create a new system, refer to [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#) for further instructions and continue from Step 9.



#### 4. Configure using "Table View"

Follow the instructions for each setting item and perform setup. [“System Settings \(Table View\) \(→page 169\)”](#)



#### 5. Install all stations.

Note the MAC addresses of all the stations.



#### 6. Associate the created setting data to the station.

[“Association Settings \(→page 160\)”](#)

Each station is restarted and the IP address assigned by DHCP server will be assigned.  
If a DHCP address cannot be assigned, it will default to "192.168.1.160."





**7. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**8. Set the time for all stations.**

[“Time \(→page 177\)”](#)



**9. Set the display language for each station (IX-MV7-\*, IX-MV).**


Refer to each station's Operation Manual.



**10. Complete**

## 6.2.2 Change the settings (For IPv4 address with DHCP)

Use this flowchart when changing the settings.





**5. Upload the setting data to all stations.**

[“Upload Settings To Station  
\(→page 145\)”](#)



**5. Complete**



**6. Complete**

---

### 6.2.3 Add a station (For IPv4 address with DHCP)

---

Use flowchart to add a station.

**1. Configure so that the IP address for the station to be added to the DHCP server is assigned as a static address.**

For information on DHCP server setting methods, refer to the DHCP server manual.



**2. Set the language.**

["Language \(→page 158\)"](#)



**3. Retrieve the setting data for all the stations.**

["Download Settings From Station \(→page 143\)"](#)



**4. Add the setting data.**

["System Settings \(Table View\) \(→page 169\)"](#)

First, add the station data to ["Station Information \(→page 170\)"](#).



**5. Install the additional station.**



**6. Associate the setting data with the additional station.**

["Association Settings \(→page 160\)"](#)

The station is restarted and the IP address assigned by DHCP server will be assigned.

If a DHCP address cannot be assigned, it will default to "192.168.1.160."



**7. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)





**8. Set the time for the additional station.**

[“Time \(→page 177\)”](#)



**9. Set the display language for the additional station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**10. Complete**

---

---

## 6.2.4 Delete a station (For IPv4 address with DHCP)

---

---

**!** Important

- If a page is placed without deleting the station from the system, the operation may be delayed.

Use flowchart to delete a station.

**1. Set the language.**

[“Language \(→page 158\)”](#)



**2. Retrieve the setting data for all the stations.**

[“Download Settings From Station \(→page 143\)”](#)



**3. From the setting data, delete the data of the station to be deleted.**

[“Remove Station \(→page 173\)”](#)



**4. Upload the setting data to all stations.**


[“Upload Settings To Station \(→page 145\)”](#)



**5. Complete**

## 6.2.5 Replace a station (due to malfunction, etc.) (For IPv4 address with DHCP)

Use flowchart to replace a station.





**6. Set the display language of the replaced station (IX-MV7-\*, IX-MV).**  
Refer to each station's Operation Manual.



**6. Complete**



**7. Complete**

## 6.3 For static IPv6 Address

### ! Important

- Save the setting file after configuring the system. Refer to [“Exporting the IX Support Tool System Configuration \(→page 150\)”](#). If the settings are not saved, it may be impossible to restore them after maintenance or after-sales servicing.

### 6.3.1 Creating new data

Use flowchart to create new configuration, e.g., when installing a new system.

#### 1. Set the language.

[“Language \(→page 158\)”](#)



#### 2. Perform "Create New System."

[“Create new system/import setting data \(→page 123\)”](#)

If using the Wizard function to create a new system, refer to [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#) for further instructions and continue from Step 9.



#### 3. Perform setup using "Table View."

Follow the instructions for each setting item and perform setup. [“System Settings \(Table View\) \(→page 169\)”](#)



#### 4. Install all stations.

Note the MAC addresses of all the stations.



#### 5. Associate the created setting data to the station.

[“Association Settings \(→page 160\)”](#)



#### 6. Set the communication method for the IX Support Tool to "IPv6."

[“IX Support Tool Settings \(→page 156\)”](#)





**7. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**8. Set the time for all stations.**

[“Time \(→page 177\)”](#)



**9. Set the display language for all stations (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**10. Complete**

---


---

### 6.3.2 Change the settings (For static IPv6 address)

---

---

Use this flowchart when changing the settings.





**5. Upload the setting data to all stations.**

["Upload Settings To Station"](#)  
(→page 145)



**5. Complete**



**6. Complete**

---

### 6.3.3 Add a station (For static IPv6 address)

---

Use flowchart to add a station.

**1. Set the language.**

["Language \(→page 158\)"](#)



**2. Retrieve the setting data for all the stations.**

["Download Settings From Station \(→page 143\)"](#)



**3. Set the communication method for the IX Support Tool to "IPv4."**

["IX Support Tool Settings \(→page 156\)"](#)



**4. Add the setting data.**

["System Settings \(Table View\) \(→page 169\)"](#)

First, add the station data to ["Station Information \(→page 170\)"](#).



**5. Install the additional station.**

Note the MAC addresses of all the stations.



**6. Associate the setting data with the additional station.**

["Association Settings \(→page 160\)"](#)



**7. Set the communication method for the IX Support Tool to "IPv6."**

["IX Support Tool Settings \(→page 156\)"](#)



**8. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)





**9. Set the time for the additional station.**

[“Time \(→page 177\)”](#)



**10. Set the display language for the additional station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**11. Complete**

---

### 6.3.4 Delete a station (For static IPv6 address)

---

Use flowchart to delete a station.

#### Important

- If a page is placed without deleting the station from the system, the operation may be delayed.

#### 1. Set the language.

["Language \(→page 158\)"](#)



#### 2. Retrieve the setting data for all the stations.

["Download Settings From Station \(→page 143\)"](#)



#### 3. From the setting data, delete the data of the station to be deleted.

["Remove Station \(→page 173\)"](#)



#### 4. Upload the setting data to all stations.

["Upload Settings To Station \(→page 145\)"](#)



#### 5. Complete

### 6.3.5 Replace a station (due to malfunction, etc.) (For static IPv6 address)

Use flowchart to replace a station.

#### 1. Set the language.

["Language \(→page 158\)"](#)



Can the setting data of the station to be replaced be retrieved?

YES



NO



#### 2. Retrieve the setting data from the station to be replaced.

["Download Settings From Station \(→page 143\)"](#)



#### 2. Replace the station.

Note the MAC address of the station to be replaced.



#### 3. Replace the station.

Note the MAC address of the station to be replaced.



#### 3. Change "Static / DHCP" to "Static IPv6" for the newly installed station and configure an appropriate "IPv6 Address."

To configure a station through a Web browser, refer to the Web Setting Manual for each station.



#### 4. Change "Static / DHCP" to "Static IPv6" for the newly installed station and configure an appropriate "IPv6 Address."

To configure a station through a Web browser, refer to the Web Setting Manual for each station.



#### 4. Replace the setting data.

\*If the settings were changed with the station, they cannot be reflected.

["Station Replacement \(→page 162\)"](#)



#### 5. Replace the setting data.

["Station Replacement \(→page 162\)"](#)



#### 5. Set the display language for the replaced station (IX-MV7-\*, IX-MV).

Refer to the Operation Manual for each station.





**6. Set the display language for the replaced station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**6. Complete**



**7. Complete**

## 6.4 For stateless IPv6 address

### ! Important

- Save the setting file after configuring the system. Refer to [“Exporting the IX Support Tool System Configuration \(→page 150\)”](#). If the settings are not saved, it may be impossible to restore them after maintenance or after-sales servicing.

### 6.4.1 Creating new data

Use flowchart to create new configuration, e.g., when installing a new system.

#### 1. Install a device (router, etc.) that can transmit Router Advertisement (RA) (that can perform stateless auto-configuration).

Do not change the device so that it cannot transmit Router Advertisement (RA). For how to set up, refer to the manual of the device.



#### 2. Set the language.

[“Language \(→page 158\)”](#)



#### 3. Perform "Create New System."

[“Create new system/import setting data \(→page 123\)”](#)

If using the Wizard function to create a new system, refer to [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#) for further instructions and continue from Step 10.



#### 4. Perform setup using "Table View."

Follow the instructions for each setting item and perform setup. [“System Settings \(Table View\) \(→page 169\)”](#)



#### 5. Install all stations.

Note the MAC addresses of all the stations.





**6. Associate the created setting data to the station.**

[“Association Settings \(→page 160\)”](#)

Each station is restarted and IPv6 Address will be automatically configured.  
If IP Address fails to be automatically configured, it will become "FDC2::7000." If this happens, cycle power to the station, and then the IP Address will be automatically reconfigured.



**7. Set the communication method for the IX Support Tool to "IPv6."**

[“IX Support Tool Settings \(→page 156\)”](#)



**8. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**9. Set the time for all stations.**

[“Time \(→page 177\)”](#)



**10. Set the display language for all stations (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**11. Complete**

---

---

## 6.4.2 Change the settings (For stateless IPv6 address)

---

---

Use this flowchart when changing the settings.

**1. Set the language.**

["Language \(→page 158\)"](#)



**2. Retrieve the setting data for all the stations.**

["Download Settings From Station \(→page 143\)"](#)



**3. Perform setup.**

Follow the instructions for each setting item and perform setup.

["System Settings \(Table View\) \(→page 169\)"](#)["System Settings \(Station View\) \(→page 374\)"](#)



**Were any of the following changed? "Number," "Name," "Location," "IP Address," "Location Registry," "Camera Name"**

YES



NO



**Was "IP Address" changed from among these options?**

YES



NO



**4. Upload the setting data to the station whose settings were changed.**

["Upload Settings To Station \(→page 145\)"](#)



**4. Because the setting data for the station whose IP address was changed is no longer associated, re-associate the data.**

["Association Settings \(→page 160\)"](#)

The station will be restarted, and the changed IP Address will be reflected in the station.



**4. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)



**5. Complete**



**5. Upload the setting data to all stations.**

[“Upload Settings To Station  
\(→page 145\)”](#)



**5. Complete**



**6. Complete**

---

---

### 6.4.3 Add a station (For stateless IPv6 address)

---

---

Use flowchart to add a station.

**1. Set the language.**

["Language \(→page 158\)"](#)



**2. Retrieve the setting data for all the stations.**

["Download Settings From Station \(→page 143\)"](#)



**3. Add the setting data.**

["System Settings \(Table View\) \(→page 169\)"](#)

First, add the station data to ["Station Information \(→page 170\)"](#).



**4. Install the additional station.**



**5. Set the communication method for the IX Support Tool to "IPv4."**

["IX Support Tool Settings \(→page 156\)"](#)



**6. Associate the setting data with the additional station.**

["Association Settings \(→page 160\)"](#)

The station is restarted and IPv6 Address will be automatically configured.

If IP Address fails to be automatically configured, it will become "FDC2::7000." If this happens, cycle power to the station, and then the IP Address will be automatically reconfigured.



**7. Set the communication method for the IX Support Tool to "IPv6."**

["IX Support Tool Settings \(→page 156\)"](#)





**8. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**9. Set the time for the additional station.**

[“Time \(→page 177\)”](#)



**10. Set the display language for the additional station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**11. Complete**

---

## 6.4.4 Delete a station (For stateless IPv6 address)

---

Use flowchart to delete a station.

### Important

- If a page is placed without deleting the station from the system, the operation may be delayed.

#### 1. Set the language.

[“Language \(→page 158\)”](#)



#### 2. Retrieve the setting data for all the stations.

[“Download Settings From Station \(→page 143\)”](#)



#### 3. From the setting data, delete the data of the station to be deleted.

[“Remove Station \(→page 173\)”](#)



#### 4. Upload the setting data to all stations.

[“Upload Settings To Station \(→page 145\)”](#)



#### 5. Complete

## 6.4.5 Replace a station (due to malfunction, etc.) (For stateless IPv6 address)

Use flowchart to replace a station.

### 1. Set the language.

["Language \(→page 158\)"](#)



Can the setting data of the station to be replaced be retrieved?

YES



NO



### 2. Retrieve the setting data from the station to be replaced.

["Download Settings From Station \(→page 143\)"](#)



### 2. Replace the station.

Note the MAC address of the station to be replaced.



### 3. Replace the station.

Note the MAC address of the station to be replaced.



### 3. Change "Static / DHCP" to "Static IPv6" for the newly installed station and configure an appropriate "IPv6 Address."

To configure a station through a Web browser, refer to the Web Setting Manual for each station.



### 4. Change "Static / DHCP" to "Static IPv6" for the newly installed station and configure an appropriate "IPv6 Address."

To configure a station through a Web browser, refer to the Web Setting Manual for each station.



### 4. Replace the setting data.

\*If the settings were changed with the station, they cannot be reflected.

["Station Replacement \(→page 162\)"](#)

The station is restarted and IPv6 Address will be automatically configured.

If IP Address fails to be automatically configured, it will become "FDC2::7000." If this happens, cycle power to the station, and then the IP Address will be automatically reconfigured.





**5. Replace the setting data.**

[“Station Replacement \(→page 162\)”](#)

The station is restarted and IPv6 Address will be automatically configured.  
If IP Address fails to be automatically configured, it will become "FDC2::7000." If this happens, cycle power to the station, and then the IP Address will be automatically reconfigured.



**5. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**6. Upload the setting data to all stations.**

[“Upload Settings To Station \(→page 145\)”](#)



**6. Set the display language for the replaced station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**7. Set the display language for the replaced station (IX-MV7-\*, IX-MV).**

Refer to the Operation Manual for each station.



**7. Complete**



**8. Complete**

## 6.5 For IPv6 address with DHCP

### ! Important

- Save the setting file after configuring the system. Refer to [“Exporting the IX Support Tool System Configuration \(→page 150\)”](#). If the settings are not saved, it may be impossible to restore them after maintenance or after-sales servicing.

### 6.5.1 Creating new data

Use flowchart to create new configuration, e.g., when installing a new system.

#### 1. Set up the DHCP server.

Configure so that a static IP address is assigned to the station by the DHCP server.  
DUID of the station is "00030001 + MAC address."  
For information on DHCP server setting methods, refer to the DHCP server manual.



#### 2. Set the language.

[“Language \(→page 158\)”](#)



#### 3. "Create New System"

[“Create new system/import setting data \(→page 123\)”](#)

If using the Wizard function to create a new system, refer to [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#) for further instructions and continue from Step 10.



#### 4. Configure using "Table View"

Follow the instructions for each setting item and perform setup. [“System Settings \(Table View\) \(→page 169\)”](#)



#### 5. Install all stations.

Note the MAC addresses of all the stations.





**6. Associate the created setting data to the station.**

["Association Settings \(→page 160\)"](#)

The station is restarted and the IPv6 Address assigned by DHCP server beforehand will be assigned.  
If a DHCP address cannot be assigned, it will default to "FDC2::7000."



**7. Choose "IPv6" for the communication method of IX Support Tool.**

["IX Support Tool Settings \(→page 156\)"](#)



**8. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)



**9. Set the time for all stations.**

["Time \(→page 177\)"](#)



**10. Set the display language for each station (IX-MV7-\*, IX-MV).**

Refer to each station's Operation Manual.



**11. Complete**

## 6.5.2 Change the settings (For IPv6 address with DHCP)

Use this flowchart when changing the settings.

### 1. Set the language.

["Language \(→page 158\)"](#)



### 2. Retrieve the setting data for all the stations.

["Download Settings From Station \(→page 143\)"](#)



### 3. Perform setup.

Follow the instructions for each setting item and perform setup.

["System Settings \(Table View\) \(→page 169\)"](#) ["System Settings \(Station View\) \(→page 374\)"](#)



**Did you change the "Number," "Name," "Location," "IP Address," "Location Registry," or "Camera Name?"**

YES



NO



**Was "IP Address" changed from among these options?**

YES



NO



**4. Upload the setting data to the station whose settings were changed.**

["Upload Settings To Station \(→page 145\)"](#)



**4. Cancel the association for the setting data for the station whose IP address was changed, then re-associate the data.**

["Association Settings \(→page 160\)"](#)

The station will be restarted, and the changed "IP Address" will be reflected in the station.



**4. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)



**5. Complete**



**5. Upload the setting data to all stations.**

[“Upload Settings To Station  
\(→page 145\)”](#)

**5. Complete**



**6. Complete**

---

### 6.5.3 Add a station (For IPv6 address with DHCP)

---

Use flowchart to add a station.

**1. Configure so that the IP address for the station to be added to the DHCP server is assigned as a static address.**

For information on DHCP server setting methods, refer to the DHCP server manual.



**2. Set the language.**

["Language \(→page 158\)"](#)



**3. Retrieve the setting data for all the stations.**

["Download Settings From Station \(→page 143\)"](#)



**4. Add the setting data.**

["System Settings \(Table View\) \(→page 169\)"](#)

First, add the station data to ["Station Information \(→page 170\)"](#).



**5. Install the additional station.**



**6. Choose "IPv4" for the communication method of IX Support Tool.**

["IX Support Tool Settings \(→page 156\)"](#)



**7. Associate the setting data with the additional station.**

["Association Settings \(→page 160\)"](#)

The station is restarted and the IPv6 Address assigned by DHCP server beforehand will be assigned.

If a DHCP address cannot be assigned, it will default to "FDC2::7000."





**8. Choose "IPv6" for the communication method of IX Support Tool.**

["IX Support Tool Settings \(→page 156\)"](#)



**9. Upload the setting data to all stations.**

["Upload Settings To Station \(→page 145\)"](#)



**10. Set the time for the additional station.**

["Time \(→page 177\)"](#)



**11. Set the display language of the station to add (IX-MV7-\*, IX-MV).**

Refer to each station's Operation Manual.



**12. Complete**

---

---

## 6.5.4 Delete a station (For IPv6 address with DHCP)

---

---

Use flowchart to delete a station.

### Important

- If a page is placed without deleting the station from the system, the operation may be delayed.

#### 1. Set the language.

["Language \(→page 158\)"](#)



#### 2. Retrieve the setting data for all the stations.

["Download Settings From Station \(→page 143\)"](#)



#### 3. From the setting data, delete the data of the station to be deleted.

["Remove Station \(→page 173\)"](#)



#### 4. Upload the setting data to all stations.


["Upload Settings To Station \(→page 145\)"](#)



#### 5. Complete

## 6.5.5 Replace a station (due to malfunction, etc.) (For IPv6 address with DHCP)

Use flowchart to replace a station.





**6. Replace the setting data.**

[“Station Replacement \(→page 162\)”](#)

The station is restarted and the IPv6 Address assigned by DHCP server beforehand will be assigned.  
If a DHCP address cannot be assigned, it will default to "FDC2::7000."



**7. Set the display language of the replaced station (IX-MV7-\*, IX-MV).**

Refer to each station's Operation Manual.



**8. Complete**




**6. Set the display language of the replaced station (IX-MV7-\*, IX-MV).**

Refer to each station's Operation Manual.



**7. Complete**



# Startup and Configuration

# 1. System requirements


---

PC requirements for using the IX Support Tool.


Operating System	Windows 7 Professional, Windows 7 Enterprise, Windows 7 Ultimate Windows 8, Windows 8 pro, Windows 8 Enterprise Windows 8.1, Windows 8.1 pro, Windows 8.1 Enterprise Windows 10 Home, Windows 10 pro, Windows 10 Enterprise Windows 10 Education
CPU	32 bit (x86) processor or 64 bit (x64) processor of 1 GHz or higher
Memory	4 GB RAM or higher
Resolution	1280x768 or greater

## 2. Installing IX Support Tool


1. Access our Web site at <https://www.aiphone.net/product/support/> and download the IX Support Tool to your PC.
2. Extract the downloaded file.  
Double-click "setup.exe" in the extracted folder and install IX Support Tool.
  - If .NET Framework4.5 is not installed yet, install .NET Framework4.5 first. Install this, following the instructions on the screen.



3. Click **[Next]**.




4. Choose the location to install the IX Support Tool and the user who will use the IX Supervision Tool, then click **[Next]**.




**!** Important

- If using a PC with user privileges, select "All Users."

**5.** Click **[Next]**.




**6.** Click **[Close]**.




- IX Support Tool is now installed.

## 3. Login and registration of the station

1. Double-click the "AIPHONE IX SupportTool" shortcut created on the desktop or "AIPHONE\_IX\_SupportTool.exe" in the folder specified during installation.  
By default, it will be installed in "Computer > Local Disk(C) > Program Files > AIPHONE\_IX\_SupportTool."



2. Enter "ID" and "Password" and click **[Login]**.
  - The setting data configured during the previous login session will be shown.
  - If logging into the IX Support Tool for the first time, proceed to Step 3.



- The default ID and Password are "admin."

3. When first logging into IX Support Tool, the "New System" screen is displayed.  
Refer to ["Create new system/import setting data \(→page 123\)"](#) and proceed with the setup.

System settings

Wizard function selection

Select the automatic door release setting

Number of Stations settings

“Restore System Settings (→page 164)”

“Reading in data created by another IX Support Tool (→page 139)”

Once "New System" configuration is complete, setting data is automatically generated and the Settings (Table View) screen is displayed.

Table View

Station View

Number of Notes: 2

#	Number	Name	Location	Station Type
0001	0001	Master Stations1		IX-MV7-*
0002	0002	Master Stations2		IX-MV7-*
0003	0003	Master Stations3		IX-MV7-*
0004	0004	Master Stations4		IX-MV7-*
0005	0005	Master Stations5		IX-MV7-*
0006	0006	Master Stations6		IX-MV
0007	0007	Master Stations7		IX-MV
0008	0008	Master Stations8		IX-MV
0009	0009	Master Stations9		IX-MV
0010	0010	Master Stations10		IX-MV
0011	0011	Video Stations1		IX-DV, IX-DVF(-)
0012	0012	Video Stations2		IX-DV, IX-DVF(-)
0013	0013	Video Stations3		IX-DV, IX-DVF(-)
0014	0014	Video Stations4		IX-DV, IX-DVF(-)
0015	0015	Video Stations5		IX-DV, IX-DVF(-)

Text in red are required settings.

# 4. How to configure

When logging into the IX Support Tool, the following setting window will be shown. Each station can be configured from this window.

- Depending on PC and OS being used, the window may be slightly different.
- After setup, refer to the Operation Manual for each station and confirm operation.

## 4.1 Settings window

### Settings screen sample

#### Table View(→page 169)

Configure all the stations in the system from the Settings window.

**Setting switching:** Click to switch to Settings (Station View).

**Update:** Click this button to update the station settings.

**Menu bar:** Allows user to create new setting data, save the settings, etc.(→page 122)

**Notes:** Displays notes.

**Title bar:** Displays the system name and title when editing settings.

IX Support Tool - [Identification] - [System Name:samele]

File(F) Edit(E) Language(V) Tools(T) Help(H)

Press F1 (or Fn + F1) key after selecting an item to view detailed explanation.

**Table View** [Related Settings] Remove Station Location Registry

**Station View**

Number of Notes 2

1. Locations must be created in the Location Registry before they can be assigned to a Station.  
2. Station Type cannot be changed once registered. To modify, station must be removed.

Text in red are required settings.

Station Information				
Identification				
#	Number	Name	Location	Station Type
0001	0001	Master Stations1		IX-MV7-*
0002	0002	Master Stations2		IX-MV7-*
0003	0003	Master Stations3		IX-MV7-*
0004	0004	Master Stations4		IX-MV7-*
0005	0005	Master Stations5		IX-MV7-*
0006	0006	Master Stations6		IX-MV
0007	0007	Master Stations7		IX-MV
0008	0008	Master Stations8		IX-MV
0009	0009	Master Stations9		IX-MV
0010	0010	Master Stations10		IX-MV
0011	0011	Video Stations1		IX-DV, IX-DVF(*)
0012	0012	Video Stations2		IX-DV, IX-DVF(*)
0013	0013	Video Stations3		IX-DV, IX-DVF(*)
0014	0014	Video Stations4		IX-DV, IX-DVF(*)
0015	0015	Video Stations5		IX-DV, IX-DVF(*)

**Setting menu:** Show all items that can be configured. Click the title to be configured to display the appropriate Settings screen.

**Settings screen:** The Settings screen for the currently selected title is displayed.

**Station View** (→page 374)

Station settings can be configured for each station in the system.

Displays station information while editing settings.

**Update:** Click this button to update the station settings.


**Setting switching:** Click to switch to Settings (Table View).

**Menu bar:** Allows user to create new setting data, save the settings, etc. (→page 122)

**Title bar:** Displays the system name and title when editing settings.

**Select Station to Edit:** Allows user to change the station to be edited.

**Copy Settings:** Copies the settings currently being edited to another station. (→page 83)



**Setting menu:** Show all items that can be configured. Click the title to be configured to display the appropriate Settings screen.

**Settings screen:** The Settings screen for the currently selected title is displayed.

**Note**

- Settings which cannot be modified will be grayed out.

## 4.2 How to configure

1. Click the title to be configured.
  - The Settings window for that particular title will be shown.
2. Enter setting values for each entry.
  - The selected field will turn orange. (Settings (Table View) only)
  - When changing the settings, the field will turn pink. (Settings (Table View) only)
  - Some titles allow copy and paste.


Station Information				
Identification				
#	Number	Name	Location	Station Type
0001	0001	Master Stations11		IX-MV7-*
0002	0002	Master Stations2		IX-MV7-*
0003	0003	Master Stations3		IX-MV7-*

Text in red are required settings

### ! Important

- Be sure to input the settings for entries in red. Upon use, leave the unnecessary items at their default values.

- Select an entry field and press the F1 key to display a Detailed Explanation (Settings (Table View) only).




**Move to related item:** This allows you to move to the Settings screen for related entries.

3. When you are done configuring on this screen, click **[Update]** to save the settings.
  - To cancel all settings, click another title in the Setting menu.
  - If there is an error when clicking **[Update]**, the error message will be shown and the settings will not be allowed to be saved.
  - The field will be shown in red if there is an error. (Settings (Table View) only)

Station Information					Network Settings <span style="color: red;">Text in red are red</span>														
#	Identification				IP Address														
	Number	Name	Location	Station Type	Hostname	IP Version	Static / DHCP	IPv4 Address				Subnet Mask				Default Gateway			
								1	2	3	4	1	2	3	4	1	2	3	4
0001	0011	Video Stations1		IX-DV, IX-DVF(-*)		IPv4	Static	0	0	1	11	1	2	3	4				

- If another title is selected without clicking **[Save]**, the system will prompt whether to save the settings. Click **[Yes]** to save the settings; click **[No]** to continue without saving.
- Click **[Cancel]** to return to the original screen.



**4.** Perform Steps 1 - 3 for other titles as well.

### 4.3 Copy settings (Settings (Station View))

Copy the settings marked with "♣" in Settings (Station View). The copied settings can be applied either to all station types or to all stations of the same type.

The screenshot shows a dialog box titled "Copy Settings". It has two radio buttons: "Copy to all stations" (selected) and "Copy to stations by Type". To the right of these is a small number "2". Below is a "Settings:" label followed by a dropdown menu showing "IP Address". To the right of the dropdown is a small number "3". Below the dropdown is a red asterisk icon and the text "Indicates fields which can be copied". At the bottom is a "Copy" button with a small number "4" to its right.

#### How to copy the settings

1. Click the title of the entry to copy and display the Settings screen.
2. Select "Copy to all stations" or "Copy to stations by Type."
3. Select the items to be copied from "Settings."
4. Click **[Copy]**.
  - The "♣" entries will be copied.

## ! Important

- Please copy the setting items below after copying [“Custom Sound Registry \(except IXW-MA\) \(→page 416\)”](#).
  - "Call Origination" - [“Ringback Tone \(except IX-MV\) ♣ \(→page 423\)”](#)
  - "Call Origination" - [“Busy Tone \(except IX-MV\)♣ \(→page 429\)”](#)
  - "Call Origination" - [“Error Tone \(Call Failed\) \(except IX-MV7-\\* and IX-MV\)♣ \(→page 430\)”](#)
  - "Incoming Call" - [“Ringtone \(→page 432\)”](#)
  - "Incoming Call" - [“Call Button \(for IX-MV7-\\* and IX-MV\) \(→page 433\)”](#)
  - "Incoming Call" - [“Option Input \(for IX-MV7-\\* and IX-MV\) \(→page 434\)”](#)
  - "Relay Output" - [“Door Release \(→page 445\)”](#)
  - "Relay Output" - [“Relay Control \(start\) \(except IX-DA, IX-DF\(-\\*\)\) and IX-BA, IX-SS\(-\\*\)\) \(→page 445\)”](#)
  - "Relay Output" - [“Relay Control \(end\) \(except for IX-DA, IX-DF\(-\\*\)\) and IX-BA, IX-SS\(-\\*\)\) \(→page 446\)”](#)
  - "Option Input Page" - [“Message File Name \(→page 454\)”](#)
  - "Network Camera Integration" - [“Event Tone \(for IX-MV\)♣ \(→page 460\)”](#)
  - "Paging Settings" - [“Paging Pretone \(→page 461\)”](#)
  - "Communication Audio Messages" - "Start Communication" - [“Message \(→page 489\)”](#)
  - "Communication Audio Messages" - "Code Received" - [“Message \(→page 490\)”](#)
  - "Chime" - "Weekly Schedule" - [“Chime \(→page 492\)”](#)
  - "Chime" - "Daily Schedule" - [“Chime \(→page 494\)”](#)
  - "Speed Dials / Favorites" - "Group Message Page" - [“Message \(→page 522\)”](#)
  - "Speed Dials / Favorites" - "All Message Page" - [“Message \(→page 523\)”](#)
  - "Volume / Tone" - [“Communication Timeout Notification \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\)♣ \(→page 529\)”](#)
  - "Volume / Tone" - [“Communication End Pretone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\)♣ \(→page 530\)”](#)
  - "Volume / Tone" - [“Call Queue Notification \(for IX-MV7-\\*\)♣ \(→page 530\)”](#)
  - "Volume / Tone" - [“Paging Pretone \(for IX-MV7-\\* and IX-MV\) ♣ \(→page 531\)”](#)
  - "Volume / Tone" - [“Auto Answer Tone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\)♣ \(→page 531\)”](#)
  - "Volume / Tone" - [“On Hold \(for IX-MV7-\\*\)♣ \(→page 532\)”](#)
  - "Volume / Tone" - [“Key Received \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, IX-SS\(-\\*\)\)♣ \(→page 532\)”](#)
  - "Volume / Tone" - [“Error \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\)♣ \(→page 533\)”](#)
  - "Communication" - [“Communication Start Tone \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\)♣ \(→page 535\)”](#)
  - "Monitor" - [“Monitored Notification \(except IX-MV7-\\* and IX-MV\) ♣ \(→page 537\)”](#)

## 5. System settings list

The following items can be configured using IX Support Tool.

The symbols indicate the following:

- ◆: Be sure to input the settings. Upon use, leave the unnecessary items at their default values.
- ♣: The setting item information can be copied.
  - The following list is the summary of IX Support Tool. The contents, how they are displayed, and the order of entries may vary from the actual ones.
  - Download and back up the setting file (Table View: ([→page 371](#)), Station View: ([→page 548](#))) in case after-sales service is required, and store it in a safe place where it will not be lost.
  - If a backup has not been performed, it may not be possible to recover the data during after-sales service.

### ■ Table View

Setting items				Reference pages
<b>Station Information</b>				
Identification	-	-	Number◆	170
	-	-	Name	171
	-	-	Location (except for IXW-MA)	171
	Add Station	-	-	172
	Remove Station	-	-	173
Location Registry (except for IXW-MA)	-	-	174	
ID and Password	-	-	Administrator ID◆	175
	-	-	Administrator Password◆	175
	-	-	User ID◆	175
	-	-	User Password◆	175
	-	-	ONVIF ID (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ◆	176
	-	-	ONVIF Password (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	176
	-	-	RTSP ID (IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G, IX-RS-* only) ◆	176
Time	Time Zone	-	Select time zone	177
	Daylight Savings Time	-	Enable automatic daylight savings time	177
	Manual Date / Time Setup	-	-	178
Expanded System (not used)	-	-	-	179

Setting items				Reference pages						
<b>Network Settings</b>										
IP Address	-	-	Hostname (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	180						
			IP Version	180						
			Static / DHCP	181						
	IPv4 Address	-	-	IP Address◆	182					
				Subnet Mask◆	182					
				Default Gateway	182					
	IPv6 Address	-	-	IP Address◆	183					
				Default Gateway	183					
	Batch IP Address Configuration	-	-	-	183					
	DNS	Primary Server	-	-	IPv4	185				
IPv6					185					
Secondary Server		-	-	-	IPv4	185				
					IPv6	185				
SIP (except for IXW-MA)	SIP Connections	-	-	SIP Signaling Port◆	186					
				User Agent (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	186					
	SIP Server (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Primary Server	-	-	ID	186				
					Password	187				
					IPv4 Address	187				
					IPv6 Address	187				
					Port◆	187				
					Secondary Server	-	-	-	ID	187
									Password	187
		IPv4 Address	187							
		IPv6 Address	188							
		Port◆	188							
		Tertiary Server	-	-	-	ID	188			
						Password	188			
						IPv4 Address	188			
						IPv6 Address	188			
Port◆	188									
Miscellaneous	-	-	-	Register Transmission Interval [sec] (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)) ◆	189					

Setting items				Reference pages
			DTMF digit interval timeout [sec] (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)) ◆	189
			Call health check timer [sec]◆	189
Multicast Address (IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	-	-	IPv4	190
			IPv6	190
	Batch Multicast Address Configuration	-	-	-
Video (IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	Video Encoder 1	-	Video Codec (IX-DA, IX-DF(-*) only)	192
			Resolution (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	192
			Frame Rate [fps] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	193
			Select Profile [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	193
			I-picture interval [H.264/AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	193
			Bit rate [kbps] [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	193
			Select Quality [Motion-JPEG] (IX-DA, IX-DF(-*) only)	194
			RTP Start Port◆	194
			RTP End Port◆	194
			Video Encoder 2	-
	Video Codec (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	195		
	Resolution (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	195		
	Frame Rate [fps] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	195		
	Select Profile [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	196		

Setting items				Reference pages	
			I-picture interval [H.264/AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	196	
			Bit rate [kbps] [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	196	
			Select Quality [Motion-JPEG] (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	196	
			RTP Start Port◆	196	
			RTP End Port◆	196	
	Master Station Video Setting (IX-MV7-* only)	-	-	Video Streaming	197
				Frame Rate [fps]	197
				Select Profile	197
				I-picture interval◆	197
				Bit rate [kbps]	197
Audio (except for IXW-MA)	-	-	Audio Codec	200	
			Audio RTP Transmission Interval [msec]	201	
			RTP Idle Detection Time [sec]◆	202	
			Audio 1 RTP Start Port◆	202	
			Audio 1 RTP End Port◆	202	
			Audio 2 RTP Start Port◆	202	
			Audio 2 RTP End Port◆	202	
	Audio Buffer	-	-	Packets Buffered at Audio Start	202
				Maximum Packets Buffered	203
Packet Priority	-	-	TOS Value (Audio) (except for IXW-MA) ◆	204	
			TOS Value (Video) (IX-MV7-*, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	204	
			TOS Value (SIP) (except for IXW-MA) ◆	204	
			VLAN Setting	204	
			VLAN ID◆	205	
			VLAN Priority	205	
NTP	Enable NTP	-	-	206	
	Synchronization Interval [hour]◆	-	-	206	
	Primary Server	Address	IPv4	206	
			IPv6	207	
		Port◆	-	207	

Setting items				Reference pages	
	Secondary Server	Address	IPv4	<a href="#">207</a>	
			IPv6	<a href="#">207</a>	
		Port◆	-	<a href="#">207</a>	
<b>System Information</b>					
Location Registry	-	-	-	<a href="#">208</a>	
Address Book (IX-MV7-* and IX-MV only)	Open Station List	-	-	<a href="#">209</a>	
	Open Network Camera List	-	-	<a href="#">212</a>	
		Open Network Camera Registry	Camera Name◆		<a href="#">214</a>
			Hostname		<a href="#">214</a>
			IP Address (IPv4)		<a href="#">214</a>
			IP Address (IPv6)		<a href="#">214</a>
			ID◆		<a href="#">214</a>
			Password◆		<a href="#">214</a>
Group (for Master) (IX-MV7-* and IX-MV only)	Create Group	-	-	<a href="#">218</a>	
Custom Sound Registry	-	-	-	<a href="#">221</a>	
<b>Call Settings</b>					
Station Information (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), or IX-SS-2G only)	-	-	Call Button Function	<a href="#">224</a>	
Called Stations (Master Stations) (IX-MV7-* and IX-MV only)	-	-	Call Destination Settings are unnecessary, Master Station can call any station in Address Book.	-	
Called Stations (Door/Sub Stations) (except for IX-MV7-*, IX-MV, or IXW-MA)	-	-	-	<a href="#">225</a>	

Setting items			Reference pages		
Call Origination (except for IXW-MA)	Call Origination Advanced Settings	-	Call Method (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	228	
			Ringback Tone (except for IX-MV)	229	
			Call Timeout (except for <b>[Call Button]</b> - IX-MV) ♦	229	
			Ringback Tone Count [time(s)] (except for IX-MV)	230	
			Call Destination ( <b>[Option Input 1 - 4]</b> - IX-MV7-* and IX-MV only)	230	
			Standard Mode Settings (except for IX-MV7-* and IX-MV)	230	
			Destination Dwell 1 - 8 (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	230	
			Destination Dwell Time (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♦	231	
			Weekly Schedule (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	232
				End Time	232
				Call Destination	232
				Priority	233
			Daily Schedule (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	234
				End Time	234
	Call Destination	234			
	Priority	235			
	Tone Settings	-	Busy Tone (except for IX-MV)	235	
			Error Tone (Call Failed) (except for IX-MV7-* and IX-MV)	236	
	Call Restart Function (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))		Call Restart Function	236	

Setting items				Reference pages
Incoming Call (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	Call Answer Settings	-	Auto Answer	237
	Ringtone	-	Ringtone (except for IX-MV7-*, IX-MV)	238
			Ringback Tone Count (except for IX-MV7-*)	238
			Call Button (IX-MV7-* and IX-MV only)	239
			Option Input (IX-MV7-* and IX-MV only)	239
			Call Button Ringtone Count [time(s)] (IX-MV7-* only)	240
			Option Input Ringtone Count [time(s)] (IX-MV7-* only)	240
	VoIP Phone (except for IX-MV)	-	VoIP Phone Call Priority	240
<b>Option Input/Relay Output Settings</b>				
Option Input	Option Input Advanced Settings	Name (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	-	241
		Function	-	242
		Type	-	242
		Detection Time	Detection Time Range	242
			Detection Time◆	242
		API	API 1	243
			API 2	243
Relay Output	Relay Output Advanced Settings	Name (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	-	244
		Function	-	245
		Option Relay Control	-	246
		Output Time Range	Output Time Range	247
			Output Time◆	248
		Door Release Authorization (except for IXW-MA)	-	248

Setting items				Reference pages	
		Sound Settings (except for IX-MV and IXW-MA)	Door Release	249	
			Relay Control (start) (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))	249	
			Relay Control (end) (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))	250	
		Weekly Schedule (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	251	
			End Time	251	
		Daily Schedule (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	252	
			End Time	253	
		Authentication Key	-	Option Relay Control Authentication Key (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	253
		<b>Paging Settings</b>			
	Paging Origination (IX-MV7-* and IX-MV only)	-	-	Paging Timeout [sec]◆	254
Paging Wait Timer [sec] (IX-MV7-* only) ◆				254	
Urgent Page Response (IX-MV7-* only)				255	
Lock Paging (IX-MV7-* only)				255	
All Page (IX-MV-* and IX-MV only)	-	-	-	256	
Option Input Page (IX-MV7-* only)	-	-	Destination	257	
			Group Number	257	
			Priority	257	
			Message File Name	258	
			Play Count [time(s)]	258	

Setting items				Reference pages	
<b>Function Settings</b>					
Door Release (IX-MV7-* and IX-MV only)	Door Release Assignment	-	Contact Assignment	259	
			Authentication Key	260	
Network Camera Integration (IX-MV7-* and IX-MV only)	Profile Setting	-	Profile	262	
			Event Registration	-	Event
	Function (IX-MV7-* only)	262			
	Event Tone (IX-MV7-* only)	263			
	ID (IX-MV7-* only)	263			
	Password (IX-MV7-* only)	263			
	Call Origination (IX-MV7-* only)	264			
	Call Destination (IX-MV7-* only)	264			
	Priority (IX-MV7-* only)	264			
	Event Tone (IX-MV only)	-	-	264	
Play count of Event Tone	-	-	264		
Paging Settings (except for IX-MV7-*, IX-MV, or IXW-MA)	-	-	Paging Pretone	267	
Bathroom Call (IXW-MA only) (not used)	-	-	-	268	
Email	Server Settings	-	SMTP Server	269	
			SMTP Port◆	269	
			SMTP Encryption	270	
	Authentication Settings	-	-	SMTP Authentication	271
				Mode	271
				ID	271
				Password	271
	Email Addresses	-	-	Destination 1	271
				Destination 2	271
				Destination 3	272
				Source Address	272

Setting items			Reference pages		
Email Event Trigger	-	Outgoing Normal Call (except for IXW-MA)	272		
		Incoming Normal Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	272		
		Outgoing Priority Call (except for IXW-MA)	272		
		Incoming Priority Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	272		
		Outgoing Urgent Call (except for IXW-MA)	272		
		Incoming Urgent Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	273		
		Door Release Activated (IX-MV7-*, IX-MV, or IX-RS-* only)	273		
		Call Failed (except for IXW-MA)	273		
		Latch Reset (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G only)	273		
		Error	273		
		Station Restarted	273		
		SD Card Error (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	273		
		Recording Memory Full (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	274		
		Line Supervision (Passed) (IX-MV7-* only)	274		
		Line Supervision (Failed) (IX-MV7-* only)	274		
		Device Check (Passed) (IX-MV7-* only)	274		
		Device Check (Failed) (IX-MV7-* only)	274		
		Subject	274		
		Periodic Log Transmission	-	Periodic Log Transmission	275
				Periodic Log Transmit Time	275
Periodic Log Transmit Interval	275				
Periodic Log Transmission Subject	276				

Setting items				Reference pages
	Send Test Email (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	277
	Additional Settings (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	-	Attach Image	278
			Image Filename	278
CGI Integration	-	-	CGI Functionality	279
SIF Integration	SIF Functionality	-	-	280
	SIP URI Format (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	280
	SIF Settings (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	Program Type	281
			IPv4	281
			IPv6	281
			Destination Port	281
			SSL	281
	Transmission Trigger (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	Connection	281
			Begin Outgoing Call (except for IXW-MA)	282
			Begin Communication (Source) (except for IXW-MA)	282
			Door Release Indication (IX-MV7-* and IX-RS-* only)	282
			End Communication (except for IXW-MA)	282
			Change contact	282
			Unit error	283
			Begin broadcast (IX-MV7-* only)	283
End broadcast (IX-MV7-* only)			283	
Begin Transfer (IX-MV7-* only)			283	
End Transfer (IX-MV7-* only)	283			
Periodical Transmission	283			
Initialization Notice	283			
End Outgoing Call (except for IXW-MA)	284			
Begin Incoming Call (except for IXW-MA)	284			

Setting items			Reference pages
		End Incoming Call (except for IXW-MA)	284
		Latch Reset (except for IX-MV7-* and IXW-MA)	284
		Change Call Destination (except for IXW-MA)	284
		Call Failure (except for IXW-MA)	284
		Begin Incoming Transfer Call (IX-MV7-* only)	284
		Begin On Hold (IX-MV7-* only)	285
		End On Hold (IX-MV7-* only)	285
		Begin Incoming Page (except for IXW-MA)	285
		End Incoming Page (except for IXW-MA)	285
		Paging Failure (IX-MV7-* only)	285
		Begin Monitoring (IX-MV7-* only)	285
		End Monitoring (IX-MV7-* only)	285
		Monitoring Failure (IX-MV7-* only)	286
		Begin Monitored (except for IX-MV7-* and IXW-MA)	286
		End Monitored (except for IX-MV7-* and IXW-MA)	286
		Begin Communication (Destination) (except for IXW-MA)	286
		Begin Privacy (IX-MV7-* only)	286
		End Privacy (IX-MV7-* only)	286
		Keypad Input (IX-MV7-* only)	286
		Speed Dial Input (IX-MV7-* only)	287
		Begin Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	287
		End Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	287
		Recording Memory Full (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	287

Setting items				Reference pages
			Passed Line Supervision (IX-MV7-* only)	287
			Failed Line Supervision (IX-MV7-* only)	287
			Passed Device Check (IX-MV7-* only)	288
			Failed Device Check (IX-MV7-* only)	288
			SD Card Error (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	288
			SIP Registration Failure (except for IXW-MA)	288
			Network Camera Event (IX-MV7-* only)	288
	Periodical Transmission (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Periodical Transmission Interval	Range	290
			Interval◆	290
	Upload SIF File	-	-	291
Download SIF File	-	-	293	
Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	Record Mode (IX-DV, IX-DVF(-*), IX-SSA(-*) only)	-	-	295
	Record Event	-	Incoming Call (IX-MV7-* only)	297
			Communication (Master) (IX-MV7-* only)	297
			Monitor (IX-MV7-* only)	297
			Outgoing Call (IX-DV, IX-DVF(-*), IX-SSA(-*) only)	297
			Communication (Door) (IX-DV, IX-DVF(-*), IX-SSA(-*) only)	297
			Monitored (IX-DV, IX-DVF(-*), IX-SSA(-*) only)	297
			Schedule (IX-DV, IX-DVF(-*), IX-SSA(-*) only)	298
	Recorded Device (IX-MV7-* only)	-	-	298
	Prevent Overwrite	-	-	298
	Video Recording File Length	-	-	298
	Event Recording Timer (IX-MV7-* only)	-	-	299
	Manual Recording (IX-MV7-* only)	-	-	299

Setting items				Reference pages		
	Audio Recording (IX-MV7-*, or IX-DV, IX-DVF(-*) only)	-	-	299		
	Weekly Schedule (IX-DV, IX-DVF(-*), or IX-SSA(-*) only)	-	Start Time	300		
End Time			300			
Communication Audio Messages (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), or IX-SS-2G only)	Start Communication	-	Message	302		
	Code Received	-	Code	303		
Message			303			
Chime (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	Weekly Schedule	-	Start Time	304		
			Chime	305		
	Daily Schedule	-	Start Time	307		
			Chime	307		
CSR	-	-	-	308		
SSL Certificate	-	-	-	309		
IEEE 802.1X (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	IEEE 802.1X	313		
			EAP	313		
			EAP User Name	314		
			EAP Password	314		
Display Mode (IX-MV7-* only)	Master UI Mode	-	-	317		
	Standard Mode		Home Screen	318		
	Receptionist Mode	Color Scheme	-		320	
		Screen Layout	-		321	
		Company Information	Name			323
			Text Size◆			323
			Bold			323
			Text Color			323
		Greeting Information	Greeting			323
	Text Size◆				323	
	Bold				323	
	Text Color				324	
	Images	Company Image			324	
Greeting Image				324		
Receptionist Image				325		

Setting items				Reference pages		
		Button Function	Button 1	325		
			Button 2	325		
			Button 3	325		
			Button 4	326		
			Button Name for Group Call	326		
			Button Name for Select By Name	326		
			Button Name for Select By List	326		
			Button Name for Enter Number	326		
				Group Call Destination	-	326
		Reject Incoming Call	-	326		
Bathroom Link (not used)	-	-	-	327		
<b>Transfer Settings</b>						
Absent Transfer (IX-MV7-* and IX-MV only)	-	-	Absent Transfer	328		
			Transfer Destination List	328		
			Re-Transfer Destination (IX-MV7-* only)	329		
Delay Transfer (IX-MV7-* and IX-MV only)	-	-	Delay Transfer	330		
			Delay Time [sec]◆	330		
			Transfer Destination List	330		
			Re-Transfer Destination (IX-MV7-* only)	331		
Schedule Transfer (IX-MV7-* and IX-MV only)	-	-	Schedule Transfer	332		
			Weekly Schedule	-	Transfer Destination List	333
					Re-Transfer Destination (IX-MV7-* only)	333
					Start Time	333
	End Time	333				
	Daily Schedule (IX-MV7-* only)	-	-	Transfer Destination List	335	
				Re-Transfer Destination	336	
				Start Time	336	
End Time				336		
Lock Transfer (IX-MV7-* only)	-	-	-	337		

Setting items				Reference pages
<b>Station Settings</b>				
Speed Dials / Favorites (IX-MV7-* and IX-MV only)	Advanced Speed Dial Button Settings	Speed Dial Name (IX-MV7-* only)	-	338
		Function	-	339
		Individual Call	Number	339
			Priority	339
		Group Call	Group Number	339
			Priority	340
		Group Page	Group Number	340
			Priority	340
		All Page	Priority	340
		Group Message Page (IX-MV7-* only)	Group Number	340
			Message	341
			Priority	341
			Play Count [time(s)]	341
		All Message Page (IX-MV7-* only)	Message	342
			Priority	342
			Play Count [time(s)]	342
		Monitor (IX-MV7-* only)	Number	342
		Network Camera Monitor (IX-MV7-* only)	Network Camera	343
		Option Relay Control (IX-MV7-* only)	Total	343
			Output Time Range	343
Output Time◆	344			
TLS	344			
Option Relay Control Key	344			
Lock (IX-MV7-* only)	-	344		
Privacy (IX-MV7-* and IX-MV only)	-	-	Privacy	345

Setting items			Reference pages	
Volume / Tone (except for IXW-MA)	Volume	-	Handset Transmit (IX-MV7-*, IX-RS-*, or IX-MV only)	346
			Handset Receive (IX-MV7-*, IX-RS-*, or IX-MV only)	346
			Hands-free Transmit (IX-MV7-*, IX-RS-*, or IX-MV only)	346
			Hands-free Receive (IX-MV7-*, IX-RS-*, or IX-MV only)	347
			Headset Jack Transmit (IX-MV7-* only)	347
			Headset Jack Receive (IX-MV7-* only)	347
			Transmit (except for IX-MV7-*, IX-RS-*, or IX-MV)	347
			Receive (except for IX-MV7-*, IX-RS-*, or IX-MV)	347
			External Input (not used)	347
			External Output (IX-RS-* only)	347
			VoIP Phone Volume Adjustment (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	347
			Ringtone	348
			Paging (IX-DV, IX-DVF(-*), and IX-SSA(-*) only)	348
			Button Feedback (IX-MV7-* and IX-MV only)	348
			Tone	-
Communication End Pretone (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	350			
Call Queue Notification (IX-MV7-* only)	350			
Paging Pretone (IX-MV7-* and IX-MV only)	351			
Auto Answer Tone (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	351			
On Hold (IX-MV7-* only)	352			
Key Received (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))	352			

Setting items				Reference pages
			Error (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	353
	Mic Select (not used)	-	-	353
	Headset Specification (IX-MV7-* only)	-	-	353
	Audio Output (for Master) (IX-MV7-* only)	-	-	353
	Audio Output (for Door) (except for IX-MV7-*, IX-SS-2G, or IX-MV)	-	-	354
Communication (except for IXW-MA)	-	-	Talk Timeout [sec]◆	355
			Communication Start Tone (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	356
			Force Touch-to-Talk (IX-MV7-* and IX-MV only)	356
Monitor (except for IXW-MA, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Monitor Timeout [sec] (IX-MV7-* and IX-MV only) ◆	-	-	357
	Scan Monitor (IX-MV7-* only)	-	Type	358
			Number	358
			Camera Settings	358
			Open Camera List	358
	Prevent Being Monitored (except for IX-MV7-* and IX-MV)	-	-	358
	Monitored Notification Tone (except for IX-MV7-* and IX-MV)	-	-	359
Monitored LED Notification (except for IX-MV7-* and IX-MV)	-	-	360	
Master Station Display (IX-MV7-* and IX-MV only)	-	-	Brightness	361
			Primary Video Source (IX-MV7-* only)	361
			Aspect Ratio (IX-MV7-* only)	361
			Time Format (IX-MV only)	361
			Standby LED State	362
			Keypad (IX-MV7-* only)	362

Setting items				Reference pages	
Camera (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	Adjustment	-	Backlight Compensation	363	
			Low Light Sensitivity	363	
	Color Settings (IX-DA, IX-DF(-*) only)	-	Brightness◆	364	
			Contrast◆	364	
			Color◆	364	
	White LED	-	Call / Communication	364	
Monitored			364		
Door Release Assignment (IX-RS-* only)	-	-	Contact Assignment	365	
			Authentication Key	365	
			Door Release by IX-RS	366	
Line Supervision (IX-MV7-* only)	Line Supervision Interval	-	Test Interval	367	
			Weekly	367	
			Line Supervision Schedule	367	
	Device Check Interval	-	-	Test Interval	368
				Weekly	368
				Device Check Schedule	368
<b>Maintenance</b>					
Firmware Update	-	-	-	369	
Initialization	-	-	-	370	
Settings File Backup	-	-	-	371	
syslog (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	IPv4 Address	373	
			IPv6 Address	373	
			Port◆	373	

## ■ Station View

Setting items				Reference pages	
<b>Station Information</b>					
Identification	-	-	Number◆	375	
			Name	375	
			Location (except for IXW-MA)	375	
ID and Password	-	-	Administrator ID◆◆	376	
			Administrator Password◆◆	376	
			User ID◆◆	376	
			User Password◆◆	376	
			ONVIF ID (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ◆◆	376	
			ONVIF Password (IX-EA(U), IX-DV, IX-DVF(-*), and IX-DA, IX-DF(-*) only) ◆◆	176	
Time	Time Zone	-	Select time zone◆	378	
			Daylight Savings Time	Enable automatic daylight savings time◆	378
			Date and Time	-	378
Expanded System (not used)	-	-	-	380	
<b>Network Settings</b>					
IP Address	-	-	Hostname (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	381	
			Static / DHCP◆	381	
			IPv4 Address	-	IP Address◆
	IPv6 Address	-	-	Subnet Mask◆◆	382
				Default Gateway◆	382
				IP Address◆	382
DNS	Primary Server◆	-	Default Gateway◆	383	
			IPv4	384	
	Secondary Server◆	-	IPv6	384	
			IPv4	384	
			IPv6	384	

Setting items				Reference pages	
SIP (except for IXW-MA)	SIP Connections	-	SIP Signaling Port◆◆	385	
			User Agent (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	385	
	SIP Server (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	Primary Server		ID◆	386
				Password◆	386
				IPv4 Address◆	386
				IPv6 Address◆	386
				Port◆◆	386
		Secondary Server		ID◆	386
				Password◆	386
				IPv4 Address◆	387
				IPv6 Address◆	387
				Port◆◆	387
		Tertiary Server		ID◆	387
				Password◆	387
	IPv4 Address◆			387	
	IPv6 Address◆			387	
	Port◆◆			388	
Miscellaneous	-		Register Transmission Interval [sec] (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ◆◆	388	
			DTMF digit interval timeout [sec] (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ◆◆	388	
			Call health check timer◆◆	388	
Multicast Address (IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	-	-	For Call / Paging (IX-MV7-* and IX-MV only)	389	
			For Call (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	389	
Video (IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	Video Encoder 1	-	Video Codec (IX-DA, IX-DF(-*) only) ◆	390	
			Resolution (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ◆	391	
			Frame Rate [fps] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	391	

Setting items			Reference pages	
			Select Profile [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	391
			I-picture interval [H.264/AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	391
			Bit rate [kbps] [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ♣	391
			Select Quality [Motion-JPEG] (IX-DA, IX-DF(-*) only) ♣	392
			RTP Start Port◆	392
			RTP End Port◆	392
Video Encoder 2	-		Second Video Encoder (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ♣	393
			Video Codec (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ♣	393
			Resolution (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ♣	393
			Frame Rate [fps] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ♣	393
			Select Profile [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	394
			I-picture interval [H.264/AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ◆	394
			Bit rate [kbps] [H.264 / AVC] (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only) ♣	394
			Select Quality [Motion-JPEG] (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ♣	394
			RTP Start Port◆	394
			RTP End Port◆	394
Master Station Video Setting (IX-MV7-* only)	-		Video Streaming	395
			Frame Rate [fps]♣	395
			Select Profile	395
			I-picture interval◆	395
			Bit Rate [kbps]♣	395
Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*)	-	-	-	397

Setting items				Reference pages
Audio (except for IXW-MA)	-	-	Audio Codec♣	398
			Audio RTP Transmission Interval [msec]♣	399
			RTP Idle Detection Time [sec]♣♣	400
			Audio 1 RTP Start Port♦	400
			Audio 1 RTP End Port♦	400
			Audio 2 RTP Start Port♦	400
			Audio 2 RTP End Port♦	400
	Audio Buffer	-	Packets Buffered at Audio Start♣	401
			Maximum Packets Buffered♣	401
	Packet Priority	-	-	TOS Value (Audio) (except for IXW-MA) ♦♣
TOS Value (Video) (IX-MV7-*, IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only) ♦♣				402
TOS Value (SIP) (except for IXW-MA) ♦♣				402
VLAN Setting♣				402
VLAN ID♦♣				403
VLAN Priority♣				403
NTP	Enable NTP♣	-	-	404
	Synchronization Interval [hour]♦♣	-	-	404
	Primary Server	Address♣	IPv4	404
			IPv6	405
		Port♦♣	-	405
	Secondary Server	Address♣	IPv4	405
			IPv6	404
		Port♦ ♣	-	405
<b>System Information</b>				
Location (IX-MV7-* and IX-MV only)	-	-	-	406
Address Book (IX-MV7-* and IX-MV only)	Station List	-	-	406
		VoIP Phone Registration	-	408
	Network Camera List	-	Camera Name♦	409
			Hostname	410
			IP Address (IPv4)	410
			IP Address (IPv6)	410
			ID♦	410
			Password♦	410

Setting items				Reference pages
			PTZ Operation	410
			Audio Monitoring	411
Group (for Master) (IX-MV7-* and IX-MV only)	-	-	-	414
Custom Sound Registry (except for IXW-MA)	-	-	-	416
<b>Call Settings</b>				
Station Information (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), or IX-SS-2G only)	-	-	Call Button Function	418
Called Stations (Master Stations) (IX-MV7-* and IX-MV only)	-	-	Call Destination Settings are unnecessary, Master Station can call any station in Address Book.	
Called Stations (Door/Sub Stations) (except for IX-MV7-*, IX-MV, or IXW-MA)	-	-	Number	420
			Protocol (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))	420
			VoIP Phone Registration	421
Call Origination (except for IXW-MA)	Call Origination Advanced Settings	-	Call Method (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	422
			Ringback Tone (except for IX-MV) ♣	423
			Call Timeout (except for IX-MV - "Call Button") ♦♣	423
			Ringback Tone Count (except for IX-MV - "Call Button") ♣	424
			Call Destination (IX-MV7-* or IX-MV - "Option Input 1 - 4" only)	424
			Standard Mode Settings (except for IX-MV7-* and IX-MV)	424
			Destination by Time Delay Settings (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	424
			Destination Dwell Time[sec] (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♦	425

Setting items				Reference pages
		Schedule Settings (Weekly Schedule) (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	426
			End Time	426
			Call Destination	426
			Priority	426
		Schedule Settings (Daily Schedule) (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	427
			End Time	427
			Call Destination	428
			Priority	428
	Tone Settings	-	Busy Tone (except for IX-MV) ♣	429
			Error Tone (Call Failed) (other than IX-MV7-* or IX-MV) ♣	430
	Call Restart Function	-	Call Restart Function (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	430
	Incoming Call (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	Call Answer Settings	-	Auto Answer♣
Ringtone		-	Ringtone (other than IX-MV7-*, IX-MV) ♣	430
			Ringback Tone Count (other than IX-MV7-*) ♣	433
			Call Button (IX-MV7-* and IX-MV only)	433
			Option Input (IX-MV7-* and IX-MV only)	434
			Call Button Ringtone Count [time(s)] (IX-MV7-* only) ♣	434
			Option Input Ringtone Count [time(s)] (IX-MV7-* only) ♣	434
VoIP Phone (except for IX-MV)		-	VoIP Phone Call Priority	435
<b>Option Input/Relay Output Settings</b>				
Option Input	Option Input Advanced Settings	Name (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	-	436
		Function	-	437
		Type	-	437

Setting items				Reference pages	
		Detection Time Range	Detection Time Range	437	
			Detection Time◆	437	
		API (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	API 1	438	
			API 2	438	
Relay Output	Relay Output Advanced Settings	Name (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	-	440	
		Function	-	440	
		Option Relay Control (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	442	
		Output Time Range	Output Time Range	443	
			Output Time [msec / sec]◆	443	
		Door Release Authorization (except for IXW-MA)	-	443	
		Sound Settings (except for IX-MV and IXW-MA)	Door Release	445	
			Relay Control (start) (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))	445	
			Relay Control (end) (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))	446	
		Schedule Settings (Weekly Schedule) (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	447	
			End Time	447	
		Schedule Settings (Daily Schedule) (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Start Time	449	
			End Time	449	
		Option Relay Control Authentication Key (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	449
		<b>Paging Settings</b>			
Paging Origination (IX-MV7-* and IX-MV only)	-	-	Paging Timeout [sec]◆♣	450	
			Paging Wait Timer [sec] (IX-MV7-* only)◆♣	450	
			Urgent Page Response (IX-MV7-* only)	450	
			Lock Paging (IX-MV7-* only)	451	

Setting items				Reference pages	
All Page (IX-MV7-* and IX-MV only)	-	-	-	452	
Option Input Page (IX-MV7-* only)	-	-	Destination	453	
			Group Number	453	
			Priority	453	
			Message File Name	454	
			Play Count [time(s)]	454	
<b>Function Settings</b>					
Door Release (IX-MV7-* and IX-MV only)	Door Release Assignment	-	Contact Assignment	455	
			Authentication Key	455	
Network Camera Integration (IX-MV7-* and IX-MV only)	Profile Setting	-	Profile	456	
			Event Registration	-	Event
	Function (IX-MV7-* only)	458			
	Event Tone (IX-MV7-* only)	459			
	ID (IX-MV7-* only)	459			
	Password (IX-MV7-* only)	459			
	Call Origination (IX-MV7-* only)	459			
	Call Destination (IX-MV7-* only)	460			
	Priority (IX-MV7-* only)	460			
	Event Tone (IX-MV only) ♣	460			
Play count of Event Tone♣	460				
Paging Settings (except for IX-MV7-*, IX-MV, or IXW-MA)	Paging Pretone Setting	-	Paging Pretone	461	
Bathroom Call (IXW-MA only) (not used)	-	-	-	462	
Email	Server Settings	-	SMTP Server♣	463	
			SMTP Port♣♣	463	
			SMTP Encryption♣	463	
	Authentication Settings	-	-	SMTP Authentication♣	464
				Mode♣	464
				ID♣	464
				Password♣	464
	Email Addresses	-	-	Destination 1♣	465
				Destination 2♣	465
				Destination 3♣	465
Source Address♣				465	

Setting items			Reference pages		
Email Event Trigger	-	Outgoing Normal Call (except for IXW-MA)	466		
		Incoming Normal Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	466		
		Outgoing Priority Call (except for IXW-MA)	467		
		Incoming Priority Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	467		
		Outgoing Urgent Call (except for IXW-MA)	467		
		Incoming Urgent Call (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	467		
		Door Release Activated (IX-MV7-*, IX-MV, or IX-RS-* only)	467		
		Call Failed (except for IXW-MA)	467		
		Latch Reset (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G only)	467		
		Error	468		
		Station Restarted	468		
		SD Card Error (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	468		
		Recording Memory Full (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	468		
		Line Supervision (Passed) (IX-MV7-* only)	468		
		Line Supervision (Failed) (IX-MV7-* only)	468		
		Device Check (Passed) (IX-MV7-* only)	469		
		Device Check (Failed) (IX-MV7-* only)	469		
		Subject	469		
		Periodic Log Transmission	-	Periodic Log Transmission	469
				Periodic Log Transmit Time	469
Periodic Log Transmit Interval	470				
Periodic Log Transmission Subject	470				
Send Test Email	-	-	471		

Setting items			Reference pages	
	Additional Settings (IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) only)	-	Attach Image♣	472
			Image Filename♣	472
CGI Integration	-	-	CGI Functionality	473
SIF Integration	SIF Functionality	-	-	474
	SIP URI Format (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♣	-	-	474
	SIF Settings (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	Program Type♣	475
			IPv4♣	475
			IPv6♣	475
			Destination Port♣	475
			SSL♣	476
			Connection♣	476
	Transmission Trigger (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	Begin Outgoing Call (except for IXW-MA)	477
			Begin Communication (Source) (except for IXW-MA)	477
			Door Release Indication (IX-MV7-* and IX-RS-* only)	477
			End Communication (except for IXW-MA)	477
			Change contact	477
			Unit Error	478
			Begin broadcast (IX-MV7-* only)	478
			End broadcast (IX-MV7-* only)	478
			Begin Transfer (IX-MV7-* only)	478
			End Transfer (IX-MV7-* only)	478
			Periodical Transmission	478
Initialization Notice			478	
End Outgoing Call (except for IXW-MA)			479	
Begin Incoming Call (except for IXW-MA)	479			
End Incoming Call (except for IXW-MA)	479			

Setting items			Reference pages
		Latch Reset (except for IX-MV7-* and IXW-MA)	479
		Change Call Destination (except for IXW-MA)	479
		Call Failure (except for IXW-MA)	479
		Begin Incoming Transfer Call (IX-MV7-* only)	479
		Begin On Hold (IX-MV7-* only)	480
		End On Hold (IX-MV7-* only)	480
		Begin Incoming Page (except for IXW-MA)	480
		End Incoming Page (except for IXW-MA)	480
		Paging Failure (IX-MV7-* only)	480
		Begin Monitoring (IX-MV7-* only)	480
		End Monitoring (IX-MV7-* only)	480
		Monitoring Failure (IX-MV7-* only)	481
		Begin Monitored (except for IX-MV7-* and IXW-MA)	481
		End Monitored (except for IX-MV7-* and IXW-MA)	481
		Begin Communication (Destination) (except for IXW-MA)	481
		Begin Privacy (IX-MV7-* only)	481
		End Privacy (IX-MV7-* only)	481
		Keypad Input (IX-MV7-* only)	481
		Speed Dial Input (IX-MV7-* only)	482
		Begin Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	482
		End Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	482
		Recording Memory Full (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	482

Setting items			Reference pages			
			Passed Line Supervision (IX-MV7-* only)	482		
			Failed Line Supervision (IX-MV7-* only)	482		
			Passed Device Check (IX-MV7-* only)	482		
			Failed Device Check (IX-MV7-* only)	483		
			SD Card Error (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	483		
			SIP Registration Failure (except for IXW-MA)	483		
			Network Camera Event (IX-MV7-* only)	483		
Periodical Transmission (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	Periodical Transmission Interval◆	483			
SIF File Management	-		SIF Communication Settings (sif.ini)	484		
			SIF Parameter Settings (sif_conf.ini)	484		
Record (IX-MV7-*, IX-DV, IX-DVF(-*), IX-SSA(-*) only)	-	-	Record Mode (IX-DV, IX-DVF(-*), IX-SSA(-*) only) ♣	485		
			Record Event	486		
			Recorded Device (IX-MV7-* only)	486		
			Prevent Overwrite♣	486		
			Video Recording File Length♣	486		
			Event Recording Timer (IX-MV7-* only) ♣	487		
			Manual Recording (IX-MV7-* only) ♣	487		
			Audio Recording (IX-MV7-*, IX-DV, IX-DVF(-*) only) ♣	487		
Schedule Settings (IX-DV, IX-DVF(-*), or IX-SSA(-*) only)	Weekly Schedule	Start Time	488			
		End Time	488			
Communication Audio Messages (IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), or IX-SS-2G only)	Start Communication	-	Message	489		
			Code Received	-	Code	490
					Message	490

Setting items				Reference pages		
Chime (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), or IXW-MA)	Weekly Schedule	-	Start Time	491		
			Chime	492		
	Daily Schedule	-	Start Time	494		
			Chime	494		
CSR	-	-	Country	495		
			State/County/Region	495		
			City/Locality	496		
			Organization	496		
			Organizational Unit	496		
			Common Name	496		
SSL Certificate	-	-	-	497		
IEEE 802.1X (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	IEEE 802.1X	498		
			EAP♣	498		
			EAP User Name♣	498		
			EAP Password♣	498		
Display Mode (IX-MV7-* only)	Master UI Mode	-	-	500		
	Standard Mode	-	Home Screen	501		
	Receptionist Mode	Color Scheme	-	-	502	
		Screen Layout	-	-	503	
		Company Information	Name	-	-	505
			Text Size♦	-	-	505
			Bold	-	-	505
			Text Color	-	-	505
		Greeting Information	Greeting	-	-	506
			Text Size♦	-	-	506
	Bold		-	-	506	
	Text Color		-	-	506	

Setting items				Reference pages	
		Images	Company Image	507	
			Greeting Image	507	
			Receptionist Image	507	
		Button Function	Button 1	508	
			Button 2	508	
			Button 3	508	
			Button 4	508	
			Button Name for Group Call	509	
			Button Name for Select By Name	509	
		Group Call Destination	Button Name for Select By List	509	
			Button Name for Enter Number	509	
			Group Call Destination	-	509
Reject Incoming Call	-	509			
Bathroom Link (not used)	-	-	-	510	
<b>Transfer Settings</b>					
Absent Transfer (IX-MV7-* and IX-MV only)	-	-	Absent Transfer	511	
			Transfer Destination List (IX-MV7-* only)	512	
			Transfer Destination (IX-MV only)	512	
			Re-Transfer Destination (IX-MV7-* only)	512	
Delay Transfer (IX-MV7-* and IX-MV only)	-	-	Delay Transfer	513	
			Delay Time [sec]↕	514	
			Transfer Destination List (IX-MV7-* only)	514	
			Transfer Destination (IX-MV only)	514	
			Re-Transfer Destination (IX-MV7-* only)	514	
Schedule Transfer (IX-MV7-* and IX-MV only)	-	-	Schedule Transfer	515	
			Weekly Schedule	Transfer Destination	516
				Re-Transfer Destination (IX-MV7-* only)	516
				Start Time	516
				End Time	516

Setting items				Reference pages	
	Daily Schedule (IX-MV7-* only)	-	Transfer Destination	517	
			Re-Transfer Destination	518	
			Start Time	518	
			End Time	518	
Lock Transfer (IX-MV7-* only)	-	-	Lock	518	
<b>Station Settings</b>					
Speed Dials / Favorites (IX-MV7-* and IX-MV only)	Advanced Speed Dial Button Settings		Speed Dial Name (IX-MV7-* only)	-	520
			Function	-	520
			Individual Call	Number	520
				Priority	520
			Group Call	Group Number	521
				Priority	521
			Group Page	Group Number	521
				Priority	521
			All Page	Priority	521
			Group Message Page (IX-MV7-* only)	Group Number	521
				Message	522
				Priority	522
				Play Count [time(s)]	522
			All Message Page (IX-MV7-* only)	Message	523
				Priority	523
				Play Count [time(s)]	523
			Monitor (IX-MV7-* only)	Number	523
Network Camera Monitor (IX-MV7-* only)	Network Camera	524			
Scan Monitor (IX-MV7-* only)	-	524			
Option Relay Control (IX-MV7-* only)	Open	524			
	Output Time	524			
	TLS	524			
	Option Relay Control Key	525			
Lock (IX-MV7-* only)	-	525			
Privacy (IX-MV7-* and IX-MV only)	-	-	Privacy♣	526	

Setting items			Reference pages	
Volume / Tone (except for IXW-MA)	Volume	-	Handset Transmit (IX-MV7-*, IX-RS-*, or IX-MV only)	527
			Handset Receive (IX-MV7-*, IX-RS-*, or IX-MV only)	527
			Hands-free Transmit (IX-MV7-*, IX-RS-*, or IX-MV only)	527
			Hands-free Receive (IX-MV7-*, IX-RS-*, or IX-MV only)	527
			Headset Jack Transmit (IX-MV7-* only)	527
			Headset Jack Receive (IX-MV7-* only)	528
			Transmit (except for IX-MV7-*, IX-RS-*, or IX-MV)	528
			Receive (except for IX-MV7-*, IX-RS-*, IX-MV, or IX-DV, IX-DVF(-*))	528
			Receive (IX-DV, IX-DVF(-*) only)	528
			External Input (not used)	528
			External Output (IX-RS-* only)	528
			VoIP Phone Volume Adjustment (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	528
			Ringtone	528
			Paging (IX-DV, IX-DVF(-*), and IX-SSA(-*) only)	529
		Button Feedback (IX-MV7-* and IX-MV only)	529	
	Tone	-	Communication Timeout Notification (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♣	529
			Communication End Pretone (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♣	530
			Call Queue Notification (IX-MV7-* only) ♣	530
			Paging Pretone (IX-MV7-* and IX-MV only) ♣	531
			Auto Answer Tone (except for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)) ♣	531
		On Hold (IX-MV7-* only) ♣	532	

Setting items				Reference pages
			Key Received (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♣	532
			Error (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	533
			Mic Select (not used)	533
			Headset Specification (IX-MV7-* only)	533
			Audio Output (for Master) (IX-MV7-* only)	533
			Audio Output (for Door) (except for IX-MV7-*, IX-SS-2G, or IX-MV)	534
Communication (except for IXW-MA)	-	-	Talk Timeout [sec] ♣ ♣	535
			Communication Start Tone (except for IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) ♣	535
			Force Touch-to-Talk (IX-MV7-* and IX-MV only)	535
Monitor (except for IXW-MA, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	Monitor Timeout [sec] (IX-MV7-* and IX-MV only) ♣ ♣	-	-	536
	Scan Monitor (IX-MV7-* only)	-	Type	536
			Number	536
			Network Camera Number	537
			Dwell Time	537
	Prevent Being Monitored (except for IX-MV7-* and IX-MV)	-	-	537
	Monitored Notification Tone (other than IX-MV7-* or IX-MV) ♣	-	-	537
Monitored LED Notification (except for IX-MV7-* and IX-MV)	-	-	538	


Setting items				Reference pages
Master Station Display (IX-MV7-* and IX-MV only)	-	-	Brightness	539
			Primary Video Source (IX-MV7-* only)	539
			Aspect Ratio	539
			Time Format (IX-MV only) ♣	539
			Standby LED State♣	539
			Keypad (IX-MV7-* only)	540
Camera (IX-DV, IX-DVF(-*), or IX-DA, IX-DF(-*) only)	Adjustment	-	Backlight Compensation♣	541
			Low Light Sensitivity♣	541
	Color Settings (IX-DA, IX-DF(-*) only)	-	Brightness♦	541
			Contrast♦	541
			Color♦	542
	White LED	-	Call / Communication♣	542
Monitored♣			542	
Door Release Assignment (IX-RS-* only)	-	-	Contact Assignment	543
			Authentication Key	543
		Door Release by IX-RS	-	544
Line Supervision (IX-MV7-* only)	-	-	Line Supervision Interval	545
			Line Supervision Schedule	545
			Device Check Interval	545
			Device Check Schedule	545
<b>Maintenance</b>				
Firmware Update	-	-	-	546
Initialization	-	-	-	547
Settings File Backup	Setting File Download	-	-	548
	Setting File Upload	-	-	550
syslog (except for IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*))	-	-	IPv4 Address	552
			IPv6 Address	552
			Port♦	552

# Menu bar

## Important

- Depending on the language for the display on the station (IX-MV7-\* or IX-MV), the content of the settings may appear incorrectly.
- The symbols indicate the following:
  - ◆: Be sure to input the settings. Upon use, leave the unnecessary items at their default values.

# 1. File




## 1.1 Create new system/import setting data

Creates new system setting data.

The below three methods can be used to create a new system depending on your objective.

- Perform detailed setup for all functions. → [“Create new system settings data \(without using the Wizard function\) \(→page 124\)”](#)
- Set call/door release/paging/monitoring functions only. → [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#)
- Import setting data from another IX Support Tool or setting data created before Ver4.0.0.0. [“Reading in data created by another IX Support Tool \(→page 139\)”](#)

Select "File" > "Create New System" to display the "New System" screen.



[“Restore System Settings \(→page 164\)”](#)

[“Reading in data created by another IX Support Tool \(→page 139\)”](#)

### 1.1.1 Create new system settings data (without using the Wizard function)

1. Configure the system settings.

#### ■ System Name◆

Description	Enter the name of the system to be created.
Settings	1 - 64 alphanumeric characters
Default values	–

#### ■ IP Version

Description	Choose the protocol for IX Support Tool.
Settings	<ul style="list-style-type: none"> <li>• IPv4</li> <li>• IPv6</li> </ul>
Default values	IPv4

#### ■ Installer Information◆

Description	Enter the installer information. The set installer information is displayed in station information/notes in IX-MV7-* - "Station Information" - "CONTACT INFORMATION."
Settings	4 rows (1-64 alphanumeric characters per row)
Default values	–

#### ■ Owner Information◆

Description	Enter the owner information.
Settings	1-64 alphanumeric characters
Default values	–

#### ■ Notes◆

Description	Enter the notes.
Settings	1-64 alphanumeric characters
Default values	–

2. Enter the number of stations in the "IX Support Tool Settings."
3. Select "Wizard Programming" > "No."  
If using the Wizard function, refer to ["Use the Wizard function to easily set up the system and make it operational \(→page 125\)"](#).
4. Select "Automatically configure door release for all stations?."
  - When Door Release Settings do not exist or when Door Release Settings for each door will be configured individually, set to "No."
5. Click **[Apply]**.
  - Setting data will be automatically generated and the Settings (Table View) screen will be displayed. Refer to ["System Settings \(Table View\) \(→page 169\)"](#) when performing the settings.
  - Click **[Cancel]** to terminate the process without creating a new system.

---

---

## 1.1.2 Use the Wizard function to easily set up the system and make it operational

---

---

Before configuring, connect the programming PC and all stations to the same network.

The Wizard allows setup for the call, door release, paging, and monitoring functions. If using other functions, refer to [“System Settings \(Table View\) \(→page 169\)”](#).

- 1.** Configure the system settings.  
For entries, refer to Step 1 of [“Create new system settings data \(without using the Wizard function\) \(→page 124\)”](#).
- 2.** Enter the number of stations in the "IX Support Tool Settings."
- 3.** Select "Wizard Programing" > "Yes."
- 4.** Select "Automatically configure door release for all stations?."
  - When Door Release Settings do not exist or when Door Release Settings for each door will be configured individually, set to "No."
- 5.** Click **[Next]**.  
Auto-generation of the setting data and a station search will be performed and the "System Configuration" screen will be displayed. (The search may take several minutes.)
  - The stations without power and the stations in the process of initialization will not be subject to search.
  - Search up to 9999 stations at a time.
  - Click **[Station Search]** to search again.
  - You cannot search for terminals using a different IP version. Select the IP version of the terminal to search in "Station Search Protocol." (Set the PC to same communication type.)
  - You cannot search for stations on other segments. Refer to Step 9.
  - The following setting items will be set automatically.
    - IP Address
    - Subnet Mask

**System Configuration**

1. Select the setting file to be linked with the chosen station:

Select	Number	Name	Location	Station Type	Hostname	IP Address	Associated
<input checked="" type="radio"/>	0001	Master Stations1		IX-MV7-*		192.168.1.10	-
<input type="radio"/>	0002	Master Stations2		IX-MV7-*		192.168.1.11	-
<input type="radio"/>	0003	Master Stations3		IX-MV7-*		192.168.1.12	-
<input type="radio"/>	0004	Master Stations4		IX-MV7-*		192.168.1.13	-
<input type="radio"/>	0005	Master Stations5		IX-MV7-*		192.168.1.14	-
<input type="radio"/>	0006	Master Stations6		IX-MV		192.168.1.15	-
<input type="radio"/>	0007	Master Stations7		IX-MV		192.168.1.16	-
<input type="radio"/>	0008	Master Stations8		IX-MV		192.168.1.17	-
<input type="radio"/>	0009	Master Stations9		IX-MV		192.168.1.18	-

2. Select the station to associate with the setting file.

Enter station MAC address:   Different Networks

Search and select station within local network

Station Search Protocol: IPv4

Select	Number	Name	Location	Station Type	MAC address	Associated
<input checked="" type="radio"/>	00001	Master Stations4		IX-MV7-*	00:0B:AA:2F:00:0F	-
<input type="radio"/>	0004	Video Door Stations1		IX-DV, IX-DVF(-*)	00:0B:AA:27:00:5E	-
<input type="radio"/>	0007	Handset Sub Station1		IX-RS-*	00:0B:AA:00:F8:51	-

3. Station(s) that have been associated with a setting file are listed below.

Select	Number	Name	Location	Station Type	IP Address	MAC address	Status

Buttons: Apply, Associate Automatically, Station Search, Remove Association, Retry Association, Back, Next, Cancel.

**Station Setting List**  
A list of the generated setting files will be shown.

**System Management**  
This allows for the addition or deletion of stations on the Station Settings List.

**Station Search Protocol**  
Select the IP version of the station to search.

**Advanced Settings**

**Station List**  
The searched stations will be shown.

Search again for stations.

Setting files and stations are automatically associated.

**Associated Station List**  
The settings that have been associated will be shown.

Perform association again.

**6. Edit "Station Settings List."**

Edit if stations are added or deleted.

["How to edit the Station Settings List \(→page 129\)"](#)

**7. Set "Advanced Settings."**

Set these when you need to change the station name, IP address, and so on.

["How to configure Advanced Settings \(→page 130\)"](#)

**8. Associate setting files and stations.**

Select the setting file to associate from "Station Settings List."

- A setting file that has already been associated cannot be selected.
- Click **[Associate Automatically]** to automatically associate all setting files with stations.

9. Select the station with which the setting file selected at Step 8 will be associated from "Station List."
- A station that has already been associated cannot be selected.
  - Select "Enter station MAC address" to specify a station by entering the MAC address.
  - To associate a station on another segment, select "Enter station MAC address" then "Different Networks," and then enter the MAC address to specify the station.
10. Click **[Apply]**.
- The settings that have been associated will be shown in "Associated Stations List."
  - The station will be restarted and the IP Address and Name will be updated. If a station on another segment was associated in Step 9, it will not be updated. Update the IP Address and Name using a Web browser.

### ! Important

- If "[Static / DHCP \(→page 181\)](#)" was set to "DHCP," "Stateless," or "DHCPv6" at Step 5, the IP address set beforehand by the DHCP server will be assigned. If the IP address assignment fails, the IP address will default to "192.168.1.160" if it is IPv4 and "FDC2::7000" if it is IPv6. If this happens, cycle power to the station to, and then the IP Address will be reassigned by the DHCP server. Afterwards, perform association again.

11. Repeat steps 8 - 10 and associate all stations.
- To dissociate, select the content to remove from "Associated Stations List" (multiple selections allowed), and then click **[Remove Association]**.
12. Click **[Next]**.
- The "Setting File Upload" screen is displayed.
- Click **[Cancel]** to terminate the process without creating a new system.

13

IX Support Tool - [IX Support Tool Wizard: Step 3]

### Setting File Upload

Select the station(s) to upload the Setting File(s): Connection Status 3/3

Select	Number	Name	Location	Station Type	IP Address	Status
<input type="checkbox"/>	0001	Master Stations1		IX-MV7-*	192.168.1.10	Available
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*		-
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*		-
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*		-
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*		-
<input type="checkbox"/>	0006	Video Stations1		IX-DV, IX-DVF(-*)		-

Select Station by Type: All Select Unselect

This PC's IP Address: 192.168.1.178

Manual Date / Time Setup Start Upload Next Finish


14 15 18

13. Select the station from which to upload the setting file from "Station List." (Multiple selections allowed)
- To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations for which there are no Association Settings cannot be selected.
14. Set the date and time.
- Enter the time for each station. Time is used for incoming calls, outgoing calls, and the system log. ["How to configure the date and time manually \(→page 139\)"](#)

**15.** Click **[Start Upload]**.

**16.** Click **[OK]**.

- Click **[Cancel]** to return to the "Setting File Upload" screen without uploading.




**17.** Click **[OK]**.

- The result is displayed in "Station List" > "Status."
  - In Process: The setting file is in the process of uploading.
  - Success: Upload is completed.
  - Failed: Upload failed.

**18.** Click **[Next]**.

The "Export Settings" screen is displayed.

- Click **[Cancel]** to terminate the process without creating a new system.



**19.** Output the system configuration file that was set.

Click **[Export]**.

**20.** Specify the save directory and click **[OK]**.


- A folder with the name specified in "System Name" in Step 1 will be created in the specified directory, and the system configuration file will be saved inside.

**21.** Click **[Apply]**.

- The Wizard function is complete.


### 1.1.2.1 How to edit the Station Settings List

This is an explanation for Step 6 of [“Use the Wizard function to easily set up the system and make it operational \(→page 125\)”](#).



#### How to add a station


On the "System Configuration" screen, click **[Add New Station]** to display the "Add New Station" screen.




1. Enter the station type and the number of the stations to be added.
2. Click **[Add]**.
3. Click **[OK]**.
  - Click **[Cancel]** to end the process for adding a new station.

**How to remove a station**

On the "System Configuration" screen, click **[Station Removal]** to display the "Station Removal" screen.




1. Select the station to delete from "Station List." (Multiple selections allowed)
2. Click **[Delete]**.
  - Click **[Cancel]** to cancel deletion.
3. Click **[Yes]**.
  - Click **[No]** to return to the "Station Removal" screen.



**1.1.2.2 How to configure Advanced Settings**

This is an explanation for Step 7 of ["Use the Wizard function to easily set up the system and make it operational \(→page 125\)"](#).



**How to register a new address book (IX-MV7-\* and IX-MV only)**

Default value: All stations to be registered to Address Book

Click **[Address Book]** to display the "Address Book" screen.

**Move row**  
Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click [Display] to move the cursor to the entered row.

List of IX-MV7-\* and IX-MV in setting data

**Move column**  
Up to 50 station number lines can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 columns.  
**[Next]:** Display the next 50 columns.  
**[Display]:** Enter the station number and click [Display] to move the cursor to the entered column.

List of stations that can be registered to Address Book

1. Search for the stations for which the Address Book will be set up from the "list of IX-MV7-\* and IX-MV in setting data."
2. Search for stations to be registered from "List of stations that can be registered to Address Book."
3. Click **[Select]** in the cell that corresponds to Steps 1 and 2.
  - Register
    - ✓: Register the selected station to the Address Book.
    - SIP: Register the station with which to communicate over a SIP server.
  - By default, "✓ (register)" is set for all stations.
4. After configuration is complete, click **[OK]**.
  - Click **[Cancel]** to complete Address Book registration.

### How to configure Station Details

Click **[Station Details]** to display the "Station Details" screen.

**Move row**


Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.



["How to register a location \(→page 135\)"](#)

1. Change setting of each item.
2. After configuration is complete, click **[OK]**.
  - Click **[Cancel]** to stop configuring station details.

**■ Number◆**

Description	Set Number. Set it such that there is no overlap with other stations. The set station number will be shown to the recipient when a call is made or when the station is paged. It is also used to search a station by station number for IX-MV7-* and IX-MV.
Settings	3-5 digits
Default values	Set in order starting from 0001.
Remarks	When configuration is complete, the stations are sorted by station number.

## ■ Name

Description	Enter the station name. The set station name will be shown to the recipient when a call is originated.
Settings	1-24 alphanumeric characters
Default values	IX-MV7-*, IX-MV: Master Station (number); IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*): Video Door Station (number); IX-SSA(-*), IX-SS-2G, IX-BA, IX-SS(-*): Audio Door Station (number); IX-RS-*: Handset Sub Station (number); IXW-MA: I/O Adaptor (number)
Remarks	When updated with no entry, the station numbers are automatically copied in this field.

## ■ Location (except for IXW-MA)

Description	Select the station's Location. The set Location will be shown to the recipient when a call is originated.
Settings	Select one from the Location registered in " <a href="#">How to register a location (→page 135)</a> ".
Default values	–

## ■ Hostname (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Set the station's hostname. Set this to access a station by hostname that was registered in " <a href="#">How to register a new address book (IX-MV7-* and IX-MV only) (→page 131)</a> ", " <a href="#">Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 225)</a> ". When setting the hostname, configure " <a href="#">DNS (→page 185)</a> ".
Settings	1-64 alphanumeric characters
Default values	–

## ■ IP Version

Description	Select the station's communication type.
Settings	<ul style="list-style-type: none"> <li>• IPv4</li> <li>• IPv6</li> </ul>
Default values	IPv4

## ! Important

- IPv4 and IPv6 cannot be mixed in the same system.

## ■ Static / DHCP

Description	Select the addressing method for the IP version selected in "IP Version."
Settings	When selecting IPv4: <ul style="list-style-type: none"> <li>• Static</li> <li>• DHCP</li> </ul> When selecting IPv6: <ul style="list-style-type: none"> <li>• Static</li> <li>• Stateless</li> <li>• DHCPv6</li> </ul>
Default values	IPv4 <ul style="list-style-type: none"> <li>• Static</li> </ul>

**! Important**

- If "DHCP" is selected for IPv4, configure so that a static IP address is assigned to the stations by the DHCP server.
- If "Stateless" is selected for IPv6, do not change the prefix of the device that can transmit Router Advertisement (RA).
- If "DHCPv6" is selected for IPv6, configure so that a static IP address is assigned to the stations by the DHCP server. DUID of the station is "00030001 + the MAC address."
- When setting up a product from another manufacturer, such as a DHCP server, refer to its manual.
- If "Static / DHCP" is set to "DHCP," settings will not be applied to the station even if the "IP Address," "Subnet Mask," and "Default Gateway" are set.

**■ IP Address (IPv4)◆**

Description	Set the IP address of the station. Set a unique IP address for each station.
Settings	1.0.0.1 - 223.255.255.254
Default values	A series of numbers proceeding in the manner of 192.168.1.10, 192.168.1.11... is set.

**■ Subnet Mask (IPv4) ◆**

Description	Set the subnet mask for the station.
Settings	128.0.0.0 - 255.255.255.255
Default values	255.255.255.0

**■ Default Gateway (IPv4)**

Description	Set the default gateway of the network to which the station belongs.
Settings	1.0.0.1 - 223.255.255.254
Default values	—

**! Important**

- If "Static / DHCP" is set to "Stateless" or "DHCPv6," settings will not be applied to the station even if "IP Address" and "Default Gateway" are set.

**■ IP Address (IPv6)◆**

Description	Set the IP address of the station. Set a unique IP address for each station.
Settings	2000::0 - 3FFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or FD00::0 - FDFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	—

**■ Default Gateway (IPv6)**

Description	Set the default gateway of the network to which the station belongs.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	—

## How to register a location

Click **[Location Registry]** to display the "Location Registry" screen.

Up to 100 locations can be registered. However, only locations set between 001 and 050 can be used with IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*).

#	Location Name	
001		1
002		
003		
004		
005		
006		
007		
008		
009		

1. Enter the location in "Location List." For IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*), enter locations within the 001 - 050 range.
  - Location: 1-24 alphanumeric characters
2. Click **[OK]**.
  - Click **[Cancel]** to end the process without registration.

### How to configure door release

Configure the door release authentication key.

To release the electrical lock connected with a destination station after performing a door release operation during communication or monitoring, it is necessary to authenticate the destination station's authentication key and door release key.

Click **[Door Release]** to display the "Door Release" screen.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

List of IX-MV7-\* and IX-MV in setting data

**Move column**

Up to 50 station number lines can be displayed at a time. Switch the display as follows.


**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered column.

Destination station and authentication key



1. Set "Authentication Key."
2. Click **[OK]**.
  - Click **[Cancel]** to stop configuring electrical lock door release.

## ■ Authentication Key

Description	Set the door release key for releasing the door connected to the destination station when a door release operation is performed. Door release is possible when it matches the Door Release Authorization of the destination station.
Settings	<ul style="list-style-type: none"> <li>• IX-MV7-*: 1-20 digits</li> <li>• IX-MV: 1-4 digits</li> </ul> If it matches the destination station's Door Release Authorization, "✓" will be displayed for "Match Result."
Default values	Configured with the same characters as the Door Release Authorization.

### Note

- The initial values for the Door Release Authorization and Authentication Key vary depending on the station type set in "File" > "Create New System" > "IX Support Tool Settings."
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) not configured: 20 digits
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) configured: 4 digits
- If the destination station's Door Release Authorization is four characters or longer, the Authentication Key for IX-MV will release the door if the first four digits match.
- If "[Contact Assignment \(→page 259\)](#)" is "Originating Station," "Authentication Key" will be "-" and "Match Result" will be "x."

### How to perform Batch IP Address Configuration

Click [**Batch IP Address Configuration**] to display the "Batch IP Address Configuration" screen.

1 Enter starting IP address (IPv4 or IPv6) and subnet mask

2 IPv4 Address [ ] . [ ] . [ ] . [ ] IPv6 Address [ ]

Subnet Mask [ ] . [ ] . [ ] . [ ]

Select stations for batch IP address assignment:

Station List						
Select	Number	Name	Location	Station Type	IP Address (IPv4)	IP Address (IPv6)
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	192 168 1 10	
<input type="checkbox"/>	0002	Video Stations1		IX-DV, IX-DVF(	192 168 1 11	
<input type="checkbox"/>	0003	Handset Sub Stator		IX-RS-*	192 168 1 12	


3

Select Station by Type: All [v] [Select] [Unselect]

4 [OK] [Cancel]

1. In "IPv4 Address" or "IPv6 Address," enter the start IP address that is to be automatically assigned.
2. For IPv4, enter "Subnet Mask."
  - With the subnet mask, set the range for assignment. The network addresses in the range and the broadcast addresses cannot be assigned.

3. Select the station to automatically assign an IP address from "Station List." (Multiple selections allowed)
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
4. Click **[OK]**.
  - Click **[Cancel]** to end the automatic assignment.
5. Click **[OK]**. The IP Addresses will be automatically assigned, and the subnet mask will be entered.
  - Click **[Cancel]** to return to the "Batch IP Address Configuration" window.



### 1.1.2.3 How to configure the date and time manually

This is an explanation for Step 14 of ["Use the Wizard function to easily set up the system and make it operational \(→page 125\)"](#).

On the "Setting File Upload" screen, click **[Manual Date / Time Setup]** to display the "Manual Date / Time Setup" screen.

1. Enter (select) "Year," "Month," "Day," "Hour," "Minute," and "Second."
  - Click **[Sync with PC]** to synchronize the time with the PC.
2. Click **[Apply]**.
3. Click **[OK]**.
4. Click **[Back]** to return to the "Setting File Upload" screen.

---

### 1.1.3 Reading in data created by another IX Support Tool

---


On the "New System" screen, click **[Import System Configuration]** to display the "Import System Configuration" screen.

- 1.** Click **[Browse]**.
  - If the other IX Support Tool is older than Ver. 4.0.0.0, place a check next to "Import system configuration from older IX Support Tool (Ver. 4.0.0.0)."
- 2.** Select the folder where the setting file is saved and click **[OK]**.
- 3.** Click **[Next]**.

## 1.2 Select Existing System

View or edit existing system setting data.

Click "File" > "Select Existing System." The "System Selection" screen will be shown.




1. Select the system name of the setting data to be edited.
2. Click **[OK]**.
  - In the Setting window, the selected setting data will be shown.
  - Click **[Cancel]** to terminate the process without selecting a system.

## 1.3 Delete Existing System


Delete created setting data.

Select "File" > "Delete Existing System" to display the "Delete System" screen.



1. Select the system name of the setting data to be deleted.
2. Click **[OK]**.
  - Delete the selected setting data.
  - Click **[Cancel]** to terminate the process without deleting a system.

3. Click **[OK]**.
  - Click **[Cancel]** to return to the "Delete System" screen.




## 1.4 Update Settings

The edited setting data overwrites the existing one. This feature is identical to **[Update]** at the top right in the Settings screen.

Select "File" > "Update Settings."

1. Click **[OK]**.
  - The edited setting data overwrites the existing one.
  - Click **[Cancel]** to quit without overwriting setting data.



2. Click **[OK]**.

## 1.5 Download Settings From Station

Obtain (download) settings from a station.

If ["Association Settings \(→page 160\)"](#) is not performed in advance, downloading is not possible.

### ! Important

- When first configuring through a Web browser or after performing configuration using the IX Support Tool, when "Identification" ["Number♦ \(→page 170\)"](#), "ID and Password" ["ID♦ \(→page 156\)"](#) and ["Password♦ \(→page 157\)"](#), "IPv4 Address" ["IP Address♦ \(→page 182\)"](#), "IPv6 Address" ["IP Address♦ \(→page 183\)"](#), "Address Book" ["Station List \(→page 209\)"](#), or "Call Settings" ["Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)"](#) is changed through a Web browser, the setting file cannot be obtained. In this case, obtain the setting file through a browser.

Click "File" > "Download Settings From Station." The "Setting File Download" screen will be shown.

Select the station(s) to download the Setting File(s):

Select	Number	Name	Location	Station Type	Status
<input checked="" type="checkbox"/>	0001	Master Stations 1		IX-MV7-*	-
<input type="checkbox"/>	0002	Master Stations 2		IX-MV7-*	-
<input type="checkbox"/>	0003	Master Stations 3		IX-MV7-*	-
<input type="checkbox"/>	0004	Master Stations 4		IX-MV7-*	-
<input type="checkbox"/>	0005	Master Stations 5		IX-MV7-*	-
<input type="checkbox"/>	0006	Master Stations 6		IX-MV	-
<input type="checkbox"/>	0007	Master Stations 7		IX-MV	-
<input type="checkbox"/>	0008	Master Stations 8		IX-MV	-

Select Station by Type:  
 All


Select the file to download:

### How to download settings

1. Select the station from which to download the setting file from "Station List." (Multiple selections allowed)
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations for which ["Association Settings \(→page 160\)"](#) has not been performed cannot be selected.
2. Download the file.
  - [Settings]**: Download only the setting file.
  - [Sounds]**: Download the setting file and audio file for a custom tone.
  - [Image]** (IX-MV7-\* only): Download the setting file and image file for the image on the reception screen.
  - [Schedule]** (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), or IXW-MA): Download schedule setting files (for transfer, etc.). Schedules for IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) are downloaded from **[Settings]**.

**3.** Click **[OK]**.

- Click **[Cancel]** to return to the "Setting File Download" screen without downloading.

**4.** Click **[OK]**.

- The file download result is displayed in "Station List" - "Status."
  - In Process: The file is in the process of downloading.
  - Success: Download is completed.
  - Failed: Download failed.
  - Unavailable: This is displayed when a file that cannot be uploaded to a station is selected to download in Step 2.
- Downloaded files are saved as follows in "AIPOHONE\_IX\_SupportTool" - "SystemData" within the folder specified during installation.
  - Setting file: "NewIXSystem(Set System Name).db"
  - Sound file: Saved as a WAV file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Image file: Saved as a PNG file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Schedule file: Saved inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)" as "SCHED\_CHIME.txt," "SCHED\_GROUP.txt," "SCHED\_OUTPUT.txt," "SCHED\_TRANSFER.txt," or "SCHED\_REC.txt" (the saved content differs depending on the station).

## 1.6 Upload Settings To Station

Upload settings created using IX Support Tool onto the station.

If ["Association Settings \(→page 160\)"](#) is not performed in advance, uploading is not possible.

Click "File" > "Upload Settings To Station." The "Setting File Upload" screen will be shown.

### Important

If a custom sound/image was added, be sure to upload each file by selecting "Sounds" / "Image" when uploading. The following will occur if only the setting file is uploaded.

- The default tone will play when the operation in which the custom tone was set is performed.
- The image will not be displayed in receptionist mode.
- "Download Settings From Station" will fail.
- "Upload Settings To Station" will fail.

### Setting File Upload

Select the station(s) to upload the Setting File(s):

Station List						Text in red are required settings.
Select	Number	Name	Location	Station Type	Status	
1 <input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	<div style="border: 1px solid gray; height: 100px; width: 100%;"></div>
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-	

Select Station by Type:

All

▼

Select

Unselect

Select file type to be uploaded

Settings

Sounds

Image

Schedule

## How to upload settings


1. Select the station from which to upload the setting file from "Station List." (Multiple selections allowed)
  - To select or unselect stations in a batch, choose the type and click **[Select]** or **[Unselect]**.
  - Stations for which "[Association Settings \(→page 160\)](#)" has not been performed cannot be selected.
2. Upload the file.
 

**[Settings]**: Upload only the setting file.

**[Sounds]**: Upload the setting file and audio file for a custom tone.

**[Image]** (IX-MV7-\* only): Upload the setting file and image file for the image on the reception screen.


**[Schedule]** (except for IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), or IXW-MA): Select and upload the schedule setting file (transfer, etc.). Refer to "[How to upload schedules \(→page 147\)](#)". Schedules for IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*) are uploaded from **[Settings]**.
3. If **[Settings]**, **[Sounds]**, or **[Image]** was clicked in Step 2, click **[OK]**.
  - Click **[Cancel]** to return to the "Setting File Upload" screen without uploading.




4. Click **[OK]**.
  - The file upload result is displayed in "Station List" - "Status."
    - In Process: The file is in the process of uploading.
    - Success: Upload is completed.
    - Failed: Upload failed.
    - Unavailable: This is displayed when a file that cannot be uploaded was selected in Step 2.

### How to upload schedules

In Step 2 of “[How to upload settings \(→page 146\)](#)”, if **[Schedule]** is clicked, the following screen is displayed.



1. Select the station from which to upload the schedule file, from the station list. (Multiple selections allowed)
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
2. Select the type of schedule file to upload. (Multiple selections allowed)
  - The schedule files that can be selected vary by station.
3. Click **[Start Upload]**.
4. Click **[OK]**.
  - Click **[Cancel]** to return to the "Upload Schedules" screen without uploading.



## 1.7 Upload SSL certificate

Apply the SSL certificate or IEEE802.1X certificate data to the station.

If "[Association Settings \(→page 160\)](#)" is not performed in advance, uploading is not possible. Select "File" > "Upload SSL Certificate" to display the "Certification Update/Delete" screen.

Chose a security certification to be uploaded.

1

SSL Certificate  
Upload certificate set for each device.

IEEE802.1X Certificate  
Select Certificate Authority File  
Browse

Select Client Certificate File  
Browse

Select Client Private Key File  
Browse

Select the station(s) to upload the Setting File(s):

Select	Number	Name	Location	Station Type	Status
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-

Select Station by Type:  
All Select Unselect


3

Delete Upload

1. Select the type of certificate to be uploaded.
  - If "SSL Certificate" is selected, configure the file to upload in "[SSL Certificate \(→page 309\)](#)".
  - If "IEEE802.1X Certificate" is selected, select the file to be uploaded and click **[Open]**.
2. Select the station for which to upload the file from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
3. Click **[Upload]**.
  - Click **[Delete]** to delete the uploaded file.
4. Click **[OK]**.
  - Click **[Cancel]** to return to the "Certification Update/Delete" screen without uploading.
  - The file upload result is displayed in "Station List" - "Status."
    - In Process: The file is in the process of uploading.
    - Success: Upload is completed.
    - Failed: Upload failed.
    - Unavailable: This is displayed when a file that cannot be uploaded was selected in Step 1.

## 1.8 Import Setting File

A setting file can be modified using a text editor and imported into IX Support Tool. Click "File" > "Import Setting File." The "Import Setting File" screen will be shown.



**Import Setting File**

Select File to Import:

1

Select target station to be applied:


Select	Number	Name	Location	Station Type	Status
<input checked="" type="radio"/>	0001	Master Stations1		IX-MV7-*	-
<input type="radio"/>	0002	Master Stations2		IX-MV7-*	-
<input type="radio"/>	0003	Master Stations3		IX-MV7-*	-
<input type="radio"/>	0004	Master Stations4		IX-MV7-*	-
<input type="radio"/>	0005	Master Stations5		IX-MV7-*	-
<input type="radio"/>	0006	Master Stations6		IX-MV	-
<input type="radio"/>	0007	Master Stations7		IX-MV	-

Text in red are required settings.

3

### How to import a setting file


1. Click **[Browse...]**, select the setting file data (txt file), and then click **[Open]**.
  - Setting file data is the txt file output via ["Exporting the IX Support Tool System Configuration \(→page 150\)"](#) (file name: config-station number-output date and time.txt)
2. Select the station from which to upload the setting file from "Station List."
3. Click **[Apply]**.
4. Click **[OK]**.
  - Click **[Cancel]** to return to the "Import Setting File" screen without importing.
  - If the file to be imported is mismatched with the original file, the file will not be imported.
  - The file should be uploaded or downloaded before importing.
  - The result is displayed in "Station List" > "Status."
    - In Process: The Setting File is in the process of importing.
    - Success: Import is completed.
    - Failed: Import failed. Try importing again.



## 1.9 Exporting the IX Support Tool System Configuration

Backup setting files created in IX Support Tool.

If the settings are lost, it may be impossible to restore them after maintenance or after-sales servicing. Select "File" > "IX Support Tool Export System Configuration" to display the "Export Settings" screen.



1. Click **[Export]**.
2. Select the folder where the setting file is saved and click **[OK]**.
  - A folder with the name specified in "System Name" will be created in the specified directory, and the system configuration file will be saved inside as a hidden file.  
Copy each "System Name" and store the setting data.
  - Click **[Cancel]** to return to the "Export Settings" screen without saving the setting file.
3. Click **[Finish]**.

## 1.10 Export To Line Supervision Software

To use registered station information with the IX Supervision Tool, output the file in Address Book format. Click "File" > "Export To Line Supervision Software." The following screen will be shown.

The screenshot shows a dialog box titled "Export to Line Supervision Software". Inside the dialog, there is a text prompt: "Browse" to select export folder. Below this prompt is a text input field and a "Browse" button. The "Browse" button is highlighted with a red box and labeled with the number "1". At the bottom right of the dialog, there is an "Export" button, also highlighted with a red box and labeled with the number "2".


1. Click **[Browse]** and select the folder where the setting file will be saved.
2. Click **[Export]**.
3. Click **[OK]**.
  - The setting file will be saved as "SettingAddressList.txt."
  - Information for stations without configured IP addresses will not be output.

## 1.11 Exit

Select "File" > "Exit" to close the IX Support Tool.

# 2. Edit


You can switch between "Table View" and "Station View" or create shortcuts to settings in "Table View" and can edit setting data.




## 2.1 Table View

All stations in the system can be configured using the table. On the "Station View" window, selecting "Edit" > "Table View" will display the "Table View" window.

"Station View" window



"Table View" window




For each item in "Table View," refer to ["System Settings \(Table View\) \(→page 169\)"](#).


## 2.2 Station View

Configure each station in the system individually. On the "Table View" window, selecting "Edit" > "Station View" will display the "Station View" window.

"Table View" window



"Station View" window



For each item in Station View, refer to ["System Settings \(Station View\) \(→page 374\)"](#).

## 2.3 Master Station Address Book

Click "Edit" > "Master Station Address Book." The following screen will be shown.

#	Station Information				Address Book			
	Identification				0001		0002	
	Number	Name	Location	Station Type	Select	Network Camera	Select	Network Camera
0001	0001	Master Stations1		IX-MV7-*			✓	
0002	0002	Master Stations2		IX-MV7-*	✓			
0003	0003	Master Stations3		IX-MV7-*	✓		✓	
0004	0004	Master Stations4		IX-MV7-*	✓		✓	
0005	0005	Master Stations5		IX-MV7-*	✓		✓	
0006	0006	Master Stations6		IX-MV	✓		✓	
0007	0007	Master Stations7		IX-MV	✓		✓	

For "Master Station Address Book," refer to ["Station List \(→page 209\)"](#).

## 2.4 Creating VoIP Phone Address Books

Click "Edit" - "VoIP Phone List." The following screen will be shown.

#	Number	Name	Location
0001			
0002			
0003			
0004			
0005			
0006			
0007			
0008			
0009			
0010			
0011			
0012			
0013			

For "VoIP Phone List," refer to ["VoIP Phone Registration \(→page 227\)"](#).

## 2.5 Register Network Camera


Click "Edit" > "Register Network Camera." The following screen will be shown.

For "Register Network Camera," refer to ["Open Network Camera List \(→page 212\)"](#).

#	Station Information				Available Network Camera(s)		
	Identification				001		
	Number	Name	Location	Station Type	Select	PTZ Operation	Audio Monitoring
0001	0001	Master Stations 1		IX-MV7-*		Enable	Enable
0002	0002	Master Stations2		IX-MV7-*		Enable	Enable
0003	0003	Master Stations3		IX-MV7-*		Enable	Enable
0004	0004	Master Stations4		IX-MV7-*		Enable	Enable

## 2.6 Network Camera Integration


Click "Edit" - "Network Camera Integration." The following screen will be shown.



For "Network Camera Integration," refer to ["Network Camera Integration \(for IX-MV7-\\* and IX-MV\) \(→page 261\)"](#).

## 2.7 Master Station Group Settings

Click "Edit" > "Master Station Group Settings." The following screen will be shown.



For "Master Station Group Settings," refer to ["Group \(for Master\) \(for IX-MV7-\\* and IX-MV\) \(→page 217\)"](#).

## 2.8 Door Station Group Settings

Click "Edit" > "Door Station Group Setting." The following screen will be shown.

#	Station Information				Total	Call Settings		
	Identification					Called Stations (Door/Sub Stations)		
	Number	Name	Location	Station Type		Group 01		
Number / Name / Station Type						0001 / Master Stations 1 / IX-MV7-*		0002 /
0011	0011	Video Stations1		IX-DV, IX-DVF(-	10	U	U	
0012	0012	Video Stations2		IX-DV, IX-DVF(-	10	U	U	
0013	0013	Video Stations3		IX-DV, IX-DVF(-	10	U	U	
0014	0014	Video Stations4		IX-DV, IX-DVF(-	10	U	U	
0015	0015	Video Stations5		IX-DV, IX-DVF(-	10	U	U	
0016	0016	Video Stations6		IX-DA, IX-DF(-*	0			
0017	0017	Video Stations7		IX-DA, IX-DF(-*	0			
0018	0018	Video Stations8		IX-DA, IX-DF(-*	0			
0019	0019	Video Stations9		IX-DA, IX-DF(-*	0			
0020	0020	Video Stations10		IX-DA, IX-DF(-*	0			
0021	0021	Audio Stations1		IX-SSA(-*)	10	U	U	
0022	0022	Audio Stations2		IX-SSA(-*)	10	U	U	
0023	0023	Audio Stations3		IX-SSA(-*)	10	U	U	

For "Door Station Group Settings," refer to ["Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)"](#).

## 2.9 Location Registry

Select "Edit" > "Location Registry" to display the "Location Registry" window.

**Location Registry**

Create location name(s):  
IX-MV, IX-DA, and IX-BA can have a maximum of 50 locations.

#	Location Name
001	
002	
003	
004	
005	
006	
007	
008	
009	
010	
011	
012	
013	
014	
015	
016	

For "Location Registry," refer to ["Register location \(except IXW-MA\) \(→page 174\)"](#).

## 2.10 Manual Date / Time Setup

Select "Edit" > "Manual Date / Time Setup" to display the "Manual Date / Time Setup" window.

For "Manual Date / Time Setup," refer to ["Manual Date / Time Setup \(→page 178\)"](#).

## 2.11 IX Support Tool Settings

Select "Edit" > "IX Support Tool Settings" to display the "IX Support Tool Settings" window.

### How to configure IX Support Tool

1. Configure each item.
2. Click [OK].
  - Click [Cancel] to quite without registering.

#### ■ ID◆

Description	Set an ID to log in IX Support Tool.
Settings	1-32 alphanumeric characters
Default values	admin

**■ Password◆**

Description	Set a password to log in IX Support Tool.
Settings	1-32 alphanumeric characters
Default values	admin

**■ System Name◆**

Description	Change the system name. When changing the system name, the name of the folder where the setting data is stored will be changed as well.
Settings	1-64 alphanumeric characters
Default values	The system name of the setting data being edited will be shown.

**■ IP Version**

Description	Choose the protocol for IX Support Tool.
Settings	<ul style="list-style-type: none"> <li>• IPv4</li> <li>• IPv6</li> </ul>
Default values	IPv4

**■ Installer Information◆**

Description	Enter the installer information. The set installer information is displayed in station information/notes in IX-MV7-* - "Station Information" - "CONTACT INFORMATION."
Settings	4 rows (1-64 alphanumeric characters per row)
Default values	—


**■ Owner Information◆**

Description	Enter the owner information.
Settings	1-64 alphanumeric characters
Default values	—

**■ Notes◆**

Description	Enter the notes.
Settings	1-64 alphanumeric characters
Default values	—

## 3. Language




Set the language of following items.

- The display content of the IX Support Tool.
- The input text language of settings item. (Station Name, Address book, etc.)
- The content of the email message and system log.

### ! Important

- Configure each station through a Web browser individually, to set a different language for each station.
- If the language (configured on the station main unit) displayed on the screen for IX-MV7-\* or IX-MV is different from the language set in "Language," the characters may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.


## 4. Tools



### 4.1 Station Search

Search the stations in IX System connected in the network to show the list.

1. Connect the PC to a network on the same segment as the system.
  - Set it to the same protocol as the system. For information on protocol settings, refer to ["IX Support Tool Settings \(→page 156\)"](#).
2. Click "Tools" > "Station Search" to display the searched stations in the "Station Search" screen. (Searching may take several minutes.)
  - The stations without power and the stations in the process of initialization will not be subject to search.
  - Search up to 9999 stations at a time.
  - You cannot search for stations on other segments.
  - Click **[Search]** to restart the search.



## 4.2 Association Settings

The data created with IX Support Tool is to be assigned to each station.  
Associate the settings when creating the setting data.  
Some items cannot be configured without association.

**1. Select the setting file to be linked with the chosen station:**

Select	Number	Name	Location	Station Type	Hostname	IP Address	Associated
<input type="radio"/>	0001	Master Stations1		IX-MV7-*		192.168.1.10	Yes
<input checked="" type="radio"/>	0002	Master Stations2		IX-MV7-*		192.168.1.11	-
<input type="radio"/>	0003	Master Stations3		IX-MV7-*		192.168.1.12	-
<input type="radio"/>	0004	Master Stations4		IX-MV7-*		192.168.1.13	-
<input type="radio"/>	0005	Master Stations5		IX-MV7-*		192.168.1.14	-
<input type="radio"/>	0006	Master Stations6		IX-MV		192.168.1.15	-
<input type="radio"/>	0007	Master Stations7		IX-MV		192.168.1.16	-
<input type="radio"/>	0008	Master Stations8		IX-MV		192.168.1.17	-
<input type="radio"/>	0009	Master Stations9		IX-MV		192.168.1.18	-
<input type="radio"/>	0010	Master Stations10		IX-MV		192.168.1.19	-

**2. Select the station to associate with the setting file.**

Enter station MAC address:   Different Networks

Search and select station within local network:

Select	Number	Name	Location	Station Type	MAC address	Associated
<input type="radio"/>	00001	Master Stations1		IX-MV7-*	00:0B:AA:2F:00:0F	Yes
<input type="radio"/>	0011	Video Stations1		IX-DV, IX-DVF(-	192.168.1.20 00:0B:AA:27:00:5E	Yes
<input type="radio"/>	0041	Handset Sub Station		IX-RS-*	00:0B:AA:00:F8:51	Yes

**3. Station Setting List**  
A list of the setting files that have been created will be shown.

**4. Station List**  
The searched stations will be shown.

**5. Apply**  Search again for stations.

Station(s) that have been associated with a setting file are listed below.

Select	Number	Name	Location	Station Type	IP Address	MAC address	Status
<input type="checkbox"/>	0001	Master Stations1		IX-MV7-*	192.168.1.10	00:0B:AA:2F:00:0F	Success
<input type="checkbox"/>	0011	Video Stations1		IX-DV, IX-DVF(-	192.168.1.20	00:0B:AA:27:00:5E	Success
<input type="checkbox"/>	0041	Handset Sub Station		IX-RS-*	192.168.1.50	00:0B:AA:00:F8:51	Success

**Associated Stations List**  
The settings that have been associated will be shown.

Removes association.

Perform association again.

1. Connect the PC to a network on the same segment as the system.
  - Set it to the same protocol as the system. For information on protocol settings, refer to ["IX Support Tool Settings \(→page 156\)"](#).
2. Select "Tools" > "Association Settings" to perform a station search, and the "Association Settings" window will be displayed. (The search may take several minutes)
  - The stations without power and the stations in the process of initialization will not be subject to search.
  - Search up to 9999 stations at a time.
  - Click **[Station Search]** to restart the search.
  - You cannot search for stations on other segments. Refer to Step 9.

- 3.** Select the file to associate from "Station Settings List."
  - A setting file that has already been associated cannot be selected.
  - A setting file without a configured IP address cannot be selected.
- 4.** Select the station with which the setting file selected at Step 3 will be associated from "Station List."
  - A station that has already been associated cannot be selected.
  - Select "Enter station MAC address" to specify a station by entering the MAC address.
  - To associate a station on another segment, select "Enter station MAC address" and "Different Networks," and then enter the MAC address to specify the station.
- 5.** Click **[Apply]**.
  - Associated content is displayed on the "Associated Stations List."  
When setting a new IP address or changing an old address, the station will be restarted and the IP address and station name will be updated. If a station on another segment was associated in Step 4, it will not be updated. Update the IP address and station name through a Web browser.
- 6.** Repeat steps 3 - 5 and associate all stations.
  - To dissociate, select the content to remove from "Associated Stations List" (multiple selections allowed), and then click **[Remove Association]**.

## 4.3 Station Replacement

Use this feature to replace a station. The station can only be replaced with one of the same station type.

### Note

- To replace a station on another segment, select "Tools" - "Association Settings" to remove the association with the malfunctioning station and then associate the newly installed station.

### Station Replacement

1. Select the station to be replaced:

Select	Number	Name	Location	Station Type	MAC address
<input checked="" type="radio"/>	0001	Master Stations1		IX-MV7-*	00:0B:AA:2F:00:0F
<input type="radio"/>	0002	Master Stations2		IX-MV7-*	
<input type="radio"/>	0003	Master Stations3		IX-MV7-*	
<input type="radio"/>	0004	Master Stations4		IX-MV7-*	
<input type="radio"/>	0005	Master Stations5		IX-MV7-*	
<input type="radio"/>	0006	Master Stations6		IX-MV	
<input type="radio"/>	0007	Master Stations7		IX-MV	
<input type="radio"/>	0008	Master Stations8		IX-MV	
<input type="radio"/>	0009	Master Stations9		IX-MV	
<input type="radio"/>	0010	Master Stations10		IX-MV	
<input type="radio"/>	0011	Video Stations 1		IX-DV, IX-DVF(-	00:0B:AA:27:00:5E

4

2. Select the replacement station:

Select	MAC address	Station Type
<input checked="" type="radio"/>	00:0B:AA:2F:00:0F	IX-MV7-*
<input type="radio"/>	00:0B:AA:27:00:5E	IX-DV, IX-DVF(-
<input type="radio"/>	00:0B:AA:00:F8:51	IX-RS-*


5

6

The MAC address for the associated stations will be displayed. If there are no associations, there will be no display.

- Connect the PC to a network on the same segment as the system.
  - Set it to the same protocol as the system. For information on protocol settings, refer to ["IX Support Tool Settings \(→page 156\)"](#).
- Replace the station.
- Select "Tools" > "Station Replacement" to perform a station search, and the "Station Replacement" window will be displayed. (The search may take several minutes)
  - The stations without power and the stations in the process of initialization will not be subject to search.
  - Search up to 9999 stations at a time.
  - Click **[Search]** to restart the search.
  - Stations can not be found using search if stations are on different network segments.
- Select the station to replace from "Station List."
  - Stations that are not associated cannot be selected.
- Select the newly installed station from "Station List."

6. Click **[Apply]**.
  - The setting data will be uploaded to the newly installed station.
7. Click **[OK]**.
  - Click **[Cancel]** to return to "Station Replacement" window without uploading.




8. Click **[OK]**.




## 8. Click [OK].

- Click [Cancel] to return to the "Restore System Settings" window.




## 9. Click [OK].

- The result is displayed in "Station List" > "Status."
  - Restoring: The setting file is in the process of restoring.
  - Success: Restore successful.
  - Failed: Restore failed.
- Restored setting files are saved as follows in "AIPHONE\_IX\_SupportTool" - "SystemData" within the folder specified when installing IX Support Tool.
  - Setting file: "NewIXSystem(Set System Name).db"
  - Sound file: Saved as a WAV file in "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Image file: Saved as a PNG file in "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Schedule file: Saved in "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)" as "SCHED\_CHIME.txt," "SCHED\_GROUP.txt," "SCHED\_OUTPUT.txt," "SCHED\_TRANSFER.txt," or "SCHED\_REC.txt" (the saved content differs depending on the station; included in the setting file for IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*)).
- The items that could not be restored are displayed as shown below.




## 4.5 System Configuration

The process from associating a newly created setting file to uploading the setting file can be configured here. Select "Tools" - "System Configuration." The "System Configuration" screen will be shown.




The procedure for "System Configuration" is the same from step 5 in ["Use the Wizard function to easily set up the system and make it operational \(→page 125\)"](#).

# 5. Help



## 5.1 Update Firmware


Select "Help" > "Update Firmware" to display the "Update Firmware" window.



For "Update Firmware," refer to ["Firmware Update \(→page 546\)"](#).

## 5.2 About

Select "Help" > "About" to display the "Version Information" window.



Click **[Close]** to close the "Version Information" window.

# System Settings (Table View)

## Important

- Depending on the language settings of the station (IX-MV7-\* or IX-MV), the content of the settings may differ from this manual.
- The symbols indicate the following:
  - ◆: Be sure to input the settings. Leave any of these unused settings at their default values.

# 1. Station Information

## 1.1 Identification

Configure the station number, station name, and location of the station to register in the system. Up to 500 stations can be registered.

**Move row**  
 Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

[“Add a Station \(→page 172\)”](#)  
[“Remove Station \(→page 173\)”](#)  
[“Register location \(except IXW-MA\) \(→page 174\)”](#)

Number of Notes: 2  
 1. Locations must be created in the Location Registry before they can be assigned to a Station.  
 2. Station Type cannot be changed once registered. To modify, station must be removed.

Station Information				
Identification				
#	Number	Name	Location	Station Type
0001	0001	Master Stations1		IX-MV7-*
0002	0002	Master Stations2		IX-MV7-*
0003	0003	Master Stations3		IX-MV7-*
0004	0004	Master Stations4		IX-MV7-*
0005	0005	Master Stations5		IX-MV7-*
0006	0006	Video Stations1		IX-DV, IX-DVF(-*)
0007	0007	Video Stations2		IX-DV, IX-DVF(-*)

Text in red are required settings.

**! Important**

- Always configure [“Language \(→page 158\)”](#) before setting "Identification."
- Enter the language configured in [“Language \(→page 158\)”](#). However, if the language displayed on the screen for IX-MV7-\* or IX-MV (configured on the station main unit) is different from that set in [“Language \(→page 158\)”](#), the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.
- Results when searching by station will be listed in order of station number.

**■ Number◆**

Description	Set an unique number for each station. The station number will be displayed on the screen of the destination during call, page, etc. This is also used to search stations by station number for IX-MV7-* and IX-MV.
Settings	3-5 digits
Default values	Start from 0001.

## ■ Name

Description	Set the station name. The station name will be displayed on the screen of the destination during call, page, etc. This is also used to search stations by station name for IX-MV7-* and IX-MV.
Settings	1-24 alphanumeric characters
Default values	IX-MV7-*, IX-MV: Master Station (number); IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*): Video Door Station (number); IX-SSA(-*), IX-SS-2G, IX-BA, IX-SS(-*): Audio Door Station (number); IX-RS-*: Handset Sub Station (number);IXW-MA: I/O Adaptor (number)
Remarks	If left blank, station name will be the same as station number.


## ■ Location (except IXW-MA)

Description	Select the Location of the station. The location will be displayed on the screen of the destination during call, page, etc.
Settings	Select one from the Location registered in " <a href="#">Register location (except IXW-MA) (→page 174)</a> ".
Default values	-

### 1.1.1 Add a Station

Add a Station to setting data.

Click **[Add New Station]** to display the "Add New Station" screen.




#### ■ How to add a station

1. Enter the station type and the number of the stations to be added.
2. Click **[Add]**.
3. Click **[OK]**.
  - Click **[Cancel]** to end the process for adding a new station.

## 1.1.2 Remove Station


Delete a station from the settings.

Click ["**Remove Station**"], the "Station Removal" window will be shown.



### How to delete a station

1. Select the station(s) to be deleted.
2. Click [**Delete**].
  - Click [**Cancel**] to end the Station Removal.
3. Click [**Yes**] to delete the station.



- Click [**No**] to cancel the deletion and return to the "Station Removal" window.

4. Click [**OK**].

### 1.1.3 Register location (except IXW-MA)

Click **[Location Registry]** , the "Location Registry" window will be shown.

Up to 100 locations can be registered. However, only locations set between 001 and 050 can be used with IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*).

#### How to register a location

1. Enter the location in "Location List." For IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*), enter locations within range of 001-050.
  - Location: 1 - 24 alphanumeric characters
2. Click **[Update]**.
3. Click **[OK]**.

## 1.2 ID and Password

Set the ID and password for logging in via a web browser, and the ID and password for ONVIF/RTSP authentication.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.



■ Administrator ID◆

Description	Set the ID of the administrator account for logging in to the Web System Setting Server. For IX-MV7-*, configure the administrator ID used to access the station's Settings screen.
Settings	1-32 alphanumeric characters
Default values	admin

■ Administrator Password◆

Description	Set the Password of the administrator account for logging in to the Web System Setting Server. For IX-MV7-*, configure the administrator password used to access the station's Settings screen.
Settings	1-32 alphanumeric characters
Default values	admin

■ User ID◆

Description	Set the ID of the user account for logging in to the Web System Setting Server.
Settings	1-32 alphanumeric characters
Default values	user

■ User Password◆

Description	Set the Password of the user account for logging in to the Web System Setting Server.
Settings	1-32 alphanumeric characters
Default values	user

### ■ ONVIF ID (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ◆

Description	Set the ID to access this station from 3rd party products using ONVIF. The setting values for IX-DA, IX-DF(-*) cannot be changed from their default values (they are not shown in the Settings screen).
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ ONVIF Password (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ◆

Description	Set the Password to access this station from 3rd party products using ONVIF. The setting values for IX-DA, IX-DF(-*) cannot be changed from their default values (they are not shown in the Settings screen).
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ RTSP ID (for IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*)◆

Description	Set the ID to access this station from 3rd party products using RTSP.
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ RTSP Password (for IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*)◆

Description	Set the Password to access this station from 3rd party products using RTSP.
Settings	1-32 alphanumeric characters
Default values	aiphone

#### Note

- The "Administrator ID" and "User ID" cannot be identical.
- The ONVIF port number is "10080" and the RTSP port number is "554."
- To view video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) using a 3rd party product, refer to ["Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\) \(→page 199\)"](#).
- The ONVIF ID and ONVIF password for IX-DA, IX-DF(-\*) can be changed on a 3rd party product. If changed on a 3rd party product, the Settings screen will not show the changes.
- The "Administrator Password," "User Password," "ONVIF Password," and "RTSP Password " are displayed as "\*\*\*\*\*" on the screen.

## 1.3 Time

Set the date and time for each station.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]**: Display the previous 50 rows.

**[Next]**: Display the next 50 rows.

**[Display]**: Enter the station number and click **[Display]** to move the cursor to the entered row.

["Manual Date / Time Setup \(→page 178\)"](#)

#	Station Information				Station Information		D
	Identification	Number	Name	Location	Station Type	Time Zone	
0001	0001	Master Stations1			IX-MV7-*	(GMT-08:00) Pacific Standard Time (US), Tijuana	N
0002	0002	Master Stations2			IX-MV7-*	(GMT-08:00) Pacific Standard Time (US), Tijuana	N

### 1.3.1 Time Zone

#### ■ Select time zone

Description	Set the Time Zone.
Settings	Select from 99 regions
Default values	When a new system is created, the following settings will be set to these defaults depending on the language selected. Japanese: (GMT+09:00) Osaka, Sapporo, Tokyo English: (GMT-08:00) Pacific Standard Time (US), Tijuana French: (GMT+01:00) Brussels, Madrid, Copenhagen, Paris Spanish: (GMT+01:00) Brussels, Madrid, Copenhagen, Paris Dutch: (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm Traditional Chinese: (GMT+08:00) Taipei Simplified Chinese: (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi

### 1.3.2 Daylight Savings Time

#### ■ Enable automatic daylight savings time

Description	The daylight saving time is set automatically according by region selected in "Select time zone."
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### 1.3.3 Manual Date / Time Setup

Enter the time for each station. Time is used for incoming calls, outgoing calls, and the system log.


#### ! Important

- The time cannot be set unless the [“Association Settings \(→page 160\)”](#) is performed and the PC is connected to the same network as the station.


Click **[Manual Date / Time Setup]** , the "Manual Date / Time Setup" window will be shown.

#### How to configure the date and time

1. Select "Year," "Month," "Day," "Hour," "Minute," and "Second."
  - Click **[Sync with PC]** to synchronize with PC.
2. Click **[Apply]**.
  - If "Association Settings" has not been configured, the following screen will be shown. Click **[OK]** and use [“Association Settings \(→page 160\)”](#).



- If the PC cannot communicate with the system, the following screen will be shown. Click **[OK]**, and then ensure the PC can communicate with the system.



3. Click **[OK]**.

## 1.4 Expanded System

"Expanded System" is a common setting.  
An "Expanded System" cannot change from "Enable" to "Disable".  
If the system contains IX-MV, "Expanded System" cannot be set to "Enable".

Expanded System  Enable  Disable

### ■ Expanded System

Description	Not used.
-------------	-----------

# 2. Network Settings

## 2.1 IP Address

Configure the hostname, IP address, subnet mask, and default gateway for each station.

**! Important**

- When a setting related to the IP address is updated on a station, it will restart. In some cases, it may take up to 10 minutes for the station to start up.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

["Batch IP Address Configuration \(→page 183\)"](#)

#	Station Information				Network Settings																	
	Identification				IP Address								Subnet Mask				Default Gateway					
	Number	Name	Location	Station Type	Hostname	IP Version	Static / DHCP	IP Address				Subnet Mask				Default Gateway						
0001	0001	Master Stations1		IX-MV7-*		IPv4	Static	192	168	1	10	255	255	255	0							
0002	0002	Master Stations2		IX-MV7-*		IPv4	Static	192	168	1	11	255	255	255	0							

■ **Hostname (except IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*))**

Description	Set the Hostname for each station. Hostname can be used to access to the stations that is registered in <a href="#">"Address Book (for IX-MV7-* and IX-MV) (→page 208)"</a> and <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 225)"</a> . Go to <a href="#">"DNS (→page 185)"</a> to set Hostname.
Settings	1-64 alphanumeric characters
Default values	-

**💡 Note**

- Communication from IX Support Tool to the stations use the IP address.

■ **IP Version**

Description	Select the Protocol.
Settings	<ul style="list-style-type: none"> <li>IPv4</li> <li>IPv6</li> </ul>
Default values	IPv4

**! Important**

- IPv4 and IPv6 cannot be mixed in the same system.

**■ Static / DHCP**

Description	Select Static or DHCP for the selected IP version in "IP Version."
Settings	For IPv4 <ul style="list-style-type: none"> <li>• Static</li> <li>• DHCP</li> </ul> For IPv6 <ul style="list-style-type: none"> <li>• Static</li> <li>• Stateless</li> <li>• DHCPv6</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Static</li> </ul>

**! Important**

- When selecting "DHCP" for IPv4, configure the system so that the DHCP server assigns a Static IP Address to each station.
- When selecting "Stateless" for IPv6, do not change the prefix of the device so that it can transmit RA.
- When selecting "DHCPv6" for IPv6, configure the system so that the DHCP server assigns a Static IP Address to each station. DUID of the station is "00030001 + MAC address."
- When setting up a product from another manufacturer, such as a DHCP server, refer to its manual.

## 2.1.1 IPv4 Address

### Important

- If "[Static / DHCP \(→page 181\)](#)" is set to "DHCP," settings will not be applied to the station even if the "IP Address," "Subnet Mask," and "Default Gateway" are set.

### ■ IP Address◆

Description	Set the IP Address. The IP Address should be unique.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

### ■ Subnet Mask◆

Description	Set the Subnet Mask.
Settings	128.0.0.0 - 255.255.255.255
Default values	-

### ■ Default Gateway

Description	Set the Default Gateway.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

## 2.1.2 IPv6 Address

### ! Important

- If "Static / DHCP" is set to "Stateless" or "DHCPv6," settings will not be applied to the station even if "IP Address" and "Default Gateway" are set.

### ■ IP Address◆

Description	Set the IP Address. The IP Address should be unique.
Settings	2000::0 - 3FFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or FD00::0 - FDFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

### ■ Default Gateway

Description	Set the Default Gateway.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

## 2.1.3 Batch IP Address Configuration

Click ["Batch IP Address Configuration"], the "Batch IP Address Configuration" window will be shown.

1 Enter starting IP address (IPv4 or IPv6) and subnet mask

2 Subnet Mask

3 Station List


4 OK

Select	Number	Name	Location	Station Type	IP Address (IPv4)	IP Address (IPv6)
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	192.168.1.10	
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	192.168.1.11	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	192.168.1.12	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	192.168.1.13	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	192.168.1.14	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	192.168.1.15	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	192.168.1.16	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	192.168.1.17	
<input type="checkbox"/>	0009	Master Stations9		IX-MV	192.168.1.18	

### How to perform Batch IP Address Configuration

1. Enter the starting address that is to be automatically assigned to "IPv4 Address" or "IPv6 Address."
2. For IPv4, enter "Subnet Mask."
  - With the subnet mask, set the range for assignment. The network addresses in the range and the broadcast addresses cannot be assigned.
3. Select the station to which the IP address in "Station List" is to be automatically assigned.
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.

4. Click **[OK]**.
5. Click **[OK]**. the Batch IP Addresses will be automatically assigned, and the subnet mask will be entered.
  - Click **[Cancel]** , the screen will go back to "Batch IP Address Configuration" window.



## 2.2 DNS

When IPv4 or IPv6 is configured by hostname for each entry, or when using the email function configured in [“Email \(→page 269\)”](#) for IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*) a DNS server must be configured for name resolution.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

Row
Previous
Next

Display

#	Station Information				Network Settings <span style="color: red; font-size: small;">Text in red are required settings.</span>											
	Identification				DNS											
	Number	Name	Location	Station Type	Primary Server				Secondary Server							
					IPv4		IPv6		IPv4		IPv6					
1	2	3	4	1	2	3	4	1	2	3	4					
0001	0001	Master Stations1		IX-MV7-*												
0002	0002	Master Stations2		IX-MV7-*												

### 2.2.1 Primary Server

#### ■ IPv4

Description	Set the IPv4 address for DNS Primary Server.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

#### ■ IPv6

Description	Set the IPv6 address for DNS Primary Server.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

### 2.2.2 Secondary Server

#### ■ IPv4

Description	Set the IPv4 address for DNS Secondary Server.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

#### ■ IPv6

Description	Set the IPv6 address for DNS Secondary Server.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

## 2.3 SIP (except IXW-MA)

Configure SIP settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Jump to related item

Moves to the selected item within the same Settings screen.

The screenshot shows the SIP settings interface. At the top, there are navigation buttons: 'Previous', 'Next', and 'Display'. A 'Row' field with 'Enter Number' and a 'Display' button is also present. A dropdown menu labeled '(Move to Related Settings)' is set to 'SIP Connections'. Below this is a 'Number of Notes: 2' section with two notes: '1. To set VoIP Phone Volume Adjustment, go to "Station Settings -> Volume/Tone -> Volume -> VoIP Phone Volume Adjustment"' and '2. To set VoIP Phone Call Priority, go to "Call Settings -> Incoming Call -> VoIP Phone Call Priority"'. The main table is titled 'Station Information' and 'Network Settings'. The 'Station Information' part has columns for '#', 'Number', 'Name', 'Location', and 'Station Type'. The 'Network Settings' part has columns for 'SIP Connections' (with sub-columns 'SIP Signaling Port' and 'User Agent') and 'Primary Server' (with sub-columns 'ID', 'Password', 'IPv4 Address', and 'IPv6 Address'). The table contains three rows of data for Master Stations 1, 2, and 3, all with a Station Type of 'IX-MV7-\*' and a SIP Signaling Port of 5060. A note at the bottom right of the table states 'Text in red are required settings.'

### 2.3.1 SIP Connections

#### ■ SIP Signaling Port◆

Description	Set the Port Number for SIP. Set the same port number for each station to communicate.
Settings	1 - 65535
Default values	5060

#### ■ User Agent (except IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*))

Description	Set the User Agent.
Settings	1-36 alphanumeric characters
Default values	-

### 2.3.2 SIP Server (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))

Configure integration with 3rd party SIP based PBX systems. Please contact your local Aiphone distribution for more information.

#### 2.3.2.1 Primary Server

##### ■ ID

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**■ Password**

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

**■ IPv4 Address**

Description	Configure the IPv4 address of the SIP server.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

**■ IPv6 Address**

Description	Configure the IPv6 address of the SIP server.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

**■ Port◆**

Description	Configure the Port Number to communicate with the SIP server.
Settings	1 - 65535
Default values	5060

**2.3.2.2 Secondary Server****■ ID**

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**■ Password**

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

**■ IPv4 Address**

Description	Configure the IPv4 address of the SIP server.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

**IPv6 Address**

Description	Set the IPv6 address of the SIP server.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

**Port**

Description	Set the Port Number to communicate with the SIP server.
Settings	1-65535
Default values	5060

**2.3.2.3 Tertiary Server****ID**

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Password**

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

**IPv4 Address**

Description	Set the IPv4 address of the SIP server.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

**IPv6 Address**

Description	Set the IPv6 address of the SIP server.
Settings	::FF:0-FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)
Default values	-

**Port**

Description	Set the Port Number to communicate with the SIP server.
Settings	1-65535
Default values	5060

### 2.3.3 Miscellaneous

#### ■ Register Transmission Interval [sec] (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*)) ◆

Description	Configure the Transmission Interval to send Register to the SIP server.
Settings	10-14400 sec
Default values	3600 sec

#### ■ DTMF digit interval timeout [sec] (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*)) ◆

Description	Configure the time to timeout signal reception, when a DTMF signal is not received from the VoIP Phone for a continuous period of time.
Settings	1-10 sec
Default values	5 sec

#### Important

- Configure the IP-PBX and VoIP phone DTMF with outbound.

#### ■ Call health check timer [sec]◆

Description	Set the timer to transmit re-INVITE while calling and monitoring.
Settings	<ul style="list-style-type: none"> <li>• Do not transmit re-INVITE: Do not detect communication errors.</li> <li>• 80-3600 sec: Select to set between 80-3600 sec (by 1 sec).</li> </ul>
Default values	90 sec

## 2.4 Multicast Address (For IX-MV7-\*, IX-MV, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

This must be configured if multicast is enabled in [“Group \(for Master\) \(for IX-MV7-\\* and IX-MV\) \(→page 217\)”](#), [“All Page \(for IX-MV7-\\* and IX-MV\) \(→page 256\)”](#), and [“Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)”](#).

### Note

- A multicast address must be configured to utilize All Page.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

[“Batch Multicast Address Configuration \(→page 191\)”](#)

Row
Previous Next

Display

[Related Settings]

Batch MulticastAddress Configuration

#	Station Information				Network Settings			
	Identification				MulticastAddress			
	Number	Name	Location	Station Type	Master Station: For Call / Paging, Video Door Station: For Call			
					IPv4		IPv6	
	1	2	3	4				
0001	0001	Master Stations1		IX-MV7-*				
0002	0002	Master Stations2		IX-MV7-*				

Text in red are required settings.

### ■ IPv4


Description	Set the IPv4 Multicast Address. The Multicast Address should be unique.
Settings	224.0.0.0 - 239.255.255.255
Default values	-

### ■ IPv6

Description	Set the IPv6 Multicast Address. The Multicast Address should be unique.
Settings	FF10::0 - FF1F:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-


## 2.4.1 Batch Multicast Address Configuration

Click **[Batch Multicast Address Configuration]**, the "Batch Multicast Address Configuration" window will be shown.



### How to perform Batch Multicast Address Configuration

1. Enter the starting multicast address that is to be automatically assigned to "IPv4" or "IPv6."
2. Select the station(s) to which the multicast address in "Station List" is to be automatically assigned.
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
3. Click **[OK]**.
4. Click **[OK]**, the multicast addresses will be automatically assigned.
  - Click **[Cancel]**, the screen goes back to "Batch Multicast Address Configuration" window.



## 2.5 Video (for IX-MV7-\*, IX-MV, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Configure video settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Move to Related Settings

Moves to the selected item within the same Settings screen.

The screenshot shows a settings interface with a navigation bar at the top. On the left, there is a 'Row' section with an 'Enter Number' input field and a 'Display' button. In the center, there are 'Previous' and 'Next' buttons. On the right, there is a 'Move to Related Settings' dropdown menu currently showing 'Video Encoder 1'. Below the navigation bar, there are two notes: 'Number of Notes:3' and two numbered notes about H.264/AVC and Motion-JPEG settings. The main content area is a table with two columns: 'Station Information' and 'Network Settings'. The 'Station Information' column has sub-columns for 'Identification', 'Number', 'Name', 'Location', and 'Station Type'. The 'Network Settings' column has sub-columns for 'Video', 'Video Encoder 1', 'Video Codec', 'Resolution', 'Frame Rate [fps]', 'Select Profile [H.264 / AVC]', and 'I-picture interval [s]'. The table contains two rows of data for stations 0001 and 0002.

#	Station Information				Network Settings							
	Identification	Number	Name	Location	Station Type	Video	Video Encoder 1	Video Codec	Resolution	Frame Rate [fps]	Select Profile [H.264 / AVC]	I-picture interval [s]
0001	0001	Master Stations1			IX-MV7-*							
0002	0002	Master Stations2			IX-MV7-*							

### 2.5.1 Video Encoder 1

Configure video settings when placing a call between stations, during communication, or when calling a VoIP phone. Configure video settings for IX-MV7-\* in ["Master Station Video Setting \(for IX-MV7-\\*\) \(→page 197\)"](#).

#### ■ Video Codec (for IX-DA, IX-DF(-\*))

Description	Select Video Codec.
Settings	<ul style="list-style-type: none"> <li>• H.264 / AVC</li> <li>• Motion-JPEG</li> </ul>
Default values	H.264 / AVC

#### Note

- For IX-DV, IX-DVF(-\*), "Video Codec" is set to "H.264 / AVC" and cannot be changed.

#### ■ Resolution (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the video resolution of Video Encoder 1.
Settings	<ul style="list-style-type: none"> <li>• 320×240 (QVGA)</li> <li>• 640×480 (VGA)</li> </ul>
Default values	IX-DV, IX-DVF(-*): 640×480 (VGA) IX-DA, IX-DF(-*): 320×240 (QVGA)

### ■ Frame Rate [fps] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the Frame Rate [fps] of Video Encoder 1.
Settings	1, 2 (for IX-DV, IX-DVF(-*)), 3, 5, 7.5, 10, 15, 20, 30 fps For IX-DA and IX-DF(-*), when the frame rate is set to 7.5, 10, 15, 20 or 30 fps, the frame Rate will be 5 fps after approx. 10 min of an outgoing call.
Default values	IX-DV, IX-DVF(-*): 10fps IX-DA, IX-DF(-*): 15 fps

#### Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Profile [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the H.264/AVC Profile of Video Encoder 1.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

### ■ I-picture interval [H.264/AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ◆

Description	Set the interval to send H.264/AVC I-picture of Video Encoder 1.
Settings	1 - 100
Default values	IX-DV, IX-DVF(-*): 10 IX-DA, IX-DF(-*): 15

### ■ Bit rate [kbps] [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the H.264/AVC Bit Rate of Video Encoder 1.
Settings	32 (for IX-DV, IX-DVF(-*)), 64, 128, 256, 384, 512, 768, 1024, 2048 kbps
Default values	1024 kbps

#### Note

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Quality [Motion-JPEG] (for IX-DA, IX-DF(-\*))

Description	Select the Quality of Motion-JPEG of Video Encoder 1.
Settings	1 (low) - 10 (high)
Default values	6

### ■ RTP Start Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 1. Set the difference to 90 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65534
Default values	30000

### ■ RTP End Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 1. Set the difference to 90 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65535
Default values	31000

## 2.5.2 Video Encoder 2

Set when transmitting video using ONVIF.

To view video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) with a 3rd party product, refer to [“Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\) \(→page 199\)”](#).

### Important

- These settings may be changed by ONVIF-compliant 3rd party products, if utilized. Refer to the manual of the 3rd party product to be used.

### ■ Second Video Encoder (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select Enable / Disable for Second Video Encoder. Set to "Enable" to send the video using ONVIF.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

### ■ Video Codec (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the Video Codec of Video Encoder 2.
Settings	<ul style="list-style-type: none"> <li>• H.264 / AVC</li> <li>• Motion-JPEG</li> </ul>
Default values	H.264 / AVC

### ■ Resolution (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the video resolution of Video Encoder 2.
Settings	<ul style="list-style-type: none"> <li>• 320x240(QVGA)</li> <li>• 640x480(VGA)</li> <li>• 800x480(WVGA) (For IX-DV, IX-DVF(-*))</li> <li>• 1280x720(HD) (For IX-DV, IX-DVF(-*))</li> <li>• 1280x960(SXVGA) (For IX-DV, IX-DVF(-*))</li> </ul>
Default values	IX-DV, IX-DVF(-*): 1280x720(HD) IX-DA, IX-DF(-*): 320x240(QVGA)

### ■ Frame Rate [fps] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the Frame Rate [fps] of Video Encoder 2.
Settings	1, 2 (for IX-DV, IX-DVF(-*)), 3, 5, 7.5, 10, 15, 20, 30 fps For IX-DA and IX-DF(-*), when the frame rate is set to 7.5, 10, 15, 20 or 30 fps, the frame Rate will be 5 fps after approx. 10 min of an outgoing call.
Default values	IX-DV, IX-DVF(-*): 10 fps IX-DA, IX-DF(-*): 15 fps

### Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Profile [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the H.264/AVC Profile of Video Encoder 2.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

### ■ I-picture interval [H.264/AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ◆

Description	Set the interval to send H.264/AVC I-picture of Video Encoder 2.
Settings	1 - 100
Default values	IX-DV, IX-DVF(-*): 10 IX-DA, IX-DF(-*): 15

### ■ Bit rate [kbps] [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the H.264/AVC Bit Rate of Video Encoder 2.
Settings	32 (for IX-DV, IX-DVF(-*)), 64, 128, 256, 384, 512, 768, 1024, 2048, 4096 (for IX-DV, IX-DVF(-*)), 8192 (for IX-DV, IX-DVF(-*)) kbps
Default values	IX-DV, IX-DVF(-*): 2048 kbps IX-DA, IX-DF(-*): 1024 kbps



#### Note

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Quality [Motion-JPEG] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the Quality of Motion-JPEG of Video Encoder 2.
Settings	1 (low) - 10 (high)
Default values	6

### ■ RTP Start Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 2. Set the difference to 10 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65534
Default values	32000

### ■ RTP End Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 2. Set the difference to 10 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65535
Default values	33000

### 2.5.3 Master Station Video Setting (for IX-MV7-\*)

Configure video settings for the IX-MV7-\* camera.

#### Important

- When sending video to an VoIP Phone, configure to the same video settings as the VoIP Phone.
- Video is not sent when making an outgoing call to a VoIP Phone.

#### ■ Video Streaming

Description	Select Enable / Disable for Video Streaming of IX-MV7-*. Video cannot be distributed to 3rd party products not compatible with ONVIF or to IX-MV. The Video Codec is H.264 / AVC.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

#### ■ Frame Rate [fps]

Description	Set the Frame Rate [fps].
Settings	0.5, 1, 2, 3, 5, 7.5, 10, 15, 20, 30 fps
Default values	15 fps

#### Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

#### ■ Select Profile

Description	Set the profile for Video Streaming.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

#### ■ I-picture interval◆

Description	Select the interval to send I-picture for Video Streaming.
Settings	1 - 100
Default values	15

#### ■ Bit rate [kbps]

Description	Select the bit rate [kbps].
Settings	32, 64, 128, 256, 384, 512, 768, 1024, 2048 kbps
Default values	1024 kbps



**Note**

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

## 2.5.4 Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)

IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) support ONVIF Profile S and RTSP.

Video and audio of IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) can be monitored from a 3rd party product.

### ! Important

- Video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) camera cannot be viewed simultaneously by more than two 3rd party products.
- Audio will not be distributed if ["Audio Codec \(→page 200\)"](#) is set to "G.722."

**Configuring IX-DV, IX-DVF(-\*), and IX-DA so that video can be viewed on a 3rd party product.**

1. Select "Enable" for ["Second Video Encoder \(for IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\) \(→page 195\)"](#).
2. Configure video and audio settings.
  - Configure video in ["Video Encoder 2 \(→page 195\)"](#), and audio in ["Audio 2 RTP Start Port♦ \(→page 202\)"](#) and ["Audio 2 RTP End Port♦ \(→page 202\)"](#).

### ! Important

- Configure ["Video Encoder 2 \(→page 195\)"](#) according to the specification of the product.

3. Register IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) with a third party product. Enter the following as necessary.
  - For IX-DV, IX-DVF(-\*)
    - ONVIF ID: Configure in ["ONVIF ID \(for IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\) ♦ \(→page 176\)"](#).
    - ONVIF Password: Configure in ["ONVIF Password \(for IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\) ♦ \(→page 176\)"](#).
    - ONVIF Port: 10080
    - RTSP ID: Configure in ["RTSP ID \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\), IX-SS-2G, IX-RS-\\*\) ♦ \(→page 176\)"](#).
    - RTSP Password : Configure in ["RTSP Password \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\), IX-SS-2G, IX-RS-\\*\) ♦ \(→page 176\)"](#).
    - RTSP Port: 554
  - For IX-DA, IX-DF(-\*)
    - ONVIF ID: aiphone
    - ONVIF Password: aiphone
    - ONVIF Port: 10080
    - RTSP ID: aiphone
    - RTSP Password : aiphone
    - RTSP Port: 554
  - For how to register, refer to the instruction manual of the third party product to be registered.

### ! Important

- "ONVIF ID" and "ONVIF Password" can be changed on the 3rd party product.
- If changed on a third party product, IX-DA, IX-DF(-\*) will not show the changes on IX Support Tool.

## 2.6 Audio (except IXW-MA)

Configure the settings for audio.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a web interface for audio settings. At the top, there is a navigation bar with a 'Row' label, a 'Previous' button, a 'Next' button, an input field for 'Enter Number', and a 'Display' button. Below this, there are two red notes: '1. The Audio 1 RTP End Port should be greater than 210 digits from the RTP Start Port.' and '2. The Audio 2 RTP End Port should be greater than 10 digits from the RTP Start Port.' The main part of the interface is a table with columns for Station Information and Network Settings. The table contains three rows of data for Master Stations 1, 2, and 3.

Station Information				Network Settings					
#	Identification			Audio					
	Number	Name	Location	Station Type	Audio Codec	Audio RTP Transmission Interval [msec]	RTP Idle Detection Time [sec]	Audio 1 RTP Start Port	Audio 1 RTP End
0001	0001	Master Stations1		IX-MV7-*	G.711(μ-law)	20	10	20000	
0002	0002	Master Stations2		IX-MV7-*	G.711(μ-law)	20	10	20000	
0003	0003	Master Stations3		IX-MV7-*	G.711(μ-law)	20	10	20000	

### ■ Audio Codec

Description	Select the Audio Codec.
Settings	<ul style="list-style-type: none"> <li>• G.711 (μ-Law)</li> <li>• G.711 (A-Law)</li> <li>• G.722 (except IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*))</li> </ul>
Default values	G.711 (μ-Law)

## ! Important

- When changing from "G.711" to "G.722" or from "G.722" to "G.711," the station will restart when the change is applied. In some cases, it may take around 10 minutes to restart the station.
- Stations with different audio codecs (G.711 and G.722) selected cannot ring, call, monitor, or page each other.
- When changing "G.711" to "G.722" and "G.722" to "G.711," change the custom tones used for the following subcategories to audio files with appropriate audio sample rates. ["Custom Sound Registry \(except IXW-MA\) \(→page 221\)"](#)
  - "Call Origination" - ["Ringback Tone \(except IX-MV\) \(→page 229\)"](#)
  - "Call Origination" - ["Busy Tone \(except IX-MV\) \(→page 235\)"](#)
  - "Call Origination" - ["Error Tone \(Call Failed\) \(except IX-MV7-\\* and IX-MV\) \(→page 236\)"](#)
  - "Incoming Call" - ["Ringtone \(→page 238\)"](#)
  - "Incoming Call" - ["Call Button \(for IX-MV7-\\* and IX-MV\) \(→page 239\)"](#)
  - "Incoming Call" - ["Option Input \(for IX-MV7-\\* and IX-MV\) \(→page 239\)"](#)
  - "Relay Output" - ["Door Release \(→page 249\)"](#)
  - "Relay Output" - ["Relay Control \(start\) \(except IX-DA, IX-DF\(-\\*\) and IX-BA, IX-SS\(-\\*\)\) \(→page 249\)"](#)
  - "Relay Output" - ["Relay Control \(end\) \(except IX-DA, IX-DF\(-\\*\) and IX-BA, IX-SS\(-\\*\)\) \(→page 250\)"](#)
  - "Option Input Page" - ["Message File Name \(→page 258\)"](#)
  - "Network Camera Integration" - ["Event Tone \(for IX-MV7-\\*\) \(→page 263\)"](#)
  - "Network Camera Integration" - ["Event Tone \(for IX-MV\) \(→page 264\)"](#)
  - "Paging Settings" - ["Paging Pretone \(→page 267\)"](#)
  - "Communication Audio Messages" - "Start Communication" - ["Message \(→page 302\)"](#)
  - "Communication Audio Messages" - "Code Received" - ["Message \(→page 303\)"](#)
  - "Chime" - "Weekly Schedule" - ["Chime \(→page 305\)"](#)
  - "Chime" - "Daily Schedule" - ["Chime \(→page 307\)"](#)
  - "Speed Dials / Favorites" - "Group Message Page" - ["How to configure Group Message Page \(for IX-MV7-\\*\) \(→page 340\)"](#)
  - "Speed Dials / Favorites" - "All Message Page" - ["How to configure All Message Page \(for IX-MV7-\\*\) \(→page 342\)"](#)
  - "Volume / Tone" - ["Communication Timeout Notification \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 349\)"](#)
  - "Volume / Tone" - ["Communication End Pretone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 350\)"](#)
  - "Volume / Tone" - ["Call Queue Notification \(for IX-MV7-\\*\) \(→page 350\)"](#)
  - "Volume / Tone" - ["Paging Pretone \(for IX-MV7-\\* and IX-MV\) \(→page 351\)"](#)
  - "Volume / Tone" - ["Auto Answer Tone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 351\)"](#)
  - "Volume / Tone" - ["On Hold \(for IX-MV7-\\*\) \(→page 352\)"](#)
  - "Volume / Tone" - ["Key Received \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, IX-SS\(-\\*\)\) \(→page 352\)"](#)
  - "Volume / Tone" - ["Error \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 353\)"](#)
  - "Communication" - ["Communication Start Tone \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 356\)"](#)
  - "Monitor" - ["Monitored Notification \(except IX-MV7-\\* and IX-MV\) \(→page 359\)"](#)

## ■ Audio RTP Transmission Interval [msec]

Description	Set the Audio RTP Transmission Interval.
Settings	20, 40, 60, 80, 100 msec
Default values	20 msec

**■ RTP Idle Detection Time [sec]◆**

Description	Set the time to detect RTP idle state for Audio. When Audio RTP is not received during communication, monitoring, or receiving a page, connection will be disconnected after the set time.
Settings	10 - 180 sec (by 1 sec)
Default values	10 sec

**■ Audio 1 RTP Start Port◆**

Description	Set the range of port numbers to transmit and receive Audio RTP, such as communication between IX systems. Set the difference to 210 or greater in the range of (Audio 1 RTP Start Port) - (Audio 1 RTP End Port).
Settings	1 - 65534
Default values	20000

**■ Audio 1 RTP End Port◆**

Description	Set the range of port numbers to transmit and receive Audio RTP, such as communication between IX systems. Set the difference to 210 or greater in the range of (Audio 1 RTP Start Port) - (Audio 1 RTP End Port).
Settings	1 - 65535
Default values	21000

**■ Audio 2 RTP Start Port◆**

Description	Set the range of port numbers to transmit and receive Audio RTP using ONVIF. Set the difference to 10 or greater in the range of (Audio 2 RTP Start Port) - (Audio 2 RTP End Port).
Settings	1 - 65534
Default values	22000

**■ Audio 2 RTP End Port◆**

Description	Set the range of port numbers to transmit and receive Audio RTP using ONVIF. Set the difference to 10 or greater in the range of (Audio 2 RTP Start Port) - (Audio 2 RTP End Port).
Settings	1 - 65535
Default values	23000

**2.6.1 Audio Buffer****■ Packets Buffered at Audio Start**

Description	Set the number of packets to accumulate before playing audio.
Settings	0 - 4
Default values	1

**Maximum Packets Buffered**

Description	Set the maximum number of packets that can be accumulated. If a packet is received beyond the set value, it is removed from the oldest packet. It should be greater than the number of <a href="#">“Packets Buffered at Audio Start (→page 202)”</a> .
Settings	2 - 10
Default values	3

## 2.7 Packet Priority

Configure the Packet Priority and VLAN for audio, video, and SIP packets.

### ! Important

- When a setting related to VLAN is updated at a station, it will restart. In some cases, it may take around 10 minutes for the station to start up.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a configuration interface with a navigation panel at the top and a table below. The navigation panel includes a 'Row' label, 'Previous' and 'Next' buttons, an 'Enter Number' input field, and a 'Display' button. Below the navigation panel, there is a note: 'Number of Notes: 1. Changing VLAN settings will cause station to restart after Update is clicked. This will take a few minutes.' The table below is titled 'Station Information' and 'Network Settings'. It has columns for '#', 'Number', 'Name', 'Location', 'Station Type', 'TOS Value (Audio)', 'TOS Value (Video)', 'TOS Value (SIP)', 'VLAN Setting', 'VLAN ID', and 'VLAN Priority'. The table contains three rows of data for stations 0001, 0002, and 0003.

#	Station Information Identification				Network Settings Packet Priority					
	Number	Name	Location	Station Type	TOS Value (Audio)	TOS Value (Video)	TOS Value (SIP)	VLAN Setting	VLAN ID	VLAN Priority
0001	0001	Master Stations1		IX-MV7-*	0x00	0x00	0x00	Disable	1	0
0002	0002	Master Stations2		IX-MV7-*	0x00	0x00	0x00	Disable	1	0
0003	0003	Master Stations3		IX-MV7-*	0x00	0x00	0x00	Disable	1	0

### ■ TOS Value (Audio) (except IXW-MA) ◆

Description	Set the Packet Priority (TOS Value) for Audio.
Settings	0x00 - 0xFF
Default values	0x00

### ■ TOS Value (Video) (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))◆

Description	Set the Packet Priority (TOS Value) for Video.
Settings	0x00 - 0xFF
Default values	0x00

### ■ TOS Value (SIP) (except IXW-MA) ◆

Description	Set the Packet Priority (TOS Value) for SIP.
Settings	0x00 - 0xFF
Default values	0x00

### ■ VLAN Setting

Description	Select Enable / Disable for tagged VLAN.
Settings	<ul style="list-style-type: none"> <li>Enable</li> <li>Disable</li> </ul>
Default values	Disable

**! Important**

- When "VLAN Setting" is set to "Enable" and uploaded to the station, ensure that the switches, PCs, and stations are all configured for VLAN operation.

**■ VLAN ID◆**

Description	Set the VLAN ID.
Settings	1 - 4094
Default values	1

**■ VLAN Priority**

Description	Set the VLAN priority.
Settings	0 (low) - 7 (high)
Default values	0

## 2.8 NTP

Configure NTP settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a control panel at the top with a 'Row' label, an 'Enter Number' input field, and 'Previous', 'Next', and 'Display' buttons. Below this is a table with two main sections: 'Station Information' and 'Network Settings'. The 'Station Information' section includes columns for '#', 'Number', 'Name', 'Location', and 'Station Type'. The 'Network Settings' section includes 'Enable NTP', 'Synchronization Interval [hour]', and 'Primary Server' (with sub-columns for 'Address' (IPv4, IPv6) and 'Port'). A red box highlights the 'Row' control panel and the 'Synchronization Interval' column in the table. A red note at the top right of the table says 'Text in red are required settings.'

Station Information					Network Settings				
#	Identification				NTP				
	Number	Name	Location	Station Type	Enable NTP	Synchronization Interval [hour]	Primary Server		
						Address		Port	
						IPv4	IPv6		
0001	0001	Master Stations 1		IX-MV7-*	No Use			24	123
0002	0002	Master Stations2		IX-MV7-*	No Use			24	123
0003	0003	Master Stations3		IX-MV7-*	No Use			24	123

### 2.8.1 Enable NTP

Description	Select Yes / No Use to synchronize the time with an NTP server. If this is set to "Yes," be sure to configure the other subcategories in <a href="#">"NTP (→page 206)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No Use</li> </ul>
Default values	No Use

### 2.8.2 Synchronization Interval [hour]◆

Description	Set the interval to synchronize with the NTP server.
Settings	1-255 hours (by 1 hour)
Default values	24 hour

### 2.8.3 Primary Server

#### ■ Address IPv4

Description	Set the IPv4 address for NTP Primary Server. Go to <a href="#">"DNS (→page 185)"</a> to set hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

## ■ Address IPv6

Description	Set the IPv6 address for NTP Primary Server. Go to <a href="#">“DNS (→page 185)”</a> to set hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

## ■ Port◆

Description	Set the port number for NTP.
Settings	1 - 65535
Default values	123

---

## 2.8.4 Secondary Server

---

## ■ Address IPv4

Description	Set the IPv4 address for NTP Secondary Server. Go to <a href="#">“DNS (→page 185)”</a> to set hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

## ■ Address IPv6

Description	Set the IPv6 address for NTP Secondary Server. Go to <a href="#">“DNS (→page 185)”</a> to set hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

## ■ Port◆

Description	Set the port number for NTP.
Settings	1 - 65535
Default values	123

## 3. System Information

### 3.1 Location Registry (for IX-MV7-\* and IX-MV)


Register a location.

For how to register a location, refer to [“Register location \(except IXW-MA\) \(→page 174\)”](#).

### 3.2 Address Book (for IX-MV7-\* and IX-MV)

Configure the IX-MV7-\* and IX-MV Address Book.

Calling, paging, monitoring, line monitoring, and malfunction monitoring can be performed for any station registered in the Address Book. Network cameras can be monitored and outgoing calls can be made to VoIP phones.



#### ! Important

- Always configure [“Language \(→page 158\)”](#) before setting "Address Book."
- Enter the language configured in [“Language \(→page 158\)”](#). However, if the language (configured on the station main unit) displayed on the screen for IX-MV7-\* or IX-MV is different from that set in [“Language \(→page 158\)”](#), the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.

### 3.2.1 Station List

Register the stations in the Address Book.  
Click **[Open Station List]**. The following window will be shown.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]**: Display the previous 50 rows.  
**[Next]**: Display the next 50 rows.  
**[Display]**: Enter the station number and click **[Display]** to move the cursor to the entered row.

**Move column**

Up to 50 station number lines can be displayed at a time. Switch the display as follows.  
**[Previous]**: Display the previous 50 columns.  
**[Next]**: Display the next 50 columns.  
**[Display]**: Enter the station number and click **[Display]** to move the cursor to the entered column.

**VoIP Phone Registration** (→page 211)  
Register the VoIP phone in the Address Book.

The screenshot shows the 'Station List' interface. At the top, there are 'Row' and 'Column' navigation controls, each with 'Previous', 'Next', and 'Display' buttons. A 'VoIP Phone Registration' button is also visible. Below these is a note: 'Number of Notes: 1 1. To register a VoIP Phone, go to Network Settings -> SIP and enter the IP address of the SIP Primary Server.' The main area contains two tables. The left table, 'Station Information', lists stations 0001 to 0008 with their names and types (IX-MV7-\* or IX-MV). The right table, 'Address Book', shows columns for 'Master Stations1 / IX-MV7-\*' and 'Master Stations2 / IX-MV7-\*', with 'Select' and 'Network Camera' sub-columns. Red boxes highlight the 'Network camera selection' buttons in the Address Book table, with a red arrow pointing to one of them. A red dashed line is drawn around row 0004 in the Station Information table.

List of IX-MV7-\*, IX-MV in the Settings data

If a network camera has not been registered in ["Open Network Camera List \(→page 212\)"](#), this will not be shown.


List of stations that can be registered to the Address Book

**! Important**

- Stations where ["IP Address \(→page 180\)"](#) is not configured cannot be registered to the Address Book.
- To access stations registered to the Address Book by hostname, configure "IP Address" - ["Hostname \(except IX-MV, IX-DA, IX-DF\(-\\*\), or IX-BA, IX-SS\(-\\*\)\) \(→page 180\)"](#) and ["DNS \(→page 185\)"](#).
- Results when searching by station will be listed in order of station number.

**How to create Station List**

1. VoIP phones are registered in ["VoIP Phone Registration \(→page 227\)"](#).
2. Identify the station to be configured using "List of IX-MV7-\* and IX-MV in the Settings data."
3. Identify the station to be registered in the Address Book using "List of stations that can be registered to the Address Book."
4. Click cells ("Select" and "Network Camera") that correspond to Steps 1 and 2.
  - Select: Register stations in which "✓" has been selected to the Address Book. For IX stations, stations for which "SIP" was selected will be registered to the Address Book as VoIP phones. By default, "✓ (register)" is set for all.
  - Network Camera (for IX-MV7-\*): Click **[Network camera selection]** and then select the network camera to associate. Network cameras configured in ["Open Network Camera List \(→page 212\)"](#) can be selected. The number of the selected network camera will be displayed. If a network camera is associated with a station, the video from the network camera will be displayed when placing a call, during a communication, or when monitoring.




5. When done, click **[Update]**.
6. Click **[OK]**.

### 3.2.1.1 VoIP Phone Registration

Register the VoIP phone to the Address Book. When registering a VoIP phone, be sure to also configure [“SIP \(except IXW-MA\) \(→page 186\)”](#).

On the "Address Book" screen, click **[VoIP Phone Registration]**. The following window will be shown.

[“Register location \(except IXW-MA\) \(→page 174\)”](#)



#### How to perform VoIP Phone Registration

1. In the "Station List," enter the "Number♦," "Name," and "Location."
  - Number: 3-32 digits
  - Name: 1-24 alphanumeric characters
  - Location: Select a location registered in [“Register location \(except IXW-MA\) \(→page 174\)”](#).
2. Click **[Update]**.
  - Click **[Cancel]** to close the "Address Book" screen without registering a VoIP phone.
  - The registered VoIP phone will be displayed at the end of the Address Book.

### 3.2.2 Open Network Camera List

IX-MV7-\* and IX-MV support the ONVIF interface standard "ONVIF profile S." Video and audio of 3rd party network camera can be monitored on the IX-MV7-\*, IX-MV screen. Register the network camera in the Address Book. Up to 500 network cameras can be registered. Configure [“Network Camera Integration \(for IX-MV7-\\* and IX-MV\) \(→page 261\)”](#) to configure event notification-related settings for the network camera. Click **[Open Network Camera List]**. The following window will be shown.

**Move row**  
 Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

[“Network Camera Registry \(→page 213\)”](#)

List of network cameras that can be registered to the Address Book

Row

[Related Settings]

#	Station Information			Station Type	Available Network Camera(s)		
	Identification				001		
	Number	Name	Location		Select	PTZ Operation	Audio Monitoring
0001	0001	Master Stations 1		IX-MV7-*	<input checked="" type="checkbox"/>	Enable	Enable
0002	0002	Master Stations 2		IX-MV7-* 1	<input checked="" type="checkbox"/>	Enable 3	Enable
0003	0003	Master Stations 3		IX-MV7-*	<input checked="" type="checkbox"/>	Enable	Enable
0004	0004	Master Stations 4		IX-MV7-*	<input checked="" type="checkbox"/>	Enable	Enable
0005	0005	Master Stations 5		IX-MV7-*	<input checked="" type="checkbox"/>	Enable	Enable
0006	0006	Master Stations 6		IX-MV	<input checked="" type="checkbox"/>		
0007	0007	Master Stations 7		IX-MV	<input checked="" type="checkbox"/>		

List of IX-MV7-\* and IX-MV in Settings data

If no network camera is registered, this will not be shown.

### How to create Network Camera List

1. Register the network camera in ["Network Camera Registry \(→page 213\)"](#).
2. Identify the station to be configured using "List of IX-MV7-\* and IX-MV in Settings data."
3. Identify the network camera to be registered in the Address Book using "List of network cameras that can be registered to the Address Book."
4. Click the cells ("Select," "PTZ Operation," and "Audio Monitoring") that correspond to Steps 2 and 3.
  - Select: Register network cameras with "✓" selected to the Address Book. All items are "blank (unregistered)" by default.
  - PTZ Operation (for IX-MV7-\*): Configure whether to allow network camera PTZ operation from the station. All items are set to "Yes" by default.
  - Audio Monitoring (for IX-MV7-\*): Configure whether to allow monitoring of network camera audio from the station. All items are set to "Enable" by default.



#### Note

- "PTZ Operation" and "Audio Monitoring" are set to "Enable" for IX-MV and cannot be changed.

5. When done, click **[Update]**.
6. Click **[OK]**.

#### 3.2.2.1 Network Camera Registry

Click **[Open Network Camera Registry]**. The following screen will be shown.

["How to register a new network camera \(→page 215\)"](#)

Select the network camera(s) to be deleted (multiple selections allowed), and click to delete.

[Related Settings]

Add Camera    Delete

Number of Notes: 1    1. To add a network camera, one or more stations must be associated and cameras need to be connected to the network.

Station Information		Network Settings			Function Settings		
Select	#	Camera Name	Hostname	IP Address (IPv4)	IP Address (IPv6)	ID	Password
<input checked="" type="checkbox"/>	001	XXXXXXXXXX		192.168.1.205		XXXXXX	***
<input type="checkbox"/>	002	XXXXXXXXXX		192.168.1.200		XXXXXX	*****

Text in red are required settings.

If no network camera is registered, this will not be shown.



#### Important

- Network camera registration is configured via ["Association Settings \(→page 160\)"](#) on at least one IX-MV7-\* or IX-MV station, and cannot be configured if the PC cannot communicate with the system (this is because, when registering a network camera, the network camera is searched through IX-MV7-\* or IX-MV).

**Note**

- When searching on the station, the numbers will be displayed in the order they were registered.

**■ Camera Name◆**

Description	Set the Network Camera Name.
Settings	1-24 alphanumeric characters
Default values	-

**■ Hostname**

Description	Set the hostname. Go to <a href="#">"DNS (→page 185)"</a> to set Hostname.
Settings	1-64 alphanumeric characters
Default values	-

**■ IP Address (IPv4)**

Description	Set the IPv4 address for Network camera.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

**■ IP Address (IPv6)**

Description	Set the IPv6 address for Network camera.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

**■ ID◆**

Description	Enter ID of the network camera.
Settings	1-32 alphanumeric characters
Default values	-

**■ Password◆**

Description	Enter Password of the network camera.
Settings	1-32 alphanumeric characters
Default values	-

**Note**

- "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

## How to register a new network camera

Registration cannot be performed if the PC is not connected to the same network as the network camera.

Click **[Add Camera]** to search for a network camera (searching may take several minutes).

When searching is done, the "Network Camera Selection" screen will be shown, and the network cameras connected in the network will be shown in the "Network Camera Search List."

1. Select the network camera to be registered

Manual Network Camera Configuration

IP Address ◆  
ID ◆  
Password ◆

2. Select from Network Camera Search List

Search  
Search Timeout: 60 Second

Select	Manufacturer	Model Number	Hostname	IP Address	ID	Password
<input checked="" type="checkbox"/>				192.168.1.200	root	*****
<input type="checkbox"/>				192.168.1.205		

3. Select the Network Camera Profile to be used

Get Network Camera Information

Select	Manufacturer	Model Number	Hostname	IP Address	Profile
<input checked="" type="checkbox"/>				192.168.1.200	
<input type="checkbox"/>				192.168.1.200	

4. Register

5. Cancel

Text in red are required settings.

If the video profile cannot be obtained, nothing will be shown.

- To search by specifying an IP address, select "Manual Network Camera Configuration," and enter the "IP Address◆," "ID◆," and "Password ◆" of the network camera.
- To select from the Network Camera Search List, select "Select from Network Camera Search List." Select the network camera(s) to register from the "Network Camera Search List" (multiple selections allowed), and then enter the "Hostname," "ID◆," and "Password◆." When entering the Hostname, configure ["DNS \(→page 185\)"](#). To search again, click **[Search]**. It is also possible change the search time.
- Click **[Get Network Camera Information]**. (Obtaining the video profile may take several minutes.) When video profiles are successfully obtained, they will be shown in "Network Camera Information."
- Choose the video profile(s) to be registered from the list (multiple selections allowed).

5. Click **[Register]** to register a network camera.
6. When done, click **[Update]**.
7. Click **[OK]**.

### 3.3 Group (for Master) (for IX-MV7-\* and IX-MV)

Configure the group for groups calls, group pages, and contact input calls.  
Up to 50 groups per station (50 stations per group) can be registered.  
Stations other than IXW-MA can be registered to groups.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

#### Move column

Up to 50 station number lines can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered column.

**Row** Previous Next

Enter Number Display

**Column** Previous Next

Enter Number Display

[Display Settings]  
Group Number  
01

Number of Notes: 1 1. Only one VoIP phone can be set per group. "M" cannot be set for VoIP phone. If designating "M", a multicast IP Addresses must be configured by "Network Setting -> Multicast Address".

Create Group from Location(s)

U = Unicast, M = Multicast  
If designating "M", multicast IP addresses must be configured for the station(s).

#	Station Information				System Information				Syst Text in red are required settings.
	Identification				Group (for Master)				Group (for Master)
	Number	Name	Location	Station Type	Group Number	Group Name	Type	Total	NumberName/Station Type
0001	0001	Master Stations1		IX-MV7-*			Audio Protocol	0	0001 / Master Stations1 / IX-MV7-*
							Video Protocol	0	
0002	0002	Master Stations2		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0003	0003	Master Stations3		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0004	0004	Master Stations4		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0005	0005	Master Stations5		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	

### ! Important

- Always configure "[Language \(→page 158\)](#)" before setting "Group (for Master)."
- Enter the language configured in "[Language \(→page 158\)](#)". However, if the language (configured on the station main unit) displayed on the screen for IX-MV7-\* or IX-MV is different from that set in "[Language \(→page 158\)](#)", the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.
- Only a single VoIP Phone can be registered to each group.
- All pages, groups pages, message pages, and external input pages cannot be sent to VoIP Phones.
- Stations "[IP Address \(→page 180\)](#)" has not been configured and that have not been registered in "[Address Book \(for IX-MV7-\\* and IX-MV\) \(→page 208\)](#)" cannot be registered to groups.
- Groups calls and calls by Option Input cannot be made to IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*).
- Groups calls and calls by Option Input cannot be made from IX-MV to IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*.
- Results when searching by station will be listed in order of group number.

### 3.3.1 Configuring a Group

#### How to configure individual settings

Configure the group to register in each station.

["How to Create Group from Location\(s\) \(→page 219\)"](#)

U = Unicast, M = Multicast  
If designating "M", multicast IP addresses must be configured for the station(s).

Station Information				System Information				System Information	
Identification				Group (for Master)				Group (for Master)	
#	Number	Name	Location	Station Type	Group Number	Group Name	Type	Total	Number/Name/Station Type
					01				0001 / Master Stations 1 / IX-MV7-*
0001	0001	Master Stations1		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0002	0002	Master Stations2		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0003	0003	Master Stations3		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	
0004	0004	Master Stations4		IX-MV7-*			Audio Protocol	0	
							Video Protocol	0	

List of IX-MV7-\* and IX-MV in Settings data      Group Information      List of stations that can be registered to group

1. Select the group to be configured from "Display Settings."  
The Settings screen for the selected group will be shown on the screen.
  2. Enter the following information in "Group Information."
    - Group Number: 01 - 99  
Group numbers must be unique.
    - Group Name: 1 - 24 alphanumeric characters
  3. Identify the station to be configured using "List of IX-MV7-\* and IX-MV in Settings data."
  4. Identify the station to be registered from the "list of stations that can be registered to group."
  5. Click the cells that correspond to Steps 3 and 4. Select an audio protocol and video protocol setting value for each, and register to a group.  
The number of registered stations will be shown in "Total."
- Audio Protocol**
- Blank: Select to not register to a group.
  - U: Belongs to group. Paging audio is transmitted in unicast.
  - M: Belongs to group. Paging audio is transmitted in multicast.
- Video Protocol (only when IX-MV7-\* is both the station to configure and register)**
- Blank: Video will be transmitted as multicast.
  - U: Video will be transmitted as unicast during group calls. Unicast can be used to send video to up to 20 stations.
  - M: Video will be transmitted as multicast during group calls.

The Video Protocol pull-down menu is shown when the Audio Protocol setting is selected.  
All items are blank by default.

6. When done, click **[Update]**.

7. Click **[OK]**.

**! Important**

- If "M" is selected or "blank" is selected for the Video Protocol, be sure to configure ["Multicast Address \(For IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)" \(→page 190\)](#).
- For VoIP phones or stations in which "SIP" was selected in ["Station List \(→page 209\)"](#) or ["Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)"](#), "M" cannot be selected.


**💡 Note**

- When making a group call, the Audio Protocol will be set to "U" and cannot be changed.

**How to Create Group from Location(s)**

Groups are automatically created for each location.

Click **[Create Group from Location(s)]**. The following window will be shown.



The locations registered in ["Register location \(except IXW-MA\) \(→page 174\)"](#) will be shown.

1. Select the location(s) for which a group is to be created.

2. Select "Group Number♦."

- 01 - 99

Select a unique value.

**3.** Click **[OK]**.

A group will be registered for all configured Location in the selected location and group number. The location is shown in the group name.

- Click **[Cancel]** to return to the "Group" screen without creating a group.

**4.** Click **[OK]**.

**!** Important

- Registration cannot be performed by selecting only a single station.
- Video Protocol and Audio Protocol settings are all set to "U" by default. To change them to "M," they must be changed individually.
- Performing Steps 1 and 4 again will overwrite with new settings.
- A group cannot be created from a location with 50 or more stations registered.

### 3.4 Custom Sound Registry (except IXW-MA)

Register audio files to be used for ringback tones, ringtones, message paging, etc. The numbers of audio files that can be registered to each station are as follows.

Station Type	Information that can be saved to the station
IX-MV7-*	Max. 100 files (with 200 seconds and 8 Mbytes per file)
IX-MV	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-DA, IX-DF(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-DV, IX-DVF(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-SSA(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-SS-2G	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-BA, IX-SS(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-RS-*	Max. 100 files (total length of within 200 seconds and 8 Mbytes)

Supported file format

- File Type: .wav
- Sample Size: 16 bits
- Sample Rate: 8 kHz (if ["Audio Codec \(→page 200\)"](#) is "G.711 (μ-Law)" or "G.711 (A-Law)"), 16 kHz (if ["Audio Codec \(→page 200\)"](#) is "G.722")
- Channel: 1 (monaural)
- File Name: 1-82 alphanumeric characters (without file extensions)

For IX-MV7-\*, enter either a letter or number as the first character. Audio files for message paging will be searched by a letter or number when paging.

Note

- If using a file for a ringback tone, ringtone, or network camera event tone, add a period of silence in the .wav file if the tone is to be intermittent.
- Sample files of custom tones are provided on our website (<https://www.aiphone.net/product/>) for download and use as audio sources.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

["How to register multiple custom tones at once \(→page 223\)"](#)

The screenshot shows the 'Custom Sound Registry' interface. At the top, there are navigation buttons: 'Row', 'Previous', 'Next', and 'Display'. Below these is a text input field for 'Enter Number'. A red box highlights the 'Row' button and the 'Display' button. A red line connects this box to the 'Move row' section above. Below the navigation controls, there are two columns for '0001' and '0002'. Each column has a 'Name' field, a 'Browse for .wav file' button, and a 'Delete' checkbox. The table below shows five rows of station information, with the first row (0001) highlighted in orange. The table has columns for '#', 'Number', 'Name', 'Location', and 'Station Type'. The first row is: 0001, 0001, Master Stations 1, IX-MV7-\*. The second row is: 0002, 0002, Master Stations2, IX-MV7-\*. The third row is: 0003, 0003, Master Stations3, IX-MV7-\*. The fourth row is: 0004, 0004, Master Stations4, IX-MV7-\*. The fifth row is: 0005, 0005, Master Stations5, IX-MV7-\*. At the bottom right of the table, there is a note: 'Text in red are required settings.'

**How to register an audio file**

- 1.** Click **[Browse]** at the end of the row for the station in which the file is to be registered.
- 2.** Select the audio file to register, and click **[Open]**.
- 3.** Information on the selected audio file will be shown.
  - Name: Shows the file name of the audio file. Up to 24 alphanumeric characters will be shown. The name will be shown as the setting value when configuring the ringback tone etc. If the file name of the audio file exceeds the character limit above, it will only partially be shown.
  - File attachment: The audio file reference destination is shown.
- 4.** When done, click **[Update]**.
- 5.** Click **[OK]**.

**How to delete a custom tone**

- 1.** Check the **[Delete]** box of the audio file to delete.
- 2.** Click **[Update]**.
- 3.** Click **[OK]**.

**Note**

- "Name" can be deleted from the Settings screen by selecting "[Upload Settings To Station \(→page 145\)](#)" - "Sounds" to upload the setting file, and then deleting the audio file from the station.

## How to register multiple custom tones at once

Audio files can be registered to multiple stations at once.

Click "Custom Sound Registration." The following screen will be shown.

1 Choose the file to be uploaded to the selected station(s).

2 Enter Custom Sound Number to register.

3 Select the station to register the custom sound.

Station List				
Select	Number	Name	Location	Station Type
<input checked="" type="checkbox"/>	0001	Master Stations 1		IX-MV7-*
<input type="checkbox"/>	0002	Master Stations 2		IX-MV7-*
<input type="checkbox"/>	0003	Master Stations 3		IX-MV7-*
<input type="checkbox"/>	0004	Master Stations 4		IX-MV7-*
<input type="checkbox"/>	0005	Master Stations 5		IX-MV7-*
<input type="checkbox"/>	0006	Master Stations 6		IX-MV
<input type="checkbox"/>	0007	Master Stations 7		IX-MV
<input type="checkbox"/>	0008	Master Stations 8		IX-MV
<input type="checkbox"/>	0009	Master Stations 9		IX-MV
<input type="checkbox"/>	0010	Master Stations 10		IX-MV

Select Station by Type:

4

1. Click **[Browse]**, select the audio file to register, and then click **[Open]**.
2. Enter the number of the custom tone to register the audio file.
  - 1 - 100
3. Select the station(s) to register the audio file from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
4. Click **[Add]**.
  - Click **[Cancel]** to quit without registering multiple files.
5. Information on the added audio file will be shown.
  - Name: Shows the file name of the audio file. Up to 24 alphanumeric characters will be shown. The Name will be shown when configuring the ringback tone etc. If the file name of the audio file exceeds the character limit above, it will only partially be shown.
  - Browse for .wav file: The audio file reference destination is shown.
6. When done, click **[Update]**.
7. Click **[OK]**.

## 4. Call Settings

### 4.1 Station Information (for IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G)

Configure the call button function.


#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.



#	Station Information				Call Settings
	Identification				Station Information
	Number	Name	Location	Station Type	Call Button Function
0011	0011	Video Stations1		IX-DV, IX-DVF(-*)	Call
0012	0012	Video Stations2		IX-DV, IX-DVF(-*)	Call
0013	0013	Video Stations3		IX-DV, IX-DVF(-*)	Call
0014	0014	Video Stations4		IX-DV, IX-DVF(-*)	Call
0015	0015	Video Stations5		IX-DV, IX-DVF(-*)	Call
0021	0021	Audio Stations1		IX-SSA(-*)	Call
0022	0022	Audio Stations2		IX-SSA(-*)	Call

#### ■ Call Button Function

Description	Select the Call Button Function when call button is pressed (for IX-RS-*: Call/Talk button).
Settings	<ul style="list-style-type: none"> <li>• Call: Outgoing call</li> <li>• Call, Cancel Call, End Communication: Out going call, Cancel outgoing call, End Communication</li> <li>• Call, Answer Call, End Communication: Outgoing call, Answer call or page, End communication</li> </ul>
Default values	Call



#### Note

- Contact input calls and communication switched from a contact input call cannot be ended by pressing the call button (IX-RS-\*: Call button).

### 4.2 Called Stations (Master Stations) (for IX-MV7-\* and IX-MV)

A call destination does not have to be set up. Any intercom station registered in [“Address Book \(for IX-MV7-\\* and IX-MV\) \(→page 208\)”](#) can be called.

### 4.3 Called Stations (Door/Sub Stations) (except IX-MV7-\*, IX-MV, and IXW-MA)

Configure the group to call when a call is made using the call button or via contact input.

- Stations other than IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*): Up to 20 stations can be configured in a single group, and up to 10 groups can be configured.
- IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*) (for placing a Call Button call): Up to 20 stations can be configured in a single group, and only a single group can be configured.
- IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*) (for placing a Option Input call): Up to 20 stations can be configured in a single group, and up to nine groups can be configured.

Any station other than IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), IXW-MA can be registered as a call recipient.

#### ! Important

- An IX-RS, IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) must be registered under Called Stations (Door/Sub Stations) to use Door Release while in communication with IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*). An IX-RS cannot place a call to IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) even IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) is under Called Stations (Door/Sub Stations.)

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

#### Move column

Up to 50 station number lines can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered column.

#### VoIP Phone

**Registration** (→ [page 211](#))

Register the VoIP phone as a call recipient.

List of IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*) in setting data

## ! Important

- Stations in which ["IP Address \(→page 180\)"](#) is not configured cannot be registered as destinations.
- If the station registered to the call destination is anything other than IX-MV7-\* or IX-MV, one of the following must be configured to receive incoming calls.
  - Set to "Call, Answer Call, End Communication" in ["Call Button Function \(→page 224\)"](#).
  - Set to "Answer Call / Page" in "Option Input" - ["Function \(→page 242\)"](#).
- Do not register the same station multiple times within a group.
- Only one VoIP phone can be registered to each group.

### How to configure destinations (Door/Sub Stations)

1. Select the group to configure from "Display Settings."
  - The Settings screen for the selected group will be displayed.
  - Use the following groups when configuring IX-DA, IX-DF(\*), IX-BA, and IX-SS(\*).
    - Groups used to place a call by operating the call button: "Group number 10"
    - Groups used to place a call by Option Input: "Group number 01 - 09"
2. Search for a station to configure from the "list of IX-RS-\*, IX-DV, IX-DVF(\*), IX-SSA(\*), IX-DA, IX-DF(\*), IX-BA, IX-SS(\*)" in setting data."
3. Search for the station to be registered from the "list of stations that can be registered to group."
4. Click the cells that correspond to Steps 2 and 3. Select the settings and register the station to the group.
  - The number of registered stations will be shown in "Total."
    - Blank: The selected station will not be registered.
    - U: The station will be registered in the call destination. An outgoing call is transmitted as unicast.
    - M: Station will be registered in the call destination. Video is transmitted as multicast for an outgoing call. Station must be IX-DV, IX-DVF(\*), IX-DA, or IX-DF(\*), and the call destination must be IX-MV7-\* or IX-MV.
    - SIP: Select this to call an IX station as a VoIP phone.
  - For group number 01 for stations other than IX-DA, IX-DF(\*), IX-BA or IX-SS(\*) and group number 10 for IX-DA, IX-DF(\*), IX-BA, or IX-SS(\*), all IX-MV7-\* or IX-MV stations in the "list of stations that can be registered to group" with station numbers in order from 1 to 20 will be set to "U".
5. When done, click **[Update]**.
6. Click **[OK]**.


## ! Important

- If "M" is selected, be sure to configure ["Multicast Address \(For IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(\\*\), IX-DA, IX-DF\(\\*\)\) \(→page 190\)"](#).

### 4.3.1 VoIP Phone Registration

Register the VoIP phone in Called Stations (Door/Sub Stations). When registering a VoIP phone, be sure to configure ["SIP \(except IXW-MA\) \(→page 186\)"](#).

On the "Called Stations (Door/Sub Stations)" screen, click **[VoIP Phone Registration]**. The following window will be shown.



#### How to perform VoIP Phone Registration

1. In the "Station List," enter the "Number♦," "Name," and "Location."
  - Number: 3-32 digits
  - Name: 1-24 alphanumeric characters
  - Location: Select a location registered in ["Register location \(except IXW-MA\) \(→page 174\)"](#).
2. Click **[Update]**.
  - Click **[Cancel]** to close the "VoIP Phone Registration" screen without registering a VoIP phone.
  - The registered VoIP phone will be displayed at the end of the Address Book.

## 4.4 Call Origination (except IXW-MA)

Configure outgoing call settings.

Select the call method to configure in **[Display Settings]**.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Display Settings

Displays settings for the selected outgoing call method.

**[Call Button]** (except IX-MV): Displays settings related to outgoing calls linked that placed by the call button or the bathroom link.

**[Option Input 1 - 6]:** Displays settings related to outgoing calls when "Call" is selected for "Option Input" - ["Function \(→page 242\)"](#).

["Weekly Schedule \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 232\)"](#)

["Daily Schedule \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 234\)"](#)

**Move to Related Settings**  
Moves to the selected item within the same Settings screen.

The screenshot shows the 'Call Origination' settings screen. At the top, there are navigation buttons: 'Row' (with 'Previous', 'Next', and 'Display' sub-buttons), 'Display Settings' (set to 'Call Button'), 'Weekly Schedule', 'Daily Schedule', 'Display Range' (set to 1-3), and 'Move to Related Settings' (set to 'Call Method'). Below these are two notes: '1. IX-SPMIC can only be set to "Call Button" for Call Origination settings' and '2. The schedule is automatically sorted by Start Time after updating.' The main table has columns for Station Information (Number, Name, Location, Station Type) and Call Settings (Call Method, Ringback Tone, Call Timeout, Ringback Tone Count, Standard Mode Settings, Destination Dw). The first row (0001) is highlighted in orange and shows 'Master Stations 1' with station type 'IX-MV7-\*' and call settings for 'Call Pattern 4'.

### 4.4.1 Call Origination Advanced Settings

#### ■ Call Method (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the Call Method to change call destinations automatically by time delay or schedule.
Settings	<ul style="list-style-type: none"> <li>Standard Destination: Do not change call destination automatically. IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are fixed to "Standard Destination" and cannot be changed.</li> <li>Change Destination by Time Delay: Change destination group from <a href="#">"Destination Dwell 1 - 8 (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*)) (→page 230)"</a> after <a href="#">"Destination Dwell Time (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*)) (→page 231)"</a>. Up to 8 groups can be used.</li> <li>Change Destination by Schedule: Change destination group by <a href="#">"Weekly Schedule (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 232)"</a> and <a href="#">"Daily Schedule (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 234)"</a>.</li> </ul>
Default values	Standard Destination

## ■ Ringback Tone (except IX-MV)

Description	Select the sound to be played by the station when placing a call. For IX-MV7-*, this will also sound when monitoring.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	<p>Call Button</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• Except IX-MV7-*: Call Pattern 1</li> </ul> <p>Option Input 1</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• Except IX-MV7-*: Call Pattern 2</li> </ul> <p>Option Input 2</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 3</li> </ul> <p>Option Input 3</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 4</li> </ul> <p>Option Input 4</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 5</li> </ul> <p>Option Input 5</p> <ul style="list-style-type: none"> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 6</li> </ul> <p>Option Input 6</p> <ul style="list-style-type: none"> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Tremolo Sound</li> </ul>

## ■ Call Timeout (except [Call Button] - IX-MV)◆

Description	Configure the Call Timeout for outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep calling until call is answered</li> <li>• 10-600sec: Select to set between 10-600 sec (by 1 sec)</li> </ul>
Default values	60sec

### Note

- For [Call Button], the outgoing call time for IX-MV is set on the station.

## ■ Ringback Tone Count [time(s)] (except [Call Button] IX-MV)

Description	Set the play count of ringback tone for outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Infinite: The ring back tone continues to play for the amount of time set in <a href="#">"Call Timeout (except [Call Button] - IX-MV)"</a> (→page 229).</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite



### Note

- For **[Call Button]**, the ringtone count for IX-MV is set on the station.

## ■ Call Destination ([Option Input 1-4] - for IX-MV7-\* and IX-MV)

Description	Configure the call destination group and call priority. Enter the group number directly, or click <b>[Open]</b> to select a group.
Settings	<ul style="list-style-type: none"> <li>• Group Number: 01 - 99. Select from groups registered in <a href="#">"Group (for Master) (for IX-MV7-* and IX-MV)"</a> (→page 217).</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Group Number: -</li> <li>• Priority: Normal</li> </ul>

## ■ Standard Mode Settings (except IX-MV7-\* and IX-MV)

Description	Select the destination group when "Standard Destination" is selected in <a href="#">"Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))"</a> (→page 228).
Settings	<ul style="list-style-type: none"> <li>• Call Destination: 01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA)"</a> (→page 225).</li> <li>The call group number for IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*) is fixed to "10" and cannot be changed for <b>[Call Button]</b>, or can be selected from "01 - 09" for <b>[Option Input 1]</b>.</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	<p>Call Button</p> <ul style="list-style-type: none"> <li>• Call Destination: 01 (10 for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Priority: Normal</li> </ul> <p>Contact input 1 - 5 call</p> <ul style="list-style-type: none"> <li>• Call Destination: - (01 for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Priority: Normal</li> </ul> <p>Option Input 6</p> <ul style="list-style-type: none"> <li>• Call Destination: 01</li> <li>• Priority: Urgent</li> </ul>

## ■ Destination Dwell 1 - 8 (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), IX-BA, or IX-SS(-\*))

Description	Configure the call priority for the call group to switch when <a href="#">"Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))"</a> (→page 228) is set to "Change Destination by Time Delay." Up to 8 groups can be configured, and it will switch between groups in order by the time configured in "Destination Dwell Time."
Settings	<ul style="list-style-type: none"> <li>• Call Destination: 01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA)"</a> (→page 225).</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Call Destination: -</li> <li>• Priority: Normal</li> </ul>

**Destination Dwell Time (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*))**◆

Description	Configure the delay time to change the call destination when "Change Destination by Time Delay" is selected in <a href="#">"Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 228)"</a> .
Settings	10-600sec / 1 sec step
Default values	30 sec

**4.4.1.1 Weekly Schedule (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Configure when [“Call Method \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 228\)”](#) is set to "Change Destination by Schedule."

Configure the switch time for the call destination, the call destination group, and the call priority each day from Sunday to Saturday. 12 schedules can be set for each day.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.


**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Weekly Schedule**

Select the day and schedule range to configure. The Settings screen is shown.

[“How to configure schedule display \(→page 233\)”](#)



**■ Start Time**

Description	Configure the time to start changing the call destination.
Settings	00:00 - 23:59
Default values	-

**■ End Time**

Description	Configure the time to stop changing the call destination. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

**■ Call Destination**


Description	Configure the call destination to change within the schedule.
Settings	01 - 10. Select from groups registered in <a href="#">“Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 225)”</a> .
Default values	-

■ Priority

Description	Configure the priority of calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

**How to configure schedule display**

Configure the day and schedule range shown on the Settings screen for the weekly schedule. The display can be filtered to show only the day and schedule to configure. Click Schedule View Adjustment. The following screen will be shown.



1. Select the day(s) to display from "Day" (multiple selections allowed).
  - To select or unselect all days at once, click **[Select]** or **[Unselect]**.
  - By default, all days are shown.
2. Select the range of schedules to display (1 - 12) that can be configured for each day of the week.
  - By default, the range of 1 - 3 is shown.
3. Click **[OK]**.
  - Click **[Cancel]** to return to the previous menu..

**4.4.1.2 Daily Schedule (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Configure when ["Call Method \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 228\)"](#) is set to "Change Destination by Schedule."

Configure the switch time for the destination, the call group, and the call priority in units of one day. A schedule one year from the set day can be configured. 12 schedules can be set for each day.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.


**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

**Daily Schedule**

Select the date and schedule range to configure. The Settings screen will be shown.

1. Select the date from the drop down menu.
2. Select the range of schedules to display (1 - 12) that can be configured for each day.
  - By default, the range of 1 - 3 is shown.
3. Click [Change to Daily Schedule Display].



**Start Time**

Description	Configure the time to start changing the call destination.
Settings	00:00 - 23:59
Default values	-

**End Time**

Description	Set the time to stop changing the call destination. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

**Call Destination**

Description	Set the call destination to change within the schedule.
Settings	01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 225)"</a> .
Default values	-

## ■ Priority

Description	Set the priority of calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

## 4.4.2 Tone Settings

Configure the busy tone and error tone when making an outgoing call.

### ■ Busy Tone (except IX-MV)

Description	Select the sound to be played when call destination station is busy.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))

## ■ Error Tone (Call Failed) (except IX-MV7-\* and IX-MV)

Description	Select the sound to be played when outgoing call has failed.
Settings	<ul style="list-style-type: none"> <li>• None (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-DA, IX-DF(-*), IX-BA, IX-SS(-*) are Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-DA, IX-DF(-*), IX-BA, IX-SS(-*) are Error Tone)</li> <li>• Pre Tone 1 (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (except for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Error (IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are Error Tone)

### 4.4.3 Call Restart Function (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*))

#### ■ Call Restart Function

Description	Select Enable/Disable for Call Restart Function. Call Restart Function: When the station is reset during an outgoing call, the outgoing call will be resumed automatically up to 2 times.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 4.5 Incoming Call (except IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Configure incoming call settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Move column

Up to 50 station number lines can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered column.

**Row**    Previous    Next

Enter Number    Display

**Column**    Previous    Next

Enter Number    Display

#	Station Information				Call Settings			
	Identification				Incoming Call			
	Number	Name	Location	Station Type	Call Answer Settings	Ringtone		0001 / 0001 / Master Stations1 / IX-1
0001	0001	Master Stations1		IX-MV7-*	OFF			Normal
0002	0002	Master Stations2		IX-MV7-*	OFF			Call Pattern 1
0003	0003	Master Stations3		IX-MV7-*	OFF			Call Pattern 1
0004	0004	Master Stations4		IX-MV7-*	OFF			Call Pattern 1
0005	0005	Master Stations5		IX-MV7-*	OFF			Call Pattern 1

### 4.5.1 Call Answer Settings

#### ■ Auto Answer

Description	Select ON / OFF to automatically answer the individual call. Auto Answer: when receiving an individual call, answer automatically. When transferring a call, it must be answered manually.
Settings	<ul style="list-style-type: none"> <li>• OFF: No Auto Answer.</li> <li>• ON: Auto Answer.</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV, IX-RS-*: OFF</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G: ON</li> </ul>

#### ! Important

- For IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, if Auto Answer is set to "OFF," be sure to configure one of the following. If not configured, calls will not be received.
  - Set to "Call, Answer Call, End Communication" in ["Call Button Function \(→page 224\)"](#).
  - Set to "Answer Call / Page" in "Option Input" - ["Function \(→page 242\)"](#).

#### 💡 Note

- For IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*), Auto Answer is set to "ON and cannot be changed."

## 4.5.2 Ringtone

### ■ Ringtone (except IX-MV7-\*, IX-MV)

Description	Select the ringtone to be played for incoming call.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	Call Pattern 3

### ■ Ringback Tone Count [time(s)] (except IX-MV7-\*)

Description	Set the play count of ringtone for incoming call.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

## ■ Call Button (for IX-MV7-\* and IX-MV)

Description	Select the ringtone for incoming call. Ringtone can be set per each source station. IX-MV7-*: Ringtone can be set per priority. IX-MV: Same for all priority. Set ringtone to "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• None (IX-MV7-* only)</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-MV: Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-MV: Error Tone)</li> <li>• Pre Tone 1 (IX-MV7-* only)</li> <li>• Pre Tone 2 (IX-MV7-* only)</li> <li>• Pre Tone 3 (IX-MV7-* only)</li> <li>• Communication End Pretone (IX-MV7-* only)</li> <li>• Call Queue Notification (IX-MV7-* only)</li> <li>• Waiting Reply Tone (IX-MV7-* only)</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	Call Pattern 1

## ■ Option Input (for IX-MV7-\* and IX-MV)

Description	Select the ringtone for incoming call by Option Input. The ringtone can be set per each source station. IX-MV7-*: The ringtone can be set per priority. IX-MV: Same for all priorities. Set the ringtone to "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• None (IX-MV7-* only)</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-MV: Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-MV: Error Tone)</li> <li>• Pre Tone 1 (IX-MV7-* only)</li> <li>• Pre Tone 2 (IX-MV7-* only)</li> <li>• Pre Tone 3 (IX-MV7-* only)</li> <li>• Communication End Pretone (IX-MV7-* only)</li> <li>• Call Queue Notification (IX-MV7-* only)</li> <li>• Waiting Reply Tone (IX-MV7-* only)</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	Call Pattern 2

### ■ Call Button Ringtone Count [time(s)] (for IX-MV7-\*)

Description	Set the play count of ringback tone for incoming call from call button.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

### ■ Option Input Ringtone Count [time(s)] (for IX-MV7-\*)

Description	Set the play count of ringback tone for incoming call from the option input.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

---

## 4.5.3 VoIP Phone (except IX-MV)

---

### ■ VoIP Phone Call Priority

Description	Select the call priority from VoIP phones.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	Normal

# 5. Option Input/Relay Output Settings

## 5.1 Option Input

Configure the input terminal settings for each station. The number of input terminals varies by station. Select the contact input number to configure in **[Display Settings]**.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.


**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Display Settings**

Displays setting content for the selected contact input number.



### 5.1.1 Option Input Advanced Settings

#### 5.1.1.1 Name (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Set the Name of the Option Input.
Settings	1-24 alphanumeric characters
Default values	-

## 5.1.1.2 Function

Description	Configure the contact input functions. The functions that can be selected differ depending on the station.
Settings	<ul style="list-style-type: none"> <li>• No Function</li> <li>• Call (except IXW-MA): Call to destination. Be sure to also configure "Option Input 1 - 6" in <a href="#">"Call Origination (except IXW-MA) (→page 228)"</a>.</li> <li>• Answer Call / Page (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), IXW-MA): Answer incoming call or page.</li> <li>• Paging (for IX-MV7-*): Page to destination. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 257)"</a>.</li> <li>• Message Page (for IX-MV7-*): Send message to destination. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 257)"</a>.</li> <li>• External Input Page (for IX-MV7-*): Page using an external sound source. Only one input terminal may be configured. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 257)"</a>.</li> <li>• Turn LCD On (for IX-MV7-*): Turn LCD backlight of IX-MV7-* on.</li> <li>• Relay Latch Reset (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SS-2G): Reset latch relay output using the option input. Be sure to select "Latch Output" in "Relay Output" - <a href="#">"Function (→page 245)"</a>.</li> <li>• Bathroom Indicator Reset (for IXW-MA): Not used.</li> <li>• API (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)): Send CGI command set by <a href="#">"API 1 (→page 243)"</a> and <a href="#">"API 2 (→page 243)"</a>.</li> </ul>
Default values	No Function

## 5.1.1.3 Type

Description	Set the detection method of the contact input.
Settings	<ul style="list-style-type: none"> <li>• Make</li> <li>• Break</li> </ul>
Default values	Make

## 5.1.1.4 Detection Time

## ■ Detection Time Range

Description	Select the Detection Time Range for Option Input.
Settings	<ul style="list-style-type: none"> <li>• 0 (Immediate): Detect at input less than 200 msec.</li> <li>• 200 - 2000 [msec]</li> <li>• 3 - 600 [sec]</li> </ul>
Default values	0 (Immediate)



## Note

- The Detection Time Range for IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*) is "200 - 2000 [msec]" and cannot be changed.

## ■ Detection Time◆

Description	Configure the contact input search time within the range set in "Detection Time Range."
Settings	<p>The settings will be configured as follows according to the information set in "Detection Time Range."</p> <ul style="list-style-type: none"> <li>• If set to 0 (Immediate): Configuration unnecessary.</li> <li>• If set to 200 - 2000 [msec]: Configure from 200 - 2000 msec (by 100 msec).</li> <li>• If set to 3 - 600 [sec]: Configure from 3 - 600 sec (by 1 sec).</li> </ul>
Default values	-

**5.1.1.5 API (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))****■ API 1**

Description	Enter the CGI command sent when "API" is selected in <a href="#">"Function (→page 242)"</a> .
Settings	1-128 alphanumeric characters
Default values	-

**■ API 2**

Description	Enter the CGI command sent when "API" is selected in <a href="#">"Function (→page 242)"</a> .
Settings	1-128 alphanumeric characters
Default values	-

## 5.2 Relay Output

Configure the output terminal settings for each station. The number of output terminals varies by station. Select the relay output number to configure in **[Display Settings]**.

**Move row**  
Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Display Settings**  
Displays setting content for the selected contact output number.

[“Weekly Schedule \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 250\)”](#)

[“Daily Schedule \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 252\)”](#)

**Move to Related Settings**  
Moves to the selected item within the same Settings screen.

The screenshot shows the 'Relay Output' configuration screen. At the top, there are navigation buttons: 'Row' (with 'Previous' and 'Next' sub-buttons), 'Display Settings' (with a dropdown for 'Relay Output 1'), 'Weekly Schedule' (with a 'Schedule View Adjustment' dropdown), 'Daily Schedule' (with a date dropdown '10/ 9/2018'), 'Display Range' (with '1' and '3' dropdowns), and 'Move to Related Settings' (with a 'Name' dropdown). Below these are two notes: '1. If other operations, such as Door Release, are performed during the scheduling period, the newest function will be prioritized (will stop the relay output). 2. The schedule is automatically sorted by Start Time after updating.' The main table is divided into 'Station Information' and 'Option Input / Relay Output Settings'. The 'Station Information' table has columns for '#', 'Number', 'Name', 'Location', and 'Station Type'. The 'Option Input / Relay Output Settings' table has columns for 'Relay Output 1' (Name, Function) and 'Status Output 1' (Outgoing Call, Incoming Call, Communication, Outgoing Page), each with sub-columns for Normal, Priority, and Urgent. A red note at the top right of the table says 'Text in red are required settings'.

### ! Important

- The four relay output methods are shown below. Redundant configuration is possible for each output terminal. If multiple commands occur during a single relay output, the last command will take priority.
  - Function selected in [“Function \(→page 245\)”](#)
  - [“Option Relay Control \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, and IX-SS\(-\\*\)\) \(→page 246\)”](#)
  - [“Weekly Schedule \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 250\)”](#), [“Daily Schedule \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 252\)”](#)
  - [“CGI \(→page 279\)”](#)

### 5.2.1 Relay Output Advanced Settings

#### 5.2.1.1 Name (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Set the name of the Relay Output.
Settings	1-24 alphanumeric characters
Default values	-

5.2.1.2 Function

Description	Select the function of the Relay Output. Different function can be selected depending on the station type.
Settings	<ul style="list-style-type: none"> <li>No Function</li> <li>Status Output (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), IXW-MA): Relay Output during the status. The details setting can be set in <a href="#">"How to configure Status Output (→page 245)"</a>.</li> <li>External Audio Output (for IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*), IX-SSA(-*), IX-BA, IX-SS(-*)): Contact is output to control the paging amplifier while audio is output from the paging amplifier terminal. Relay output during Line audio output. This operates when "Volume / Tone" - <a href="#">"Audio Output (for Door) (except IX-MV7-*, IX-SS-2G, and IX-MV) (→page 354)"</a> is set to something other than "Built-in Speaker for Communication and Paging."</li> <li>Door Release (except IXW-MA): Relay output when door release is activated or, entering the authentication key using keypad of the station or the VoIP Phone. Configure the output time in <a href="#">"Output Time♦ (→page 248)"</a>.</li> <li>Latch Output (for IX-RS-*, IX-DV, IX-DVF(-*), IX-FA, IX-SS-2G): Latch relay output by event trigger. Continue to output until latch reset trigger input. Ignore set <a href="#">"Output Time♦ (→page 248)"</a>. Configuration can be set in "How to configure Latch Output".</li> <li>Contact Input Call / Communication State (for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)): Relay output during the contact input call and communication until reset.</li> <li>Bathroom Indicator (for IXW-MA): Not used.</li> <li>Contact Change SIF Event (for IXW-MA): Relay output when Contact Change SIF Event is received from another station. Output Time is the same as Option Input Detection Time or Relay Output Time of the SIF command originating station. Set in "SIF" - "Transmission Trigger" - <a href="#">"Change contact (→page 282)"</a>.</li> </ul>
Default values	Relay Output 1 <ul style="list-style-type: none"> <li>Except IXW-MA: Door Release</li> <li>IXW-MA: No Function</li> </ul> Relay Output 2 - 10 <ul style="list-style-type: none"> <li>No Function</li> </ul>

 Note

- If "Automatically configure door release for all stations?" is set to "No" in ["Create new system/import setting data \(→page 123\)"](#), the default value for "Relay Output 1 (except IXW-MA)" will be "No Function."

**How to configure Status Output**

If ["Function \(→page 245\)"](#) is set to "Status Output," select the operating state for when the relay output occurs. This can be selected for each operation priority (multiple selections allowed).

The operating states that can be selected vary by station type.

#	Station Information				Option Input / Relay Output Settings <span style="color: red;">Text in red are required settings.</span>															
	Identification				Relay Output															
	Number	Name	Location	Station Type	Status Output 1			Outgoing Call			Incoming Call			Communication		Outgoing Page		Incoming Page		Monitor
					Normal	Priority	Urgent	Normal	Priority	Urgent	Normal	Priority	Urgent	Normal	Urgent	Normal	Urgent	Normal	Urgent	
0001	0001	Master Stations1	IX-MV7-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0002	0002	Master Stations2	IX-MV7-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0003	0003	Master Stations3	IX-MV7-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0004	0004	Master Stations4	IX-MV7-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
0005	0005	Master Stations5	IX-MV7-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

 Note

- For "Outgoing Page" and "Incoming Page," relay output is performed even during message paging and external input paging.
- For "Monitored," relay output is performed even during scan monitoring.

### How to configure Latch Output

If ["Function \(→page 245\)"](#) is set to "Latch Output," select the operating state for when the relay output occurs. This can be selected for each operation priority (multiple selections allowed).

Choose from two restoration methods for relay output.

- Option Input (default value): Reset Latch Output by the Option Input.
- End Communication: Reset Latch Output by ending communication or the option input.

All items are set to "Option Input" by default.

To reset by Option Input, be sure to configure "Relay Latch Reset" in "Option Input" - ["Function \(→page 242\)"](#).

#	Station Information				Option Input / Relay Output Settings						
	Identification				Relay Output						
	Number	Name	Location	Station Type	Latch Trigger Event 1						
					Outgoing Call			Communication			Latch Reset Trigger Event
				Normal	Priority	Urgent	Normal	Priority	Urgent		
0041	0041	Handset Sub Statio		IX-RS-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Option Input
0042	0042	Handset Sub Statio		IX-RS-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Option Input
0043	0043	Handset Sub Statio		IX-RS-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Option Input
0044	0044	Handset Sub Statio		IX-RS-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Option Input
0045	0045	Handset Sub Statio		IX-RS-*	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Option Input

### How to configure Contact Change SIF Event

If ["Function \(→page 245\)"](#) is set to "Contact Change SIF Event", select the station for interlocking with Contact Change SIF Event of Relay Output 1.

#	Station Information				Option Input / Relay Output Settings	
	Identification				Relay Output	
	Number	Name	Location	Station Type	Relay Output 1	
					Contact Change SIF Event	
				Number	Station List	
0026	0026	I/O Adaptor1		IXW-MA		Open
0027	0027	I/O Adaptor2		IXW-MA		Open
0028	0028	I/O Adaptor3		IXW-MA		Open
0029	0029	I/O Adaptor4		IXW-MA		Open
0030	0030	I/O Adaptor5		IXW-MA		Open

### ■ Number

Description	Set SIF Origination Station Number. Enter the station number or select station from the list.
Settings	3-32 digits
Default values	-

#### 5.2.1.3 Option Relay Control (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))

Description	<p>Select Enable/Disable for Option Relay Control when using the speed dial of IX-MV7-* to control the output.</p> <p>If set to "Enable," contact will be output according to the "Speed Dials / Favorites" - <a href="#">"How to configure Option Relay Control (for IX-MV7-*) (→page 343)"</a> setting.</p> <p>If "How to configure optional relay" - <a href="#">"TLS (→page 344)"</a> was set to "Enable" for the station that be controlled, also configure <a href="#">"Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), IX-BA and IX-SS(-*)) (→page 253)"</a>.</p> <p>For IXW-MA, this can be controlled as an optional relay if set to "Enable," only when <a href="#">"Function (→page 245)"</a> is set to "No Function."</p>
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 5.2.1.4 Output Time Range

## ■ Output Time Range

Description	Select the Output Time Range for relay output if <a href="#">"Function (→page 245)"</a> is set to "Door Release" or if the output terminal is controlled via <a href="#">"CGI (→page 279)"</a> .
Settings	<ul style="list-style-type: none"> <li>• 0 (Momentary) (for IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)): Outputs while an output command is received. However, this is set to 10 sec and cannot be changed if a relay output command is received via CGI.</li> <li>• 200-2000 [msec]</li> <li>• 3 - 600 [sec] (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))</li> <li>• 3-300 [sec] (for IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))</li> </ul>
Default values	200-2000 [msec]

## ! Important

- If set to "0 (Momentary)," the operation when the door on the other station is released will be as follows.  
IX-MV7-\* or IX-RS-\*: When the Door Release button is pressed or the Authentication Key is input by the keypad, a relay output command is sent and the output command ends immediately. The output command will not continue even if the Door Release button is held.  
IX-MV: The relay output command continues while the Door Release button is pressed, and ends once it is released.

## ■ Output Time◆

Description	Set the Output Time within the range selected in <a href="#">"Output Time Range (→page 247)"</a> .
Settings	Select the Output Time Range for relay output. <ul style="list-style-type: none"> <li>• If set to 0 (Momentary): Configuration unnecessary.</li> <li>• If set to 200-2000 [msec]: Configure from 200 - 2000 msec (by 200 msec).</li> <li>• If set to 3 - 600 [sec]: Configure from 3 - 600 sec (by 1 sec).</li> <li>• If set to 3-300 [sec]: Configure from 3 - 300 sec (by 1 sec).</li> </ul>
Default values	400 [msec]

### 5.2.1.5 Door Release Authorization (except IXW-MA)

Description	Set the Authentication Key when "Door Release" is selected in <a href="#">"Function (→page 245)"</a> for releasing the door that is connected to the station. When the "Authentication Key" is confirmed, the relay output will be activated. Configure "Door Release Settings" - <a href="#">"Authentication Key (→page 260)"</a> . This will also be the authentication key used to release the door using the numerical keypad on IX-MV7-* or VoIP Phone.
Settings	<ul style="list-style-type: none"> <li>• Except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*): 1-20 digits</li> <li>• IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*): 1-4 digits</li> </ul>
Default values	This will vary depending on the setting value configured in <a href="#">"Create new system/import setting data (→page 123)"</a> - "IX Support Tool Settings." <ul style="list-style-type: none"> <li>– IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*) not configured: 20 random digits</li> <li>– IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*) configured: 4 random digits</li> </ul>

## ! Important

- Configure the Authentication Key using 1 to 4 digits to release when using the IX-MV.
- Configure a different Authentication Key for each output terminal. (The same key cannot be used.)
- Configure an Authentication Key that is different from the Authentication Key configured in "Communication Audio Messages" - ["Door Release Authorization \(except IXW-MA\) \(→page 248\)"](#) and ["Option Relay Control Authentication Key \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA and IX-SS\(-\\*\)\) \(→page 253\)"](#). If the setting is the same, multiple functions might operate.
- To release the door using the numerical keypad, enter "\*\*\*Door Release Authorization\*\*" on the IX-MV7-\* or VoIP Phone numerical keypad (if the Authentication Key is "0000" enter "\*\*\*0000\*\*").

## 5.2.1.6 Sound Settings (except IX-MV and IXW-MA)

## ■ Door Release

Description	Select the Door Release sounds to be played.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Operation Sound

## ■ Relay Control (start) (except IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*))

Description	Select the sound to be played when Option Relay is activated.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

■ Relay Control (end) (except IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*))

Description	Select the sound to be played when Option Relay is deactivated.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

5.2.1.7 Weekly Schedule (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure the time to perform relay output for each day of the week, from Sunday to Saturday. 12 schedules can be set for each day.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Weekly Schedule**

Select the day and schedule range to configure. The Settings screen will be shown.

[“How to configure schedule display \(→page 233\)”](#)

The screenshot shows the system settings interface. At the top, there are controls for 'Row' (with 'Previous', 'Next', and 'Display' buttons) and 'Weekly Schedule' (with a dropdown menu and a 'Schedule View Adjustment' button). Below these controls is a table with columns for 'Station Information' and 'Option Input / Relay Output Settings'. The table has 7 rows, with the first row highlighted in blue. The table columns are: #, Number, Name, Location, Station Type, Weekly Schedule: Sunday 01, Weekly Schedule: Sunday 02, Weekly Schedule: Sunday 03, Weekly Schedule: Monday 01, Weekly Schedule: Monday 02, Weekly Schedule: Monday 03, Weekly Schedule: Tuesday 01, Weekly Schedule: Tuesday 02, Weekly Schedule: Tuesday 03, Weekly Schedule: Wednesday 01, Weekly Schedule: Wednesday 02, Weekly Schedule: Wednesday 03, Weekly Schedule: Thursday 01, Weekly Schedule: Thursday 02, Weekly Schedule: Thursday 03, Weekly Schedule: Friday 01, Weekly Schedule: Friday 02, Weekly Schedule: Friday 03, Weekly Schedule: Saturday 01, Weekly Schedule: Saturday 02, Weekly Schedule: Saturday 03.

## ! Important

- Regardless of the configuration in "[Function \(→page 245\)](#)", the relay will continue to output during the time period set in the schedule. However, if a door release operation or other command occurs during the relay output, the last command will be given priority, and the relay output will stop even if it is still within the time set in the schedule.

## ■ Start Time

Description	Set the time to start the relay output.
Settings	00:00 - 23:59
Default values	-

## ■ End Time


Description	Set the time to end the relay output. If set earlier than "Start Time," the end time will be the time the following day.
Settings	00:00 - 23:59
Default values	-

## How to configure schedule display

Configure the day and schedule range shown on the Settings screen for the weekly schedule.

The display can be filtered to show only the day and schedule to configure.

Click Schedule View Adjustment. The following screen will be shown.



1. Select the day(s) to display from "Day" (multiple selections allowed).
  - To select or unselect all days at once, click **[Select]** or **[Unselect]**.
  - By default, all days are shown.
2. Select the range of schedules to display (1 - 12) that can be configured for each day of the week.
  - By default, the range of 1 - 3 is shown.

**3.** Click **[OK]**.

- Click **[Cancel]** to return to the schedule display.

**5.2.1.8 Daily Schedule (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Configure the time at which relay output will be performed, in units of one day. A schedule one year from the set day can be configured. 12 schedules can be set for each day.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.


**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Daily Schedule**

Select the date and schedule range to configure. The Settings screen will be shown.

1. Select the date from the drop down menu.
2. Select the range of schedules to display (1 - 12) that can be configured for each day.
  - By default, the range of 1 - 3 is shown.
3. Click **[Change to Daily Schedule Display]**.



**! Important**

- Regardless of the setting in "[Function \(→page 245\)](#)", the relay will continue to output during the time period set in the schedule. However, if a door release operation or other command occurs during relay output, the latest command will be given priority, and relay output will stop even if it is still within the time set in the schedule.

**■ Start Time**

Description	Set the time to start the relay output.
Settings	00:00 - 23:59
Default values	-

## ■ End Time

Description	Set the time to end the relay output. If set earlier than "Start Time," the end time will be the time the following day.
Settings	00:00 - 23:59
Default values	-

## 5.2.2 Authentication Key

### ■ Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-\*), IX-BA and IX-SS(-\*))

Description	If " <a href="#">Option Relay Control (except IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*)) (→page 246)</a> " is set to "Enable" and "Speed Dials / Favorites" - " <a href="#">TLS (→page 344)</a> " is set to "Enable" on the requesting station, configure the key used to decrypt encrypted communication. If this matches the "Option Relay Control Key" of the station performing the operation, the Relay Output can be controlled. To use this, be sure to configure "Speed Dials / Favorites" - " <a href="#">Option Relay Control Key (→page 344)</a> ".
Settings	1-20 digits
Default values	-



#### Note

- Only one Option Relay Control Authentication Key can be set for each station. It will be shared with multiple Relay Output.

## 6. Paging Settings

### ! Important

- All pages, groups pages, message pages, and external input pages cannot be sent to VoIP Phone.

### 6.1 Paging Origination (for IX-MV7-\* and IX-MV)

Configure settings related to outgoing paging.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a control bar with a 'Row' label, 'Previous' and 'Next' buttons, an 'Enter Number' input field, and a 'Display' button. Below this is a yellow banner with two red instructions: '1. Page settings for Master Stations.' and '2. To set Paging Pretone Setting for Master Stations, go to "Station Settings -> Volume/Tone -> Tone -> Paging Pretone".' Below the banner is a table with columns for Station Information and Paging Settings. The table has a red border around the 'Paging Settings' columns.

#	Station Information				Paging Settings				Text in red are required settings.
	Identification				Paging Origination				
	Number	Name	Location	Station Type	Paging Timeout [sec]	Paging Wait Timer [sec]	Urgent Page Response	Lock Paging	
0001	0001	Master Stations1		IX-MV7-*	30	10	Disable	Disable	
0002	0002	Master Stations2		IX-MV7-*	30	10	Disable	Disable	
0003	0003	Master Stations3		IX-MV7-*	30	10	Disable	Disable	
0004	0004	Master Stations4		IX-MV7-*	30	10	Disable	Disable	

#### ■ Paging Timeout [sec]◆

Description	Set the time for outgoing paging duration.
Settings	10-600sec / 1 sec step
Default values	30 sec

#### ■ Paging Wait Timer [sec] (for IX-MV7-\*)◆

Description	Set the time to wait for a response from all destination stations when outgoing paging is activated. Paging starts after this time without a response form all destination.
Settings	1-20sec (by 1 sec)
Default values	10 sec

### ! Important

- A page may not be sent to a station if a response is received after "Paging Wait Timer [sec]" elapses. If multiple stations receive pages, configure a longer paging wait timer.

### 💡 Note

- The paging wait time for IX-MV is set to "10 sec" and cannot be changed.

## ■ Urgent Page Response (for IX-MV7-\*)

Description	Select Enable / Disable for the paging destination station can answer the urgent page.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### Important

- If the station being called is IX-MV, end operations can be performed even if urgent paging rejecting is set to "Enable."

## ■ Lock Paging (for IX-MV7-\*)

Description	Select Enable / Disable to lock paging function.
Settings	<ul style="list-style-type: none"> <li>• Enable: Page button will be hidden</li> <li>• Disable</li> </ul>
Default values	Disable

### Note

- Configure the pretone when a page is received in "Volume / Tone" - ["Paging Pretone \(for IX-MV7-\\* and IX-MV\) \(→page 351\)"](#).

## 6.2 All Page (for IX-MV7-\* and IX-MV)

When paging all stations, the default setting is set to multicast. When unicast is required, configure the following settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Move column

Up to 50 station number lines can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered column.

Address Book Station List

**Row** Previous Next

Enter Number  **Display**

**Column** Previous Next

Enter Number  **Display**

Number of Notes: 2  
 1. Page settings for Master Stations.  
 2. Multicast is utilized for All Page function (by default) and must be configured for the stations.

#	Station Information				Total	Paging Settings		
	Number	Name	Location	Station Type		All Page	Unicast	
0001	0001	Master Stations1		IX-MV7-*	0	0001 / Master Stations1 / IX-MV7-*	0002 / Master Stations2 / IX-MV7-*	0003 / Mast
0002	0002	Master Stations2		IX-MV7-*	0		2	
0003	0003	Master Stations3		IX-MV7-*	0			3
0004	0004	Master Stations4		IX-MV7-*	0			

Text in red are required settings.

List of IX-MV7-\* and IX-MV in the Settings data

### ! Important

- Unicast can reach up to 50 stations. If you need to page more than 50 stations are to be paged at once, use multicast.
- When paging stations in multicast, configure ["Multicast Address \(For IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)" \(→page 190\)](#).

### How to configure All Page

1. Identify the station to be configured using "List of IX-MV7-\* and IX-MV in the setting data."
2. Search for stations to transmit via unicast from the "List of stations in Address Book."
3. Place a check in the cells corresponding to Steps 1 and 2.
  - Unchecked: Multicast transmission
  - Checked: Unicast transmission
  - By default, all are set to "Unchecked" (multicast transmission).
4. When done, click **[Update]**.
5. Click **[OK]**.

## 6.3 Option Input Page (for IX-MV7-\*)

Configure contact input paging.

Configure if "Paging," "Message Page," and "External Input Page" are selected in "Option Input" - "[Function](#) ([→page 242](#))".

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Display Settings

Displays setting content for the selected Option Input number.

The screenshot shows the 'Option Input Page' interface. At the top, there are navigation buttons: 'Row', 'Previous', 'Next', and 'Display'. Below these is a text input field labeled 'Enter Number' and a 'Display' button. To the right, there is a dropdown menu labeled '[Display Settings]' with 'Option Input 1' selected. Below the navigation controls, there are two numbered notes: '1. Page settings for Master Stations.' and '2. To configure an Option Input Page, "Page", "Message Page", or "External Input Page" must be selected in Option Input settings.' Below the notes is a table with columns for 'Station Information' and 'Paging Settings'. The 'Station Information' columns are '#', 'Number', 'Name', 'Location', and 'Station Type'. The 'Paging Settings' columns are 'Option Input Page', 'Destination', 'Group' (with sub-columns 'Group Number' and 'Group Selection'), 'Priority', 'Message File Name', and 'Play Count [time(s)]'. The table contains five rows of data, each with a 'Group Selection' button labeled 'Open'.

Station Information					Paging Settings					
Identification					Option Input Page					
#	Number	Name	Location	Station Type	Option Input 1					
					Destination	Group Number	Group Selection	Priority	Message File Name	Play Count [time(s)]
0001	0001	Master Stations1		IX-MV7-*	All Page		Open	Normal		
0002	0002	Master Stations2		IX-MV7-*	All Page		Open	Normal		
0003	0003	Master Stations3		IX-MV7-*	All Page		Open	Normal		
0004	0004	Master Stations4		IX-MV7-*	All Page		Open	Normal		
0005	0005	Master Stations5		IX-MV7-*	All Page		Open	Normal		

### ■ Destination

Description	Set the destination group for paging.
Settings	<ul style="list-style-type: none"> <li>All Page: Page all stations that are registered in the address book.</li> <li>Group: Page the group that is set in "Group Number."</li> </ul>
Default values	All Page

### ■ Group Number

Description	Set the destination group for paging. Enter the group number, or click <b>[Open]</b> to select group.
Settings	01 - 99. Select from groups registered in " <a href="#">Group (for Master) (for IX-MV7-* and IX-MV)</a> ( <a href="#">→page 217</a> )".
Default values	-

### ■ Priority

Description	Set the priority for paging.
Settings	<ul style="list-style-type: none"> <li>Normal</li> <li>Urgent</li> </ul>
Default values	Normal

## ■ Message File Name

Description	Select the message to be sent for message paging. Available when "Message Page" is selected in "Option Input" - <a href="#">"Function (→page 242)"</a> .
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	None

## ■ Play Count [time(s)]

Description	Set the play count for message paging.
Settings	1 - 20 times
Default values	1 time

# 7. Function Settings

## 7.1 Door Release (for IX-MV7-\* and IX-MV)

### 7.1.1 Door Release Assignment

Configure the connected station and the authentication key to release the door during a call.  
 For IX-RS-\* settings, refer to [“Door Release Assignment \(for IX-RS-\\*\) \(→page 365\)”](#).

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Move column**

Up to 50 station number lines can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 columns.  
**[Next]:** Display the next 50 columns.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered column.

Destination station list  
 (# / Number / Name / Station Type)

### ■ Contact Assignment

Description	Select which relay output will be used for door release during call or monitoring.
Settings	<ul style="list-style-type: none"> <li>• Origination Station: Use origination station relay output for door release.</li> <li>• Destination Station: Use destination station relay output for door release.</li> </ul>
Default values	Destination Station

## ■ Authentication Key

Description	When "Destination Station" is selected in "Contact Assignment", set the Authentication Key for door release. Authentication key must match with the destination station's authentication key, which is set in "Relay Output" - " <a href="#">Door Release Authorization (except IXW-MA) (→page 248)</a> " to allow door release.
Settings	<ul style="list-style-type: none"> <li>• IX-MV7-*: 1-20 digits</li> <li>• IX-MV: 1-4 digits</li> </ul>
Default values	Random characters (compatible with default value of "Relay Output" - "Door Release Authorization")



### Note

- If "[Create new system/import setting data \(→page 123\)](#)" - "Automatically configure door release for all stations?" was set to "No," a default value for "Authentication Key" will not be set.
- The default values for the Door Release Authorization and Authentication Key vary depending on the station type set in "[Create new system/import setting data \(→page 123\)](#)" - "IX Support Tool Settings."
  - System with IX-MV, IX-DA, or IX-BA: 20 digits
  - System without IX-MV, IX-DA, or IX-BA: 4 digits
- If the destination station's Authentication Key is four characters or longer, the Door Release Key for IX-MV will release the door if the first four digits match.

## 7.2 Network Camera Integration (for IX-MV7-\* and IX-MV)

Configure network camera profile (video profile) and event related settings.

To configure the settings, register a network camera in the Address Book of the IX-MV7-\* or IX-MV which will receive the event in "Address Book" - ["Open Network Camera List \(→page 212\)"](#).

### ! Important

- For network camera event registration, ["Association Settings \(→page 160\)"](#) must be configured for the IX-MV7-\* or IX-MV. If the programming PC is not connected to the same network or cannot communicate with multicast transmission, it is not possible to configure. (this is because network camera events are obtained over multicast via IX-MV7-\* or IX-MV when registering network camera events).

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

#### Jump to related item

Moves to the selected item within the same Settings screen.

#### Profile Setting

**[<<]:** Displays the first column for profile setting.

**[>>]:** Displays the last column for profile setting.

**[Go]:** Enter a network camera number and click **[Go]** to display the column for the entered network camera number.

#### Event Registration

**[<<]:** Displays the first column for event registration.

**[>>]:** Displays the last column for event registration.

**[Go]:** Enter an event number and click **[Go]** to display the column for the entered event number.

["How to configure network camera event setup"](#)

Network Camera Number

Event Number

If no network camera is registered, this will not be shown.

If no event is registered, this will not be shown.

## 7.2.1 Profile Setting

Configure when changing the profile selected when a network camera is registered in "Address Book" - "[Open Network Camera List \(→page 212\)](#)".

### ■ Profile

Description	Select the profile of the network camera. On the first screen, the Profile that was selected when registering the network camera will be displayed. Refer to the manual of the network camera for the details.
Settings	—
Default values	—

## 7.2.2 Event Registration

Configure the network camera event to register in IX-MV7-\* or IX-MV.

When the registered event is received, network camera monitoring will be performed and the notification tone will be played, or the outgoing call command will be sent to the destination station (for IX-MV7-\*).

### ■ Event

Description	Displays Event registered in " <a href="#">How to configure network camera event setup (→page 265)</a> ". To delete the registered event, click <b>[Update]</b> with "Event" set as blank. For details on topics, refer to the manual of the network camera.
Settings	—
Default values	—

### ■ Function (for IX-MV7-\*)

Description	Select the function when receive the topic from the network camera.
Settings	<ul style="list-style-type: none"> <li>• Monitor: Play the notification tone and begin network camera monitoring.</li> <li>• Call: An outgoing call is placed from the station set in "<a href="#">Call Origination (for IX-MV7-*) (→page 264)</a>". Configure "<a href="#">ID (for IX-MV7-*) (→page 263)</a>", "<a href="#">Password (for IX-MV7-*) (→page 263)</a>", "<a href="#">Call Origination (for IX-MV7-*) (→page 264)</a>", "<a href="#">Call Destination (for IX-MV7-*) (→page 264)</a>", and "<a href="#">Priority (for IX-MV7-*) (→page 264)</a>".</li> </ul>
Default values	—

## ■ Event Tone (for IX-MV7-\*)

Description	Select the tone to be played when receiving event from the network camera.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	Call Pattern 3

## ■ ID (for IX-MV7-\*)

Description	If "Call" is set in <a href="#">"Function (for IX-MV7-*) (→page 262)"</a> , configure the administrator ID of the station set in <a href="#">"Call Origination (for IX-MV7-*) (→page 264)"</a> .
Settings	1-32 alphanumeric characters
Default values	–

## ■ Password (for IX-MV7-\*)

Description	If "Call" is set in <a href="#">"Function (for IX-MV7-*) (→page 262)"</a> , configure the administrator password of the station set in <a href="#">"Call Origination (for IX-MV7-*) (→page 264)"</a> .
Settings	1-32 alphanumeric characters
Default values	–



### Note

- "Password" will be displayed as "\*\*\*\*\*" in the Settings screen.

## ■ Call Origination (for IX-MV7-\*)

Description	If " <a href="#">Function (for IX-MV7-*) (→page 262)</a> " is set to "Call," configure from which station to make the outgoing call. Enter the station number or click <b>[Open]</b> to select a station. The selected station must be set "Enable" in " <a href="#">CGI Functionality (→page 279)</a> ".
Settings	Select from the stations registered in " <a href="#">Address Book (for IX-MV7-* and IX-MV) (→page 208)</a> ". IXW-MA cannot be selected.
Default values	–

## ■ Call Destination (for IX-MV7-\*)

Description	Configure the destination station number or group number when the station configured in " <a href="#">Call Origination (for IX-MV7-*) (→page 264)</a> " makes an outgoing call.
Settings	Station number: 3-32 digits Group number: 01 - 99
Default values	–

## ■ Priority (for IX-MV7-\*)

Description	Select the call priority when the station configured in " <a href="#">Call Origination (for IX-MV7-*) (→page 264)</a> " makes an outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	–

## ■ Event Tone (for IX-MV)

Description	Select the tone to be played when receiving event from the network camera. The tone will be the same for all network cameras and events registered in the station.
Settings	<ul style="list-style-type: none"> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error Tone</li> </ul> <ul style="list-style-type: none"> <li>• Select a sound that is registered in "<a href="#">Custom Sound Registry (except IXW-MA) (→page 221)</a>".</li> </ul>
Default values	Call Pattern 3


## ■ Play count of Event Tone

Description	Set the play count for Network Camera Event Tone when " <a href="#">Function (for IX-MV7-*) (→page 262)</a> " is set to "Monitor." The ringtone count will be the same for all network cameras and events registered to the station. If "Call" is set, the ringtone count for the event notification tone will be 1 only.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Continues to sound while the event generated by the network camera is received.</li> <li>• 1 - 20 times</li> </ul>
Default values	1 time

**How to configure network camera event setup**

The network camera event must be registered.

Click **[Open Network Camera Event Registry]**. The "Open Network Camera Event Registry" screen will be shown.



If no event is obtained, this will not be shown.

1. Select the station to register the network camera event from "Station List."
2. Select the network camera(s) to monitor events from "Network Camera List" (multiple selections allowed).
  - Network cameras registered in the Address Book in "Address Book" - ["Open Network Camera List \(→page 212\)"](#) will be shown.
3. Click **[Get Network Camera Events]**. (Obtaining the events may take several minutes.)
  - Once events are successfully obtained, they will be shown in "Event List."

4. Select the events to monitor from "Event List." (Multiple selections allowed)
  - For details on events, refer to the manual of the network camera.
5. Click **[Register]** to register the event.
  - The network cameras and events registered in event registry will be shown.
  - Click **[Cancel]** to back to the "Network Camera Integration" screen without registering the event.

## 7.3 Paging Settings (except IX-MV7-\*, IX-MV, and IXW-MA)

Configure incoming page settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a control panel at the top with a 'Row' label, 'Previous', 'Next', and 'Display' buttons. Below this is a text input field labeled 'Enter Number' and a 'Display' button. A status bar indicates 'Number of Notes: 1' and '1. Page settings for Door/Sub Stations.' Below the control panel is a table with columns for Station Information and Function Settings. The Station Information column is further divided into Identification (Number, Name, Location, Station Type) and Paging Settings (Paging Pretone). The table lists stations 0011 through 0016, all with 'Pre Tone 2' as their paging pretone. A red note at the top right of the table states 'Text in red are required settings.'

#	Station Information				Function Settings
	Number	Name	Location	Station Type	Paging Settings
0011	0011	Video Stations1		IX-DV, IX-DVF(-*)	Pre Tone 2
0012	0012	Video Stations2		IX-DV, IX-DVF(-*)	Pre Tone 2
0013	0013	Video Stations3		IX-DV, IX-DVF(-*)	Pre Tone 2
0014	0014	Video Stations4		IX-DV, IX-DVF(-*)	Pre Tone 2
0015	0015	Video Stations5		IX-DV, IX-DVF(-*)	Pre Tone 2
0016	0016	Video Stations6		IX-DA, IX-DF(-*)	Pre Tone 2

### 7.3.1 Paging Pretone Setting

#### ■ Paging Pretone

Description	Select the Paging Pretone.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 2 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 3 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 4 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 5 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 6 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Tremolo Sound (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Busy Response Tone (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Operation Sound (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Error (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3 (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a> (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)).</li> </ul>
Default values	Pre Tone 2

#### ! Important

- Configure a tone with a shorter duration than the paging pretone on the paging origination station. Configuring a longer tone might prevent the station from receiving audio when paging begins.

## 7.4 Bathroom Call (for IXW-MA)

This function cannot be used outside Japan.

## 7.5 Email

Configure this section when email notification of station operation is required.

Be sure to configure [“DNS \(→page 185\)”](#) for IX-MV, IX-DA, IX-DF(-\*), IX-BA, or IX-SS(-\*).

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

Select the event (sending trigger) to configure. The Settings screen is displayed.  
[“How to select event display \(→page 275\)”](#)

### Move to Related Settings

Moves to the selected item within the same Settings screen.

The screenshot shows the 'Email' settings screen. At the top, there are navigation buttons: 'Row' (with a text input 'Enter Number' and a 'Display' button), 'Previous', and 'Next'. Below these are 'Display Settings' and 'Event View Selection' buttons. To the right, there is a '(move to related settings)' button and a 'Server Settings' dropdown menu. Below the navigation area is a table with the following data:

#	Station Information				Function Settings								
	Identification				Email								
	Number	Name	Location	Station Type	Server Settings				Authentication Settings				
				SMTP Server	SMTP Port	SMTP Encryption	SMTP Authentication	Mode	ID	Passw			
0001	0001	Master Stations 1		IX-MV7-*		25	OFF	OFF	LOGIN				
0002	0002	Master Stations 2		IX-MV7-*		25	OFF	OFF	LOGIN				

*Text in red are required settings.*

### 7.5.1 Server Settings

#### ■ SMTP Server

Description	Set the SMTP server. When choosing an IPv4 address, enter the IP address or the hostname. When choosing an IPv6 address, configure the IP address (except IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*)) or the hostname. If a hostname is used, configure <a href="#">“DNS (→page 185)”</a> .
Settings	1 - 255 alphanumeric characters
Default values	—

#### ■ SMTP Port◆

Description	Set the port number for SMTP.
Settings	1 - 65535
Default values	25

**■ SMTP Encryption**

Description	Select the encryption type for SMTP.
Settings	<ul style="list-style-type: none"><li>• OFF</li><li>• TLS</li><li>• STARTTLS</li></ul>
Default values	OFF

## 7.5.2 Authentication Settings

### ■ SMTP Authentication

Description	Select ON / OFF for SMTP Authentication.
Settings	<ul style="list-style-type: none"> <li>• ON</li> <li>• OFF</li> </ul>
Default values	OFF

### ■ Mode

Description	Select the SMTP Authentication Mode.
Settings	<ul style="list-style-type: none"> <li>• LOGIN</li> <li>• CRAM-MD5</li> </ul>
Default values	LOGIN

### ■ ID

Description	Set the ID for SMTP authentication.
Settings	1-64 alphanumeric characters
Default values	-

### ■ Password

Description	Set the Password for SMTP authentication.
Settings	1-64 alphanumeric characters
Default values	-



#### Note

- "Password" will be displayed as "\*\*\*\*\*" on the screen.

## 7.5.3 Email Addresses

### ■ Destination 1

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

### ■ Destination 2

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

**Destination 3**

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

**Source Address**

Description	Set the source email address.
Settings	1-64 alphanumeric characters
Default values	-

**7.5.4 Email Event Trigger**

Set the email event trigger which initiates the message sending process. Configure the email event trigger for each destination address.

**Outgoing Normal Call (except IXW-MA)**

Description	Send email when an outgoing call is placed at "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**Incoming Normal Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)**

Description	Send email when an incoming call is received at "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**Outgoing Priority Call (except IXW-MA)**

Description	Send email when an outgoing call is placed at "Priority" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**Incoming Priority Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)**

Description	Send email when an incoming call is received at "Priority" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**Outgoing Urgent Call (except IXW-MA)**

Description	Send email when an outgoing call is placed at "Urgent" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Incoming Urgent Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Send email when an incoming call is received at "Urgent" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Door Release Activated (for IX-MV7-\*, IX-MV, and IX-RS-\*)

Description	Send email when Door Release is activated.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Call Failed (except IXW-MA)

Description	Send email when outgoing call has failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Latch Reset (for IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G)

Description	Send email when reset latch relay output. ("Latch Output" is selected in "Relay Output" - <a href="#">"Function (→page 245)"</a> .)
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Error

Description	Send email when a communication error has occurred.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Station Restarted

Description	Send email when the station has reset.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ SD Card Error (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send email when a microSD access error is detected. If the error is detected continuously, mail will not be sent an additional time.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Recording Memory Full (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send email when a microSD card meets following criteria. If the error is detected continuously, mail will not be sent an additional time. <ul style="list-style-type: none"> <li>• When <a href="#">"Prevent Overwrite (→page 298)"</a> is set to "Enable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 950</li> <li>– Storage capacity remaining 5%</li> </ul> </li> <li>• When <a href="#">"Prevent Overwrite (→page 298)"</a> is set to "Disable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 999</li> <li>– Storage capacity remaining 0%</li> </ul> </li> </ul>
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Line Supervision (Passed) (for IX-MV7-\*)

Description	Send email when Line Supervision is "Passed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Line Supervision (Failed) (for IX-MV7-\*)

Description	Send email when Line Supervision is "Failed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Device Check (Passed) (for IX-MV7-\*)

Description	Send email when Device Check is "Passed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Device Check (Failed) (for IX-MV7-\*)

Description	Send email when Device Check is "Failed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Subject

Description	Set the Subject of email per Event Trigger. This will be used for all recipient addresses.
Settings	1-64 alphanumeric characters
Default values	-

### Important


- "UTF-8" encoding is used for "Subject." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

**How to select event display**

Select an event (Email Event Trigger) to display on the Settings screen. The selected sending trigger will be the only one displayed.

This will be used for all recipient addresses.

Click Event View Selection. The following screen will be shown.



1. Select the event(s) (Email Event Trigger) from "Event List" (multiple selections allowed).
  - To select or unselect all events at once, click **[Select]** or **[Unselect]**.
  - By default, all events are displayed.
2. Click **[OK]**.
  - Click **[Cancel]** to exit the event display selection.

---

**7.5.5 Periodic Log Transmission**

---

Configure settings related to sending periodic logs. These can be configured for each recipient email address.

**■ Periodic Log Transmission**

Description	Select Enable / Disable for send station log periodically.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

**■ Periodic Log Transmit Time**

Description	Set the time to send the periodic log.
Settings	00:00 - 23:59
Default values	00:00

**■ Periodic Log Transmit Interval**

Description	Select the interval to send the periodic log.
Settings	1 Day - 7 Day
Default values	1 Day

## ■ Periodic Log Transmission Subject

Description	Set the email subject for Periodic Log Transmission. This is used for all destination addresses.
Settings	1 - 64 alphanumeric characters
Default values	–

### Important

- "UTF-8" encoding is used for "Periodic Log Transmission Subject." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

## 7.5.6 Send Test Email (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Send a test email to the address specified in [“Email Addresses \(→page 271\)”](#).

Click **[Send]** of the station to send the test email to. The following email will be sent to the configured address.

### Important

- To send a test email, [“Association Settings \(→page 160\)”](#) must have been configured, and the programming PC must be able to communicate with the system.

Example of sending an email message:

When sending a test email from the station (Station Number: 001, Station Name: Intercom Station 1, Location: Office).

From	△△△△@△△△△△.com
Date and time	11/20/2018 15:22
To CC	xxxx@xxxxx.com
Subject	001 Intercom Station 1 Test Email
Text	Test Email sent at "20181120 15:22:46."  Station Number: "001" Station Name: [Intercom Station 1] Station location: [Office]

### Important

- "UTF-8" encoding is used for "Subject," "Periodic Log Transmission Subject," and "Image Filename." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

## 7.5.7 Additional Settings (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

### ■ Attach Image

Description	Select Enable / Disable to send an image with the email when "Outgoing Normal Call", "Outgoing Priority Call" and "Outgoing Urgent Call" is selected in <a href="#">"Email Event Trigger (→page 272)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ■ Image Filename

Description	Set the filename of a image file when "Attach Image" is enabled.
Settings	1-64 alphanumeric characters
Default values	-

### ! Important

- "UTF-8" encoding is used for "Image Filename." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

## 7.6 CGI

For the details of CGI functionality, contact the local Aiphone representative.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a control panel at the top with a 'Row' label, 'Previous' and 'Next' buttons, an input field labeled 'Enter Number', and a 'Display' button. Below this is a table with the following structure:

#	Station Information				Function Settings
	Identification				CGI
	Number	Name	Location	Station Type	CGI Functionality
0001	0001	Master Stations1		IX-MV7-*	Disable
0002	0002	Master Stations2		IX-MV7-*	Disable

Text in red are required settings.

### ■ CGI Functionality

Description	Select Enable / Disable for CGI functionality.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ! Important

- CGI controls may fail when multiple CGI commands are received.

## 7.7 SIF

For the details of SIF functionality, contact the local Aiphone representative.

**Move row**  
Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Display Settings**  
Displays setting content for the selected number or periodic transmission.  
  
Select the event (SIF sending trigger) to configure. The Settings screen is displayed.  
["How to select event display \(→page 289\)"](#)

**Move to Related Settings**  
Moves to the selected item within the same Settings screen.  
  
["Upload SIF File \(→page 291\)"](#)

The screenshot shows the SIF settings interface. At the top, there are several control panels: 'Row' with 'Previous', 'Next', and 'Display' buttons; 'Display Settings' with a dropdown menu showing 'No.01'; 'Event View Selection'; 'Move to Related Settings' with a dropdown menu showing 'SIF Functionality'; and 'Related Settings' with 'Upload SIF File' and 'Download SIF File' buttons. Below these panels is a table with columns for Station Information (Number, Name, Location, Station Type) and Function Settings (SIF Functionality, SIP URI Format, SIF Settings). The table contains four rows of data, with the first row highlighted. A red box highlights the 'Download SIF File' button in the bottom right corner, with a callout pointing to it: ["Download SIF File \(→page 293\)"](#).

### 7.7.1 SIF Functionality

Description	Select Enable / Disable for SIF functionality.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### 7.7.2 SIP URI Format (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select Enable / Disable when SIP URI Format is used for station destination. If set to "Enable," TERMID cannot be used.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### 7.7.3 SIF Settings (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*))

Configure SIF recipient and communication settings. 16 SIF settings can be set for each station. Select the number to configure from No.1 - No.16 in **[Display Settings]**.



#### Note

- There are two ways to configure SIF communication: manually configuring settings or uploading a "SIF Communication Settings (sif.ini)" file in ["Upload SIF File \(→page 291\)"](#). The latest setting will take priority.

#### ■ Program Type

Description	Set the Program Type for SIF.
Settings	0000-1111 If this is set to "0000," "0001," or "0011," the <a href="#">"Transmission Trigger (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)) (→page 282)"</a> setting will be disabled.
Default values	-

#### ■ IPv4

Description	Set the SIF IPv4 destination address. Go to <a href="#">"DNS (→page 185)"</a> to set Hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ IPv6

Description	Set the SIF IPv6 destination address. Go to <a href="#">"DNS (→page 185)"</a> to set Hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ Destination Port

Description	Set the Port Number for destination.
Settings	1 - 65535
Default values	-

#### ■ SSL

Description	Select Enable / Disable for SSL.
Settings	<ul style="list-style-type: none"> <li>• Disable</li> <li>• Enable</li> </ul>
Default values	-

#### ■ Connection

Description	Select Socket / HTTP for connection.
Settings	<ul style="list-style-type: none"> <li>• Socket</li> <li>• HTTP</li> </ul>
Default values	-

#### 7.7.4 Transmission Trigger (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*))

Configure the SIF sending trigger when "[Program Type \(→page 281\)](#)" is set to "0010" or "0100-1111."  
This can be configured for each recipient. Select the number to configure from No.1 - No.16 in **[Display Settings]**.

##### ■ Begin Outgoing Call (except IXW-MA)

Description	Send SIF command when outgoing call is placed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

##### ■ Begin Communication (Source) (except IXW-MA)

Description	Send SIF command when beginning communication.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

##### ■ Door Release Indication (for IX-MV7-\* and IX-RS-\*)

Description	Send SIF command when door release request is sent.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

##### ■ End Communication (except IXW-MA)

Description	Send SIF command when ending communication.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

##### ■ Change contact

Description	Send SIF command when Option Input contact or Relay Output contact is changed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Unit error

Description	Send SIF command when communication error has occurred.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Begin broadcast (for IX-MV7-\*)

Description	Send SIF command when page, message page, or external input page is started.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ End broadcast (for IX-MV7-\*)

Description	Send SIF command when page, message page, or external input page has ended.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Begin Transfer (for IX-MV7-\*)

Description	Send SIF command when communication begins after transferring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ End Transfer (for IX-MV7-\*)

Description	Send SIF command when communication ends after transferring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Periodical Transmission

Description	Periodically send the station status using SIF command. The interval is set in <a href="#">“Periodical Transmission (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*)) (→page 290)”</a> .
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Initialization Notice

Description	Send SIF command when the station is booted.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ End Outgoing Call (except IXW-MA)

Description	Send SIF command when ending a outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Begin Incoming Call (except IXW-MA)

Description	Send SIF command when beginning a incoming call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ End Incoming Call (except IXW-MA)

Description	Send SIF command when ending a incoming call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Latch Reset (except IX-MV7-\* and IXW-MA)

Description	Send SIF command by reset latch relay output. ("Latch Output" is selected in "Relay Output" - <a href="#">"Function (→page 245)"</a> .)
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Change Call Destination (except IXW-MA)

Description	Send SIF command when changing call destination by delay time or schedule, or making an absent transfer, delay transfer or schedule transfer by the destination station.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Call Failure (except IXW-MA)

Description	Send SIF command when failed to place a call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Begin Incoming Transfer Call (for IX-MV7-\*)

Description	Send SIF command when beginning Absent Transfer, Delay Transfer or Schedule Transfer.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin On Hold (for IX-MV7-\*)**

Description	Send SIF command when beginning a call on hold.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End On Hold (for IX-MV7-\*)**

Description	Send SIF command when ending a call on hold.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Incoming Page (except IXW-MA)**

Description	Send SIF command when beginning a incoming page, message page, or external input page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Incoming Page (except IXW-MA)**

Description	Send SIF command when ending a incoming page, message page, or external input page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Paging Failure (for IX-MV7-\*)**

Description	Send SIF command when failed to send a page, message page, or external input page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Monitoring (for IX-MV7-\*)**

Description	Send SIF command when beginning monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Monitoring (for IX-MV7-\*)**

Description	Send SIF command when ending monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Monitoring Failure (for IX-MV7-\*)**

Description	Send SIF command when failed monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Monitored (except IX-MV7-\* and IXW-MA)**

Description	Send SIF command when the monitoring of this station begins.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Monitored (except IX-MV7-\* and IXW-MA)**

Description	Send SIF command when the monitoring of this station ends.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Communication (Destination) (except IXW-MA)**

Description	Send SIF command when communication begins.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Privacy (for IX-MV7-\*)**

Description	Send SIF command when privacy mode begins.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Privacy (for IX-MV7-\*)**

Description	Send SIF command when privacy mode ends.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Keypad Input (for IX-MV7-\*)**

Description	Send SIF command when entering number using a keypad.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Speed Dial Input (for IX-MV7-\*)

Description	Send SIF command when pressing a speed dial button.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Begin Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when beginning recording.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ End Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when recording ends.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Recording Memory Full (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	<p>Send SIF command when a microSD card meets following criteria. If the error is detected continuously, SIF command will not be sent an additional time.</p> <ul style="list-style-type: none"> <li>• When <a href="#">"Prevent Overwrite (→page 298)"</a> is set to "Enable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 950</li> <li>– Storage capacity remaining 5%</li> </ul> </li> <li>• When <a href="#">"Prevent Overwrite (→page 298)"</a> is set to "Disable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 999</li> <li>– Storage capacity remaining 0%</li> </ul> </li> </ul>
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Passed Line Supervision (for IX-MV7-\*)

Description	Send SIF command when the result of Line Supervision is "Passed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Failed Line Supervision (for IX-MV7-\*)

Description	Send SIF command when the result of Line Supervision is "Failed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Passed Device Check (for IX-MV7-\*)

Description	Send SIF command when the result of Device Check is "Passed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Failed Device Check (for IX-MV7-\*)

Description	Send SIF command when the result of Device Check is "Failed".
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ SD Card Error (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when a microSD access error is detected.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ SIP Registration Failure (except IXW-MA)

Description	Send SIF command when REGISTER request for SIP server has a failure.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Network Camera Event (for IX-MV7-\*)


Description	Send SIF command when receiving event from the network camera.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**How to select event display**

Select an event (SIF sending trigger) to display on the Settings screen. Only the selected SIF sending trigger will be displayed.

This will be used for No.01 - No.16.

Click Event View Selection. The following screen will be shown.



- 1.** Select the event(s) (SIF sending trigger) from "Event List" (multiple selections allowed).
  - To select or unselect all events at once, click **[Select]** or **[Unselect]**.
  - By default, all events are displayed.
- 2.** Click **[OK]**.
  - Click **[Cancel]** to exit the event display selection.

## 7.7.5 Periodical Transmission (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*))

Select periodic transmission in **[Display Settings]**.

### 7.7.5.1 Periodical Transmission Interval

#### ■ Range

Description	Set the interval to send the station status periodically using SIF command in <a href="#">"Periodical Transmission (→page 283)"</a> . This will be used for No.1 - No.16.
Settings	<ul style="list-style-type: none"> <li>• 1[sec]-59[sec]</li> <li>• 0[min]-1440[min]</li> </ul>
Default values	0[min]-1440[min]

#### ■ Interval◆

Description	Set the interval to send Periodical Transmission from selected "Range." This will be used for No.1 - No.16.
Settings	<p>The setting value as follows depends on "Range."</p> <ul style="list-style-type: none"> <li>• If set to 1[sec]-59[sec]: Configure from 1 - 59 sec (by 1 sec).</li> <li>• If set to 0[min]-1440[min]: Set from 0 (do not send) - 1440 min (by 1 min).</li> </ul>
Default values	0 min (do not send)

## 7.7.6 Upload SIF File

Upload the information in "[SIF Settings \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 475\)](#)" using the file extension of "sif.ini," and upload the SIF parameter settings when "[Program Type \(→page 281\)](#)" is set to "0000," "0001," or "0011" using the file extension of "sif\_conf.ini."

If **[Upload SIF File]** is clicked, the following window will be shown.

**Upload SIF File**

Select file(s) to upload 1  
 SIF Communication Settings (sif.ini)  
 SIF Parameter Settings (sif\_conf.ini)

Select Station(s) by type: 2

Select	Number	Name	Location	Station Type	Status	
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	<div style="text-align: right; font-size: small; color: red;">Text in red are required settings.</div>
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-	

Select Station by Type: 3

4


### ! Important

- To upload a SIF setting file, "[Association Settings \(→page 160\)](#)" must be performed in the uploading station. And the programming PC and the station must be connected to the same network.

### How to upload SIF setting files

1. Select the type of SIF file being uploaded.
2. Click **[Browse]** and select the file to be uploaded.
3. Select the station to upload the SIF setting file from "Station List."
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations in which "[Association Settings \(→page 160\)](#)" has not been performed cannot be selected.
4. Click **[Start Upload]**.

5. Click **[OK]**.
  - Click **[Cancel]** to back to "Upload SIF File" window without uploading the file.



6. Click **[OK]**.
  - The results are displayed in "Status" in "Station List."
    - Success: Upload is completed.
    - Failed: Upload failed.

## 7.7.7 Download SIF File

Download the content in "[SIF Settings \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, IX-SS\(-\\*\)\) \(→page 281\)](#)" with "sif.ini" and download the uploaded "sif\_conf.ini."

If **[Download SIF File]** is clicked, the following window will be shown.

**Download SIF File**

Select file(s) to download 1  
 SIF Communication Settings (sif.ini)  
 SIF Parameter Settings (sif\_conf.ini)

Click "Browse" and select the folder where the SIF file will be saved. 2

Select	Number	Name	Location	Station Type	Status	
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	<div style="text-align: right; font-size: small; color: red;">Text in red are required settings.</div>
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-	

Select Station by Type:

4


### ! Important

- To download a SIF setting file, "[Association Settings \(→page 160\)](#)" must be performed in the downloading station. The programming PC and the station must be connected to the same network.

### How to download SIF setting files

1. Select the type of SIF file being downloaded.
2. Click **[Browse]** and select the folder to download.
3. Select the station to download the SIF setting file from "Station List."
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations in which "[Association Settings \(→page 160\)](#)" has not been performed cannot be selected.
4. Click **[Start Download]**.

5. Click **[OK]**.
  - Click **[Cancel]** to back to "Download SIF File" window without downloading.



6. Click **[OK]**.
  - The results are displayed in "Status" in "Station List."  
Success: Download is completed.  
Failed: Download failed.

## 7.8 Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Configure settings related to video and audio recording. If there is no video, configure only audio recording. When recording audio during a call, audio will be recorded from both sides. The following SD standards are required to record video and audio.

Standard	Storage Capacity	Format	Speed class
microSDHC	Max. 32 GB	FAT32	SD speed class 10
microSDXC (for IX-MV7-*)	Max. 128 GB	exFAT	SD speed class 10 UHS speed class 1

### ! Important

- A microSD card is not included with this station.
- The device may not operate correctly depending on the microSD card.
- If the card contains data other than video/audio files, it may not have enough space to record video/audio.
- The network camera may not be able to record video, depending on the size of the video.

### 💡 Note

- A maximum of 999 video/audio files can be saved. However, this may vary depending on the size of the video/audio files and the capacity of the microSD card.
- Line Supervision and Device Check results are also saved to the microSD card.
- Iphone assumes no responsibility for microSD cards. Please be aware of this in advance.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

["Weekly Schedule \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\)\) \(→page 300\)"](#)

#### Move to Related Settings

Moves to the selected item within the same Settings screen.

The screenshot shows the 'Record' settings screen. At the top, there are navigation buttons: 'Row' (with 'Previous' and 'Next' sub-buttons), 'Enter Number' (with a 'Display' button), '[Display Settings]', '[Weekly Schedule]', '[Move to Related Settings]', and 'Record Mode' (a dropdown menu). Below these is a 'Schedule View Adjustment' section. A yellow banner contains the text: 'Number of Notes: 2' followed by two numbered instructions: '1. The schedule is automatically sorted by Start Time after updating.' and '2. To upload Weekly Schedule to the station, upload schedule file using "Upload Settings To Station".' Below the banner is a table with two main sections: 'Station Information' and 'Function Settings'. The 'Station Information' table has columns for '#', 'Number', 'Name', 'Location', and 'Station Type'. The 'Function Settings' table has columns for 'Record Mode' and 'Record Event' (with sub-columns for 'Incoming Call', 'Communication (Master)', 'Monitor', 'Outgoing Call', 'Communication (Door)', and 'Mc'). The first row of the 'Station Information' table is highlighted in blue.

Station Information					Function Settings						
#	Identification				Record Mode	Record Event					
	Number	Name	Location	Station Type		Incoming Call	Communication (Master)	Monitor	Outgoing Call	Communication (Door)	Mc
0001	0001	Master Stations1		IX-MV7-*		No	No	No			
0002	0002	Master Stations2		IX-MV7-*		No	No	No			
0003	0003	Master Stations3		IX-MV7-*		No	No	No			
0004	0004	Master Stations4		IX-MV7-*		No	No	No			
0005	0005	Master Stations5		IX-MV7-*		No	No	No			

---

---

**7.8.1 Record Mode (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))**

---

---

Description	Select the Record Mode.
Settings	<ul style="list-style-type: none"><li>• No Recording</li><li>• Event Recording: Automatically record when the trigger set in "Record Event" has occurred.</li><li>• 24/7 Recording: Continuous recording while the station is operating normally.</li></ul>
Default values	No Recording

## 7.8.2 Record Event

Configure the trigger in use to start recording video/audio automatically.  
For stations other than IX-MV7-\*, this is only the case when "Record Mode" is set to "Event Recording."

### ■ Incoming Call (for IX-MV7-\*)

Description	Video Recording starts when station receives an incoming call. If a call is automatically answered, recording will start when communication starts.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### ■ Communication (Master) (for IX-MV7-\*)

Description	Recording starts when communication begins.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### ■ Monitor (for IX-MV7-\*)

Description	Recording starts when monitoring begins. Recording is not possible during Scan Monitor.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### ■ Outgoing Call (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	IX-DV, IX-DVF(-*): Video recording will start when a call is placed. Audio recording will start once the outgoing call is answered. IX-SSA(-*): Audio recording will start once the outgoing call is answered.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### ■ Communication (Door) (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Recording starts when communication begins.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### ■ Monitored (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Recording starts when station is Monitored. Recording is not possible during Scan Monitor.
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

## ■ Schedule (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Record during schedule set in <a href="#">"Weekly Schedule (for IX-DV, IX-DVF(-*), IX-SSA(-*))" (→page 300)</a> .
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### Important

- Video/audio recording will continue for the time set in ["Weekly Schedule \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\)\)" \(→page 300\)](#), regardless of what is configured for other triggers.

## 7.8.3 Recorded Device (for IX-MV7-\*)

Description	Set the Recorded Device when IX-MV7-* is displaying video from an IX Station and a Network Camera simultaneously.
Settings	<ul style="list-style-type: none"> <li>• IX Station: Record IX station video</li> <li>• Network Camera: Record network camera video</li> </ul>
Default values	IX Station

## 7.8.4 Prevent Overwrite

Description	Set prevent overwriting the old recorded file, when the number of saved video/audio files, the entire storage space of the microSD card, or the video/audio recording storage space of the microSD card is full.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 7.8.5 Video Recording File Length

Description	Select the recording file length to split recording. Once recording has reached this time, a new recording file will be created automatically.
Settings	<ul style="list-style-type: none"> <li>• 5 min</li> <li>• 10 min</li> <li>• 20 min</li> <li>• 40 min</li> <li>• 60 min</li> </ul>
Default values	10 min

### Note

- If the Video Recording File Length is changed during recording video/audio, the setting will not be applied until the recording is completed.

### 7.8.6 Event Recording Timer (for IX-MV7-\*)

Description	Set the recording duration when the event trigger has occurred.
Settings	<ul style="list-style-type: none"> <li>• Disable: Does not stop until the operating status ends or the record button is tapped.</li> <li>• 5 sec</li> <li>• 10 sec</li> <li>• 30 sec</li> </ul>
Default values	Disable

### 7.8.7 Manual Recording (for IX-MV7-\*)

Description	Select Enable / Disable for manual recording.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

### 7.8.8 Audio Recording (for IX-MV7-\*, IX-DV, IX-DVF(-\*))

Description	Select Enable / Disable for audio recording with video.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

### 7.8.9 Weekly Schedule (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Configure this when "Record Event" - "[Schedule \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\)\) \(→page 298\)](#)" is set to "Yes." Configure the video and audio recording time for each day from Sunday to Saturday. Up to 12 schedules can be set for each day.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Weekly Schedule**

Select the day and schedule range to configure. The Settings screen is displayed.

["How to configure schedule display \(→page 301\)"](#)

■ **Start Time**

Description	Set the Start Time to begin recording.
Settings	00:00 - 23:59
Default values	-

■ **End Time**

Description	Set the End Time to stop recording. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

### How to configure schedule display

Configure the day and schedule range shown on the Settings screen for the weekly schedule.

The display can be filtered to show only the day and schedule to configure.

Click Schedule View Adjustment. The following screen will be shown.

IX Support Tool- [Schedule View Adjustment]

### Schedule View Adjustment

1. Select the day of the week to display (Multiple selection available)

Select	Day
<input checked="" type="checkbox"/>	Weekly
<input checked="" type="checkbox"/>	Sun
<input checked="" type="checkbox"/>	Mon
<input checked="" type="checkbox"/>	Tue
<input checked="" type="checkbox"/>	Wed
<input checked="" type="checkbox"/>	Thu
<input checked="" type="checkbox"/>	Fri
<input checked="" type="checkbox"/>	Sat

Select Unselect

2. Display range for the schedule. (Between from 1 to 12)

1 - 3

OK Cancel

Text in red are required settings.

1. Select the day to display(s) from "Day" (multiple selections allowed).
  - To select or unselect all days at once, click **[Select]** or **[Unselect]**.
  - By default, all days are shown.
2. Select the range of schedules to display (1 - 12) that can be configured for each day of the week.
  - By default, the range of 1 - 3 is shown.
3. Click **[OK]**.
  - Click **[Cancel]** to set the schedule display.

## 7.9 Communication Audio Messages (for IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G)

Configure the communication audio message.

Communication Audio Messages: Send messages to destination station when beginning communication or by keypad input from the other station (IX-MV7-\*).

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

Station Information				Function Settings									
#	Identification			Communication Audio Messages									
	Number	Name	Location	Station Type	Start Communication				Code Received				
					No.01		No.02		No.03		No.04		
Message	Code	Message	Code	Message	Code	Message	Code	Message	Code				
0045	0045	Handset Sub Statio		IX-RS-*	None		None		None		None		None
0044	0044	Handset Sub Statio		IX-RS-*	None		None		None		None		None
0043	0043	Handset Sub Statio		IX-RS-*	None		None		None		None		None
0042	0042	Handset Sub Statio		IX-RS-*	None		None		None		None		None
0041	0041	Handset Sub Statio		IX-RS-*	None		None		None		None		None

### 7.9.1 Start Communication

#### Message

Description	Select the message to be sent to destination station when beginning communication.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

## 7.9.2 Code Received

Configure the message to be sent when the code is received. Four patterns can be set for the received code and message.

### Code

Description	Set the code to play message by keypad input from IX-MV7-*
Settings	1-20 digits
Default values	-



### Note

- Enter " \* \*Door Release Authorization\*" using the keypad (if the Door Release Authorization is "0000" enter " \* \*0000\*").

### Message

Description	Set the code to play message by keypad input from IX-MV7-*
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	None

## 7.10 Chime (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Configure the chime tone to be played from this station linked with the set schedule.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

### Weekly Schedule

Select the day and schedule range to configure. The Settings screen will be shown.

[“Weekly Schedule \(→page 304\)”](#)

[“Daily Schedule \(→page 306\)”](#)

### Move to Related Settings

Moves to the selected item within the same Settings screen.

Number of Notes 2

1. The schedule is automatically sorted by Start Time after updating.  
2. To upload Weekly Schedule , Daily Schedule to the station, upload schedule file using "Upload Settings To Station".

#	Station Information				Function Settings							
	Identification				Chime							
	Number	Name	Location	Station Type	Sun 01		Sun 02		Sun 03		Mon 01	
				Start Time	Chime	Start Time	Chime	Start Time	Chime	Start Time	Chime	
0001	0001	Master Stations1		IX-MV7-*		None		None		None		None
0002	0002	Master Stations2		IX-MV7-*		None		None		None		None
0003	0003	Master Stations3		IX-MV7-*		None		None		None		None
0004	0004	Master Stations4		IX-MV7-*		None		None		None		None
0005	0005	Master Stations5		IX-MV7-*		None		None		None		None

### 7.10.1 Weekly Schedule

Configure the start time and the chime tone for every day from Sunday through Saturday. 50 schedules can be set for each day.

#### ■ Start Time


Description	Set the Time to ring Chime.
Settings	00:00 - 23:59
Default values	-

## ■ Chime

Description	Set the sound for chime.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	None

### How to configure schedule display

Configure the day and schedule range shown on the Settings screen for the weekly schedule. The display can be filtered to show only the day and schedule to configure. Click Schedule View Adjustment. The following screen will be shown.



1. Select the day(s) to display from "Day" (multiple selections allowed).
  - To select or unselect all days at once, click **[Select]** or **[Unselect]**.
  - By default, all days are shown.

2. Select the range of schedules to display (from 1 to 50) that can be configured for each day of the week.
  - By default, the range of 1 - 3 is shown.
3. Click **[OK]**.
  - Click **[Cancel]** to set the schedule display.

### 7.10.2 Daily Schedule

Configure the start time and the chime tone in units of one day.

A schedule one year from the set day can be configured. 50 schedules can be set for each day.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

#### Daily Schedule

Select the date and schedule range to configure. The Settings screen will be shown.

1. Select the date from the drop down menu.
2. Select the range of schedules to display (from 1 to 50) that can be configured for each day.
  - By default, the range of 1 - 3 is shown.
3. Click **[Change to Daily Schedule Display]**.

The screenshot shows the 'Daily Schedule' configuration screen. At the top, there are controls for 'Row' selection (Previous, Next, Display) and a 'Daily Schedule' section with a date dropdown (10/19/2018) and a 'Display Range' (1-3). A calendar for October 2018 is visible, with the 19th selected. Below the calendar is a table of station settings with columns for Station Information, Function Settings, and Daily Schedule. The table lists stations 0001 through 0012. A red box highlights the 'Change to Daily Schedule Display' button.

#	Station Information				Function Settings		Daily Schedule		
	Number	Name	Location	Station Type	Chime	Start Time	Chime	Start Time	Chime
0001	0001	Master Stations1		IX-MV7-*	None		None		None
0002	0002	Master Stations2		IX-MV7-*	None		None		None
0003	0003	Master Stations3		IX-MV7-*	None		None		None
0004	0004	Master Stations4		IX-MV7-*	None		None		None
0005	0005	Master Stations5		IX-MV7-*	None		None		None
0011	0011	Video Stations1		IX-DV, IX-DVF(-)	None		None		None
0012	0012	Video Stations2		IX-DV, IX-DVF(-)	None		None		None

## ■ Start Time

Description	Set the Time to ring Chime.
Settings	00:00 - 23:59
Default values	-

## ■ Chime

Description	Set the sound for chime.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

## 7.11 CSR

Generate the signature request (CSR) submitted when a request is made to the Server Certificate Authority (CA)

Generate the signature request according to each station's settings. [“CSR \(→page 495\)”](#)

## 7.12 SSL Certificate

Upload the Server Certificate received from the Certificate Authority (CA) as well as the CA certificate.

### ! Important

- To upload an SSL certificate, [“Association Settings \(→page 160\)”](#) must have been completed on the station, and the PC must be able to communicate with the system.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

[“How to upload the SSL certificate to each station \(→page 311\)”](#)

Number of Notes: 1 1. Changing SSL Certificate settings will cause station to restart after Update is clicked. This will take a few minutes.

#	Station Information				Function Settings							
	Identification				SSL Certificate							
	Number	Name	Location	Station Type	Server Certificate				CA Certificate			
				Name	File	Browse...	Delete	Name	File	Browse...	Delete	
0001	0001	Master Stations1		IX-MV7-*			Browse	<input type="checkbox"/>				
0002	0002	Master Stations2		IX-MV7-*			Browse	<input type="checkbox"/>				
0003	0003	Master Stations3		IX-MV7-*			Browse	<input type="checkbox"/>				
0004	0004	Master Stations4		IX-MV7-*			Browse	<input type="checkbox"/>				
0005	0005	Master Stations5		IX-MV7-*			Browse	<input type="checkbox"/>				

#### How to register SSL certificates

1. Click **[Browse]** of the station to upload the server certificate and then select a file.
2. If required, click **[Browse]** of the station to upload the CA certificate and then select a file.
3. The reference destination of the file selected in "File" is displayed.
4. Click **[Update]**.
  - The name of the file registered in "Name" is displayed.
  - Server certificate and CA certificate files are saved in "aiphone" - "AIPHONE\_IX\_SupportTool" - "SystemData" within the folder specified during installation for each station.
5. Click **[OK]**.
6. Click **[Upload SSL Certificate]** to upload certificates to each station. Refer to [“How to upload the SSL certificate to each station \(→page 311\)”](#).

### ! Important

- The server certificate must be uploaded when uploading a CA certificate.

### How to delete a registered SSL certificate

- 1.** Check the **[Delete]** box of the server certificate or CA certificate to delete.
- 2.** Click **[Update]**.
  - The server certificate or CA certificate file will be deleted from the PC folder in which the file was saved in step 4 of "How to register SSL certificates."
- 3.** Click **[OK]**.

## 7.12.1 How to upload the SSL certificate to each station

Click **[Upload SSL Certificate]**. The following window will be shown.

### Certification Update/Delete

Chose a security certification to be uploaded.

SSL Certificate  
Upload certificate set for each device.

IEEE802.1X Certificate  
Select Certificate Authority File

Select Client Certificate File

Select Client Private Key File

Select the station(s) to upload the Setting File(s):

Station List						Text in red are required settings.
Select	Number	Name	Location	Station Type	Status	
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-	

Select Station by Type:  
   2

### Important


- When uploading the SSL certificate, restart the station. Restart may take up to 10 minutes in total. The station will not operate until restart is complete.

### How to upload an SSL certificate

1. Select the station(s) to upload a certificate from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations in which ["Association Settings \(→page 160\)"](#) has not been performed cannot be selected.
2. Click **[Upload]**.

**3.** Click **[OK]**.

- The server certificate or CA certificate file is uploaded to the station, and the station is restarted.
- Click **[Cancel]** to return to the "Certification Update/Delete" screen without uploading.



**4.** Click **[OK]**.

- The results are displayed in "Status" in "Station List."  
In Process: Uploading the certificate.  
Success: Upload is completed.  
Failed: Upload failed.

## 7.13 IEEE 802.1X (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure the settings for IEEE802.1X Authentication.

### Move row


Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

["How to upload/delete the IEEE802.1X Certificate to each station \(→page 315\)"](#)



#	Station Information				Function Settings			
	Number	Name	Location	Station Type	IEEE 802.1X	EAP	EAP User Name	EAP Password
0001	0001	Master Stations 1		IX-MV7-*	Disable	TLS		
0002	0002	Master Stations 2		IX-MV7-*	Disable	TLS		
0003	0003	Master Stations 3		IX-MV7-*	Disable	TLS		
0004	0004	Master Stations 4		IX-MV7-*	Disable	TLS		
0005	0005	Master Stations 5		IX-MV7-*	Disable	TLS		

### ! Important

- Authentication may be impossible if there is a time difference between the authentication server and station.
- Upload the certificate prior to configuration.
- To Update/Delete an IEEE802.1X Certificate, ["Association Settings \(→page 160\)"](#) must have been performed on the station to upload/delete, and the PC must be able to communicate with the system.
- When changes to IEEE802.1X settings are updated on the station, or after uploading a certificate, restart the station. Restart may take up to 10 minutes in total. The station will not operate until restart is complete.

### ■ IEEE 802.1X

Description	Select Enable / Disable for IEEE802.1X function.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ■ EAP

Description	Select the EAP method for IEEE802.1X authentication when <a href="#">"IEEE 802.1X (→page 313)"</a> is set to "Enable".
Settings	<ul style="list-style-type: none"> <li>• TLS</li> <li>• PEAP</li> </ul>
Default values	TLS

## ■ EAP User Name

Description	Set the EAP User Name.
Settings	1 - 32 alphanumeric characters
Default values	-

## ■ EAP Password

Description	Set the EAP Password when "EAP" is set to "PEAP".
Settings	1 - 32 alphanumeric characters
Default values	-



### Note

- "EAP Password" is shown as "\*\*\*\*\*" in the Settings screen.

### 7.13.1 How to upload/delete the IEEE802.1X Certificate to each station

Click **[IEEE802.1X Certificate Update/Delete]**. The following window will be shown.

Chose a security certification to be uploaded.

SSL Certificate  
Upload certificate set for each device.

IEEE802.1X Certificate

1 Select Certificate Authority File  
[Text Input] [Browse]

2 Select Client Certificate File  
[Text Input] [Browse]

3 Select Client Private Key File  
[Text Input] [Browse]

Select the station(s) to upload the Setting File(s):

Select	Number	Name	Location	Station Type	Status
<input checked="" type="checkbox"/>	0001	Master Stations 1		IX-MV7-*	-
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-
<input type="checkbox"/>	0009	Master Stations9		IX-MV	-

Select Station by Type: [All] [Select] [Unselect]


[Delete] [Upload]

#### How to upload/delete IEEE802.1X certificates

To delete, start from Step 4.

1. Click **[Browse]** next to the Certificate Authority File to select a file.
2. If "[EAP \(→page 313\)](#)" was set to "TLS," click **[Browse]** next to the Client Certificate File to select a file.
3. If "EAP" was set to "TLS," click **[Browse]** next to the Client Private Key File to select a file.
4. Select the station(s) to upload/delete the file from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations in which "[Association Settings \(→page 160\)](#)" has not been performed cannot be selected.
5. Click **[Upload]** or **[Delete]**.

6. Click **[OK]**.
- The file will be uploaded/deleted and the station will restart.
  - Click **[Cancel]** to back to the "Certification Update/Delete" screen without uploading/deleting.



7. Click **[OK]**.
- The results are displayed in "Status" in "Station List."
    - In Process: The file is being uploaded/deleted.
    - Success: Upload/delete is completed.
    - Failed: Upload/delete failed. Try uploading/deleting again.

## 7.14 Display Mode (for IX-MV7-\*)

Configure IX-MV7-\* Master UI Mode, for both Standard and Receptionist modes.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Jump to related item

Moves to the selected item within the same Settings screen.

The screenshot shows a settings interface with a 'Row' control at the top left containing 'Previous', 'Next', and 'Display' buttons, and a 'Master UI Mode' dropdown menu at the top right. Below these is a 'Number of Notes:3' section with two numbered instructions: '1. Changing Display Mode settings will cause station to restart after Update is clicked. This will take a few minutes.' and '2. To upload Image to the station, upload image file using "Upload Settings To Station"'. The main table is titled 'Station Information' and 'Function Settings'.

#	Station Information				Function Settings											
	Identification				Display Mode											
	Number	Name	Location	Station Type	Master UI Mode	Standard Mode	Receptionist Mode		Company Information							
					Home Screen	Color Scheme	Screen Layout	Name	Text Size	Bold	Text Color					
0001	0001	Master Stations1		IX-MV7-*	Standard	Option 1	Light	Layout 1		12	OFF	Option 1				
0002	0002	Master Stations2		IX-MV7-*	Standard	Option 1	Light	Layout 1		12	OFF	Option 1				
0003	0003	Master Stations3		IX-MV7-*	Standard	Option 1	Light	Layout 1		12	OFF	Option 1				
0004	0004	Master Stations4		IX-MV7-*	Standard	Option 1	Light	Layout 1		12	OFF	Option 1				
0005	0005	Master Stations5		IX-MV7-*	Standard	Option 1	Light	Layout 1		12	OFF	Option 1				

### 7.14.1 Master UI Mode

Description	Set the User Interface Mode.
Settings	<ul style="list-style-type: none"> <li>Standard: All functions can be used.</li> <li>Receptionist: Only outgoing call can be used. Refer to <a href="#">"Receptionist Mode (→page 319)"</a> for detail settings.</li> </ul>
Default values	Standard

### ! Important

- When the "Master UI Mode" setting is applied to the station it will restart. This may take up to 10 minutes and the station cannot be used until it has finished restarting.

7.14.2 Standard Mode

■ Home Screen

Description	Select the layout of top image when "Master UI Mode (→page 317)" is set to "Standard."
Settings	<p>• Option 1:</p>  <p>• Option 2:</p> 
Default values	Option 1

### 7.14.3 Receptionist Mode

Configure Receptionist Mode screen if "Receptionist" was set in ["Master UI Mode \(→page 317\)"](#).

#### Important

- During receptionist mode, operations are limited to the following.
  - The outgoing call method is limited to the method configured in ["Button Function \(→page 325\)"](#).
  - Calls will be automatically answered even if ["Auto Answer \(→page 237\)"](#) is set to "OFF." However, the call will not be received if ["Reject Incoming Call \(→page 326\)"](#) is set to "Enable."
  - For "Option Input" - ["Function \(→page 242\)"](#), only "Call" and "Turn LCD On" are valid.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.


**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

#### Move to Related Settings

Moves to the selected item within the same Settings screen.




Number of Notes: 3




1. Changing Display Mode settings will cause station to restart after Update is clicked. This will take a few minutes.
2. To upload Image to the station, upload image file using "Upload Settings To Station".

#	Station Information				Function Settings						
	Identification				Display Mode						
	Number	Name	Location	Station Type	Receptionist Mode		Company Information			Greeting Information	
				Color Scheme	Screen Layout	Name	Text Size	Bold	Text Color	Greeting	
0001	0001	Master Stations1		IX-MV7-*	Light	Layout 1		12	OFF	Option 1	
0002	0002	Master Stations2		IX-MV7-*	Light	Layout 1		12	OFF	Option 1	
0003	0003	Master Stations3		IX-MV7-*	Light	Layout 1		12	OFF	Option 1	
0004	0004	Master Stations4		IX-MV7-*	Light	Layout 1		12	OFF	Option 1	

7.14.3.1 Color Scheme

Description	Select the Color Scheme of Receptionist Mode.
Settings	<p>Example where "Layout 1" was set in <a href="#">"Screen Layout (→page 321)"</a></p> <ul style="list-style-type: none"> <li>• Light:</li> </ul>  <ul style="list-style-type: none"> <li>• Dark:</li> </ul> 
Default values	Light

7.14.3.2 Screen Layout


Description	Select the Screen Layout of top image for Receptionist Mode.
Settings	<p>Example where "Light" was set in <a href="#">"Color Scheme (→page 320)"</a></p> <ul style="list-style-type: none"> <li>• Layout 1:            </li> <li>• Layout 2:            </li> <li>• Layout 3:            </li> </ul>
Default values	Layout 1

## Customizing each screen layout


The layout of each screen's characters, images, and button displays can be customized.

The following spaces are customized by configuring [“Company Information \(→page 323\)”](#), [“Greeting Information \(→page 323\)”](#), [“Images \(→page 324\)”](#), and [“Button Function \(→page 325\)”](#).


Layout 1



Layout 2



Layout 3



### 7.14.3.3 Company Information

#### ■ Name

Description	Enter the Company Information.
Settings	0-40 alphanumeric characters
Default values	-

#### ■ Text Size◆

Description	Set the text size of Company Information.
Settings	12 - 24 pt (by 1pt)
Default values	12pt

#### ■ Bold

Description	Select ON / OFF for Bold text.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• ON</li> </ul>
Default values	OFF

#### ■ Text Color

Description	Set the text color of Company Information.
Settings	<ul style="list-style-type: none"> <li>• Option 1 "Black" if "Light" was set in <a href="#">"Color Scheme (→page 320)"</a>. "White" if "Dark" was set.</li> <li>• Option 2 "Blue" if <a href="#">"Color Scheme (→page 320)"</a> was set to "Light." "Orange" if "Dark" was set.</li> </ul>
Default values	Option 1

### 7.14.3.4 Greeting Information

#### ■ Greeting

Description	Enter Greeting text.
Settings	0-100 alphanumeric characters (Up to 10 line breaks can be inserted. Insert a line break by pressing "Alt" + "Enter.")
Default values	-

#### ■ Text Size◆

Description	Set the text size of Greeting.
Settings	12 - 70 pt (by 1 pt)
Default values	12pt

#### ■ Bold

Description	Select ON / OFF for Bold text.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• ON</li> </ul>
Default values	OFF

## ■ Text Color

Description	Configure the character color displayed in Greeting Information.
Settings	<ul style="list-style-type: none"> <li>Option 1 "Black" if "Light" was set in <a href="#">"Color Scheme (→page 320)"</a>. "White" if "Dark" was set.</li> <li>Option 2 "Blue" if <a href="#">"Color Scheme (→page 320)"</a> was set to "Light." "Orange" if "Dark" was set.</li> </ul>
Default values	Option 1

### 7.14.3.5 Images

Upload the image file to display on the reception screen. Upload an image file that suits the layout configured in ["Screen Layout \(→page 321\)"](#). Refer to ["Customizing each screen layout \(→page 322\)"](#) for recommended image file resolutions for each screen layout.

## ■ Company Image

Description	Update Company Image. Supported file format <ul style="list-style-type: none"> <li>File name: within 20 characters (excluding extension)</li> <li>File format: png</li> <li>Resolution Width: 400 - 800 pixels Height: 80 - 480 pixels</li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Delete: Place a check in <b>[Delete]</b> .
Default values	-

## ■ Greeting Image

Description	Update Greeting Image. Supported file format <ul style="list-style-type: none"> <li>File name: within 20 characters (excluding extension)</li> <li>File format: png</li> <li>Resolution Width: 400 - 800 pixels Height: 80 - 480 pixels</li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Delete: Place a check in <b>[Delete]</b> .
Default values	-

## ■ Receptionist Image

Description	Update Receptionist Image. Supported file format <ul style="list-style-type: none"> <li>• File name: within 20 characters (excluding extension)</li> <li>• File format: png</li> <li>• Resolution Width: 400 - 800 pixels Height: 80 - 480 pixels</li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Delete: Place a check in <b>[Delete]</b> .
Default values	-



### Note

- Image file names can be deleted from the Settings screen by selecting "[Upload Settings To Station \(→page 145\)](#)" - "Image" to upload the setting file, and then deleting the image file from the station.

### 7.14.3.6 Button Function

Configure the buttons displayed on the reception screen and their functions. Refer to "[Customizing each screen layout \(→page 322\)](#)" while configuring.

#### ■ Button 1

Description	Set the function of Button 1.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by "<a href="#">Group Call Destination (→page 326)</a>".</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

#### ■ Button 2

Description	Set the function of Button 2.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by "<a href="#">Group Call Destination (→page 326)</a>".</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

#### ■ Button 3

Description	Set the function of Button 3.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by "<a href="#">Group Call Destination (→page 326)</a>".</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

## ■ Button 4

Description	Set the function of Button 4.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by "<a href="#">Group Call Destination (→page 326)</a>".</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

## ■ Button Name for Group Call

Description	Set the Button Name when Button 1 - 4 is assigned to "Group Call". If "Group Call" is set to multiple buttons, they will all share the same name.
Settings	1-24 alphanumeric characters
Default values	-

## ■ Button Name for Select By Name

Description	Set the Button Name when Button 1 - 4 is assigned to "Select By Name". If "Select By Name" is set to multiple buttons, they will all share the same name.
Settings	1-24 alphanumeric characters
Default values	-

## ■ Button Name for Select By List

Description	Set the Button Name when Button 1 - 4 is assigned to "Select By List". If "Select By List" is set to multiple buttons, they will all share the same name.
Settings	1-24 alphanumeric characters
Default values	-

## ■ Button Name for Enter Number

Description	Set the Button Name when Button 1 - 4 is assigned to "Enter Number". If "Enter Number" is set to multiple buttons, they will all share the same name.
Settings	1-24 alphanumeric characters
Default values	-

### 7.14.3.7 Group Call Destination

Description	Set the destination group when Button 1 - 4 is assigned to "Group Call". If "Group Call" is set for multiple buttons, they will all share the same call destination group. Enter the group number directly, or click <b>[Open]</b> to select group.
Settings	01 - 99
Default values	-

### 7.14.3.8 Reject Incoming Call

Description	Select Enable / Disable for incoming calls in Receptionist Mode.
Settings	<ul style="list-style-type: none"> <li>• Enable: Do not receive incoming calls.</li> <li>• Disable: Receive incoming calls.</li> </ul>
Default values	Disable

## 7.15 Bathroom Link

This function cannot be used outside Japan.

# 8. Transfer Settings

## 8.1 Absent Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for absent transfer.

Absent Transfer: If an incoming call is received during absent transfer, the incoming call will be automatically transferred to a transfer destination.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]**: Display the previous 50 rows.

**[Next]**: Display the next 50 rows.

**[Display]**: Enter the station number and click **[Display]** to move the cursor to the entered row.

### ! Important

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which ["IP Address \(→page 180\)"](#) has not been configured cannot be configured as transfer destinations.

### ■ Absent Transfer

Description	Select Enable / Disable for Absent Transfer. The setting can also be changed on the station. If "Transfer Destination List" is not configured, this cannot be set to "Enable."
Settings	<ul style="list-style-type: none"> <li>• Enable: Set absent transfer</li> <li>• Disable: Do not set absent transfer</li> </ul>
Default values	Disable

### ■ Transfer Destination List

Description	<p>Configure the transfer destination station (Number) for absent transfer. Up to 10 transfer destination stations (IX-MV: one station only) can be configured. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the transfer will be made only to the station entered in "No.01."</p> <p>Enter Number directly, or click <b>[Open]</b> to choose a station.</p> <p>For IX-MV, a VoIP phone cannot be set as the transfer destination.</p>
Settings	<p>IX-MV7-*: 3-32 digits</p> <p>IX-MV: 3-5 digits</p>
Default values	-

 Important

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

### ■ Re-Transfer Destination (for IX-MV7-\*)

Description	Configure the transfer destination station (number) for absent re-transfer for a transferred call. Only a single station can be configured as the transfer destination. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*) the call will be received without transferring it again. Enter the station number or click <b>[Open]</b> to choose one.
Settings	3-32 digits
Default values	-

## 8.2 Delay Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for delay transfer.

Delay Transfer: A call can be automatically transferred to another station after a certain period of time (delay time) elapses.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### ! Important

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which "[IP Address \(→page 180\)](#)" has not been configured cannot be configured as transfer destinations.

### ■ Delay Transfer

Description	Select Enable / Disable for Delay Transfer. To enable Delay Transfer, set transfer or re-transfer destination.
Settings	<ul style="list-style-type: none"> <li>• Enable: Delay transfer enabled</li> <li>• Disable: Delay transfer disabled</li> </ul>
Default values	Disable

### ■ Delay Time [sec]◆

Description	Set the delay time between receiving and transferring a call.
Settings	1-300 sec (by 1 sec)
Default values	30 sec

### ■ Transfer Destination List

Description	<p>Configure the transfer destination station (Number) for delay transfer. Up to 10 transfer destination stations (IX-MV: one station only) can be configured. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the transfer will be made only to the station entered in "No.01."</p> <p>Enter Number directly, or click <b>[Open]</b> to choose a station.</p> <p>For IX-MV, a VoIP phone cannot be set as the transfer destination.</p>
Settings	<p>IX-MV7-*: 3-32 digits</p> <p>IX-MV: 3-5 digits</p>
Default values	-

 Important

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

■ Re-Transfer Destination (for IX-MV7-\*)

Description	Configure the transfer destination station (number) for delay re-transfer for a transferred call. Only a single station can be configured as the transfer destination. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the call will be received without transferring it again. Enter the station number or click <b>[Open]</b> to choose one.
Settings	3-32 digits
Default values	-

### 8.3 Schedule Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for Schedule Transfer.

Schedule Transfer: A call can be automatically transferred to another station when a call comes in during the time period set up in [“Weekly Schedule \(→page 333\)”](#) and [“Daily Schedule \(for IX-MV7-\\*\) \(→page 335\)”](#).

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Weekly Schedule**

Select the day and schedule range to configure. The Settings screen is displayed. [“Weekly Schedule \(→page 333\)”](#)

[“Daily Schedule \(for IX-MV7-\\*\) \(→page 335\)”](#)

**Move to Related Settings**

Moves to the selected item within the same Settings screen.

The screenshot shows the 'Schedule Transfer' settings page. At the top, there are navigation buttons: 'Row' (with 'Enter Number' and 'Display'), 'Previous', 'Next', and 'Schedule View Adjustment'. To the right, there are tabs for '[Display Settings]', '[Weekly Schedule]', and '[Daily Schedule]'. The '[Daily Schedule]' tab is active, showing a date '10/ 9/2018', a display range '1 - 3', and a 'Change to Daily Schedule Display' button. A 'Move to Related Settings' button is also visible. Below the navigation is a table with columns for '#', 'Number', 'Name', 'Location', 'Station Type', 'Schedule Transfer', and 'Transfer Destination List'. The table lists stations 0001 through 0007. A red box highlights the 'Schedule Transfer' column, and a note at the bottom right says 'Text in red are required settings.'

**! Important**

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which [“IP Address \(→page 180\)”](#) has not been configured cannot be configured as transfer destinations.
- Incoming calls will be transferred during the time period set in "Schedule Transfer," regardless of what was set in [“Absent Transfer \(for IX-MV7-\\* and IX-MV\) \(→page 328\)”](#) and [“Delay Transfer \(for IX-MV7-\\* and IX-MV\) \(→page 330\)”](#).

**■ Schedule Transfer**

Description	Select Enable / Disable for Schedule Transfer. To enable Schedule Transfer, configure <a href="#">“Weekly Schedule (→page 333)”</a> or <a href="#">“Daily Schedule (for IX-MV7-*) (→page 335)”</a> .
Settings	<ul style="list-style-type: none"> <li>• Enable: Schedule transfer enabled</li> <li>• Disable: Schedule transfer disabled</li> </ul>
Default values	Disable

### 8.3.1 Weekly Schedule

Configure the transfer destination and transfer time for every day from Sunday through Saturday.

For IX-MV7-\*, up to 12 schedules can be set for each day, and for the IX-MV, one schedule can be set for each day.

#### Transfer Destination List

Description	<p>Configure the transfer destination station (Number) for scheduled transfer.</p> <ul style="list-style-type: none"> <li>IX-MV7-*: Up to 10 transfer destination stations can be configured for each of the 12 schedules, and for each day of the week. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the transfer will only be made to the station entered in "No.01."</li> <li>IX-MV: Only a single transfer destination station can be set for each day of the week. Enter this in "No.01" for "Sun 01." A VoIP phone cannot be set as the transfer destination.</li> </ul> <p>Enter Number manually, or click <b>[Open]</b> to choose a station.</p>
Settings	<p>IX-MV7-*: 3-32 digits IX-MV: 3-5 digits</p>
Default values	-

#### ! Important

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

#### Re-Transfer Destination (for IX-MV7-\*)

Description	<p>Configure the transfer destination station (Number) when performing a scheduled transfer again for a transferred call. Only a single station can be configured as the transfer destination for each of the 12 schedules on each day of the week. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the call will be received without transferring it again.</p> <p>Enter the station number or click <b>[Open]</b> to choose one.</p>
Settings	3-32 digits
Default values	-

#### Start Time

Description	<p>Set the Start Time to enable schedule transfer.</p> <p>For IX-MV, configure this as the first schedule of each day of the week. For example, configure Sunday in "Sun 01."</p>
Settings	00:00 - 23:59
Default values	-

#### End Time

Description	<p>Set the End Time to disable schedule transfer. If this is set earlier than "Start Time," the end time will be for the following day.</p> <p>For IX-MV, configure this as the first schedule of each day of the week. For example, configure Sunday in "Sun 01."</p>
Settings	00:00 - 23:59
Default values	-

### How to configure schedule display

Configure the day and schedule range shown on the Settings screen for the weekly schedule.

The display can be filtered to show only the day and schedule to configure.

Click Schedule View Adjustment. The following screen will be shown.

IX Support Tool- [Schedule View Adjustment]

### Schedule View Adjustment

1. Select the day of the week to display (Multiple selection available)

Day **Text in red are required settings.**

Select	Weekly
<input checked="" type="checkbox"/>	Sun
<input checked="" type="checkbox"/>	Mon
<input checked="" type="checkbox"/>	Tue
<input checked="" type="checkbox"/>	Wed
<input checked="" type="checkbox"/>	Thu
<input checked="" type="checkbox"/>	Fri
<input checked="" type="checkbox"/>	Sat

Select Unselect

2. Display range for the schedule. (Between from 1 to 12)

1 - 3

OK Cancel

1. Select the day(s) to display from "Day" (multiple selections allowed).
  - To select or unselect all days at once, click **[Select]** or **[Unselect]**.
  - By default, all days are shown.
2. Select the range of schedules to display (1 - 12) that can be configured for each day of the week.
  - By default, the range of 1 - 3 is shown.
3. Click **[OK]**.
  - Click **[Cancel]** to return to the schedule display.

### 8.3.2 Daily Schedule (for IX-MV7-\*)

Configure the transfer destination and time for each individual day.  
 A schedule one year from the set day can be configured. 12 schedules can be set for each day.


**Move row**

Up to 50 station number rows can be displayed at a time.  
 Switch the display as follows.  
**[Previous]:** Display the previous 50 rows.  
**[Next]:** Display the next 50 rows.  
**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

**Daily Schedule**

Select the date and schedule range to configure. The Settings screen is displayed.

1. Select the date from the drop down menu.
2. Select the range of schedules to display (1 - 12) that can be configured for each day.
  - By default, the range of 1 - 3 is displayed.
3. Click **[Change to Daily Schedule Display]**.



### ■ Transfer Destination List

Description	Configure the transfer destination station (Number) for scheduled transfer. Up to 10 transfer destination stations can be configured for each of the 12 schedules for each day of the week. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the transfer will be made only to the station entered in "No.01." Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-32 digits
Default values	-

**! Important**

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

## ■ Re-Transfer Destination

Description	Configure the transfer destination station (Number) when performing scheduled re-transfer for a transferred call. Only a single station can be configured as the transfer destination for each of the 12 schedules on each day. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, or IX-SS(-*), the call will be received without transferring it again. Enter the station number or click <b>[Open]</b> to choose one.
Settings	3-32 digits
Default values	-

## ■ Start Time

Description	Set the Start Time to enable schedule transfer.
Settings	00:00 - 23:59
Default values	-

## ■ End Time

Description	Set the End Time to disable schedule transfer. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

## 8.4 Lock Transfer (for IX-MV7-\*)

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[ON]:** Enter the station number and click [Display] to move the cursor to the row of the entered station number.

Row
Previous
Next

Enter Number

Display

#	Station Information				Transfer Settings
	Identification				Lock Transfer
	Number	Name	Location	Station Type	
0001	0001	Master Stations1		IX-MV7-*	OFF
0002	0002	Master Stations2		IX-MV7-*	OFF
0003	0003	Master Stations3		IX-MV7-*	OFF
0004	0004	Master Stations4		IX-MV7-*	OFF
0005	0005	Master Stations5		IX-MV7-*	OFF

Text in red are required settings.

<b>Description</b>	Select ON / OFF to Lock Transfer function. When set to "ON", transfer function cannot be changed by user account.
<b>Settings</b>	<ul style="list-style-type: none"> <li>ON: Cannot be configured with user privileges.</li> <li>OFF: Can be configured with user privileges.</li> </ul>
<b>Default values</b>	OFF

# 9. Station Settings

## 9.1 Speed Dials / Favorites (for IX-MV7-\* and IX-MV)

Configure the settings for Speed Dial buttons of IX-MV7-\* and IX-MV.  
 Select the Speed Dial button number to configure in **[Display Settings]**.

**Move row**

Up to 50 station number rows can be displayed at a time. Switch the display as follows.  
**[Previous]**: Display the previous 50 rows.  
**[Next]**: Display the next 50 rows.  
**[Display]**: Enter the station number and click **[Display]** to move the cursor to the entered row.

**Display Settings**

Settings for the selected Speed Dial button number are displayed.

Station Information				Station Settings						
Identification				Speed Dials / Favorites						
#	Number	Name	Location	Station Type	Speed Dial 1					
					Speed Dial Name	Function	Individual Call	Group Call		
						Number	Station List	Priority	Group Number	Group Set
0001	0001	Master Stations1		IX-MV7-*		No Function		Open		Open
0002	0002	Master Stations2		IX-MV7-*		No Function		Open		Open
0003	0003	Master Stations3		IX-MV7-*		No Function		Open		Open
0004	0004	Master Stations4		IX-MV7-*		No Function		Open		Open
0005	0005	Master Stations5		IX-MV7-*		No Function		Open		Open
0006	0006	Master Stations6		IX-MV		No Function		Open		Open
0007	0007	Master Stations7		IX-MV		No Function		Open		Open
0008	0008	Master Stations8		IX-MV		No Function		Open		Open
0009	0009	Master Stations9		IX-MV		No Function		Open		Open
0010	0010	Master Stations10		IX-MV		No Function		Open		Open

### 9.1.1 Advanced Speed Dial Button Settings

Select the functions to assign to each Speed Dial button.  
 Up to eight Speed Dial buttons can be set for IX-MV7-\*, and six for IX-MV.

#### 9.1.1.1 Speed Dial Name (for IX-MV7-\*)

Description	Set the Speed Dial Name.
Settings	1-24 alphanumeric characters The entire name may not be shown on the station screen, depending on the number of characters.
Default values	-

## ! Important

- Enter button names in the language configure in "[Language \(→page 158\)](#)". However, if the language (configured on the station main unit) displayed on the screen for IX-MV7-\* differs from that set in "Language," the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.

### 9.1.1.2 Function

Description	Set the Speed Dial Function. The functions that can be selected differ between stations. Refer to " <a href="#">How to configure Individual Call (→page 339)</a> " for how to configure detailed functions.
Settings	<ul style="list-style-type: none"> <li>• No Function</li> <li>• Individual Call: Call individual station set in "Individual Call".</li> <li>• Group Call: Call group set in "Group Call".</li> <li>• Group Page: Page group set in "Group Page".</li> <li>• All Page: Page all stations.</li> <li>• Group Message Page (For IX-MV7-*): Page message to group set in "Group Message Page".</li> <li>• All Message Page (For IX-MV7-*): Page message to all stations..</li> <li>• Monitor (For IX-MV7-*): Monitor station set in "Monitor".</li> <li>• Network Camera Monitor (For IX-MV7-*): Monitor network camera set in "Network Camera Monitor".</li> <li>• Scan Monitor (For IX-MV7-*): Start scan monitor sequence set in "Station Settings - Monitor".</li> <li>• Option Relay Control (For IX-MV7-*): Relay Control set in "Option Relay Control". Relay output will not be controlled for IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*).</li> </ul>
Default values	No Function

#### How to configure Individual Call

Configure this if "Individual Call" is set in "[Function \(→page 339\)](#)".

#### ■ Number

Description	Set the destination station (Station Number). Enter the Station Number or click <b>[Open]</b> to choose one. This cannot be configured for IXW-MA.
Settings	3-32 digits
Default values	-

## ! Important

- Stations in which "[IP Address \(→page 180\)](#)" has not been configured cannot be configured as destinations.

#### ■ Priority

Description	Set the Priority for the individual calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

#### How to configure Group Call

Configure if "Group Call" is set in "[Function \(→page 339\)](#)".

#### ■ Group Number

Description	Set the destination group (group number). Enter the group number or click <b>[Open]</b> to choose one.
Settings	01 - 99
Default values	-

## ■ Priority

Description	Set the priority of Individual call.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

### How to configure Group Page

Configure if "Group Page" is set in ["Function \(→page 339\)"](#).

## ■ Group Number

Description	Set the destination group (Group Number). Enter the Group Number or click <b>[Open]</b> to choose one.
Settings	01 - 99
Default values	-

## ■ Priority

Description	Set the priority of group page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

### How to configure All Page

Configure if "All Page" is set in ["Function \(→page 339\)"](#).

## ■ Priority

Description	Set the priority of all page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

### How to configure Group Message Page (for IX-MV7-\*)

Configure if "Group Message Page" is set in ["Function \(→page 339\)"](#).

## ■ Group Number

Description	Set the destination group (Group Number). Enter the Group Number directly, or click <b>[Open]</b> to choose one.
Settings	01 - 99
Default values	-

## ■ Message

Description	Select the message (audio file) to be send during group message paging.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

## ■ Priority

Description	Set the priority of group message page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

## ■ Play Count [time(s)]

Description	Set the message play count of group message page.
Settings	1 - 20 times
Default values	-

**How to configure All Message Page (for IX-MV7-\*)**

Configure if "All Message Page" is set in ["Function \(→page 339\)"](#).

**■ Message**

Description	Select the message (audio file) to send during all message paging.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	None

**■ Priority**

Description	Set the priority of all message page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

**■ Play Count [time(s)]**

Description	Set the message play count of all message page.
Settings	1 - 20 times
Default values	-

**How to configure Monitor (for IX-MV7-\*)**

Configure if "Monitor" is set in ["Function \(→page 339\)"](#).

**■ Number**

Description	Set the destination station (Station Number). Enter the Station Number or click <b>[Open]</b> to choose one. This cannot be configured for IX-MV7-*, IX-MV, IXW-MA, or VoIP phones.
Settings	3-32 digits
Default values	-

**! Important**

- Stations in which ["IP Address \(→page 180\)"](#) has not been configured cannot be configured to be monitored.

**How to configure Network Camera Monitor (for IX-MV7-\*)**

Configure if "Network Camera Monitor" is set in ["Function \(→page 339\)"](#).

**■ Network Camera**

Description	Set the destination Network Camera (#). Enter the number of the network camera set in <a href="#">"Open Network Camera List (→page 212)"</a> or click <b>[Network camera selection]</b> to choose one.
Settings	001 - 050
Default values	-

**How to configure Option Relay Control (for IX-MV7-\*)**

Configure if "Option Relay Control" is set in ["Function \(→page 339\)"](#).

**Note**

- When controlling relay output for multiple stations, processing may take some time and control may be delayed.

**■ Total**

Description	Configure the station to control relay output. This cannot be configured for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*). Click <b>[Open]</b> to choose a station. Multiple stations (infinite) can be selected.
Settings	The number of selected stations is displayed.
Default values	0

**Important**

- Stations that the "IP Address" has not been configured cannot be configured as stations to perform control.

**■ Output Time Range**

Description	Select the Output Time Range for relay output.
Settings	<ul style="list-style-type: none"> <li>• 0 (Momentary): Start Relay Output by pressing a Speed Dial button. Stop Relay Output by pressing again the Speed Dial button.</li> <li>• 200-2000 [msec]</li> <li>• 3 - 600 [sec]</li> </ul>
Default values	0 (Momentary)

## ■ Output Time◆

Description	Set the Output Time within the range selected in "Output Time Range."
Settings	The setting value is as follows depends on "Output Time Range." <ul style="list-style-type: none"> <li>• If set to 0 (Momentary): Configuration unnecessary.</li> <li>• If set to 200-2000 [msec]: Configure from 200 - 2000 msec (by 200 msec).</li> <li>• If set to 3 - 600 [sec]: Configure from 3 - 600 sec (by 1 sec).</li> </ul>
Default values	0

## ■ TLS

Description	Select Enable / Disable for TLS. When "Enable" is selected, set "Option Relay Control Key" and "Relay Output" - " <a href="#">Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), IX-BA and IX-SS(-*)) (→page 253)</a> ".
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ! Important

- If "TLS" is set to "Enable," this may take some time if there are multiple stations to control.

## ■ Option Relay Control Key

Description	Set the Option Relay Control Key when "TLS" is set to "Enable." When matched with the Option Relay Control Authentication Key in "Relay Output" - " <a href="#">Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), IX-BA and IX-SS(-*)) (→page 253)</a> ", the relay output will activate.
Settings	1-20 digits
Default values	-

### 9.1.1.3 Lock (for IX-MV7-\*)

Description	Select ON / OFF to Lock Speed Dial setting. Once set to "ON", Speed Dial function cannot be changed by user account.
Settings	<ul style="list-style-type: none"> <li>• ON</li> <li>• OFF</li> </ul>
Default values	OFF

## 9.2 Privacy (for IX-MV7-\* and IX-MV)

Configure to prevent the other station from hearing/viewing audio or camera images, when [“Auto Answer \(→page 237\)”](#) is set to "ON."


### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.



### ■ Privacy

Description	Select Enable / Disable for Privacy function. The setting can also be changed on the station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.3 Volume / Tone (except IXW-MA)

Configure the sound settings, such as volume and ringtone.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

### Move to Related Settings

Moves to the selected item within the same Settings screen.

The screenshot shows a settings interface with a navigation bar at the top containing 'Row', 'Previous', 'Next', and 'Display' buttons. Below the navigation bar is a table with columns for 'Station Information' and 'Station Settings'. The 'Station Settings' section is expanded to show 'Volume / Tone' settings for various stations. A red box highlights the 'Volume' dropdown menu, and another red box highlights the 'Display' button. A red line connects the 'Display' button to the 'Volume' dropdown menu.

#	Station Information				Station Settings					
	Identification				Volume / Tone					
	Number	Name	Location	Station Type	Handset Transmit	Handset Receive	Hands-free Transmit	Hands-free Receive	Headset Jack Transmit	Headset Jack Receive
0001	0001	Master Stations1		IX-MV7-*	10	6	10	6	10	
0002	0002	Master Stations2		IX-MV7-*	10	6	10	6	10	
0003	0003	Master Stations3		IX-MV7-*	10	6	10	6	10	
0004	0004	Master Stations4		IX-MV7-*	10	6	10	6	10	
0005	0005	Master Stations5		IX-MV7-*	10	6	10	6	10	
0006	0006	Master Stations6		IX-MV	10	6	10	6		

### 9.3.1 Volume

#### ■ Handset Transmit (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the transmit volume using handset while communicating and paging.
Settings	1 (Low) - 10 (High)
Default values	10

#### ■ Handset Receive (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the receive volume using handset while communicating. Also sets ringback tone volume.
Settings	1 (Low) - 10 (High)
Default values	6

#### ■ Hands-free Transmit (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the hands-free transmit volume while communicating and paging.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Hands-free Receive (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the hands-free receive volume while communicating and paging. Also sets ringback tone volume.
Settings	1 (Low) - 10 (High)
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV: 6</li> <li>• IX-RS-*: 10</li> </ul>

### ■ Headset Jack Transmit (for IX-MV7-\*)

Description	Set the transmit volume using headset jack.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Headset Jack Receive (for IX-MV7-\*)

Description	Set the receive volume using headset jack.
Settings	1 (Low) - 10 (High)
Default values	6

### ■ Transmit (except IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the transmit volume while communicating and being monitored.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Receive (except IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the receive volume while communicating and paging (except IX-DV, IX-DVF(-*), IX-SSA(-*)). Also sets ringback tone. The receive volume for IX-DV, IX-DVF(-*), IX-SSA(-*) during page is configured in <a href="#">“Paging (for IX-DV, IX-DVF(-*), IX-SSA(-*)) (→page 348)”</a> .
Settings	1 (Low) - 10 (High)
Default values	IX-SS-2G, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*): 10 IX-DV, IX-DVF(-*), IX-SSA(-*): 6

### ■ External Input

Description	Not used.
-------------	-----------

### ■ External Output (for IX-RS-\*)

Description	Set the transmit volume using external output.
Settings	1 (Low) - 10 (High)
Default values	6

### ■ VoIP Phone Volume Adjustment (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the volume adjustment between VoIP Phone and IX stations.
Settings	<ul style="list-style-type: none"> <li>• -12dB from VoIP, +12dB to VoIP</li> <li>• -6dB from VoIP, +6dB to VoIP</li> <li>• No Adjustment</li> <li>• +6dB from VoIP, -6dB to VoIP</li> <li>• +12dB from VoIP, -12dB to VoIP</li> </ul>
Default values	No Adjustment

## ■ Ringtone

Description	Select the volume for Ringtone and Paging Pretone.
Settings	0 (Off), 1 (Low) - 10 (High)
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-SSA(-*): 6</li> <li>• IX-SS-2G, IX-RS-*, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*): 10</li> </ul>

## ■ Paging (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Set the volume while receiving page.
Settings	0 (Off), 1 (Low) - 10 (High)
Default values	6

## ■ Button Feedback (for IX-MV7-\* and IX-MV)

Description	Select Enable / Disable for Button Feedback tone.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*: Enable</li> <li>• IX-MV: Disable</li> </ul>

## 9.3.2 Tone

### ■ Communication Timeout Notification (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the tone to be played when an outgoing call times out.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 221)"</a>.</li> </ul>
Default values	Error

## ■ Communication End Pretone (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the tone to be played 10 sec before communication, paging or monitoring ends.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Communication End Pretone

## ■ Call Queue Notification (for IX-MV7-\*)

Description	Select the tone to be played when receiving a call while communicating.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Call Queue Notification

## ■ Paging Pretone (for IX-MV7-\* and IX-MV)

Description	Select the sound to be played when placing or receiving a page.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Pre Tone 2

### Important

- Configure the paging pretone with a longer duration than the paging pretone of the station receiving the page. Configuring a shorter tone might prevent audio from playing on the other station when paging starts. Configure the same tone as that of other IX-MV7-\* and IX-MV stations in the system.

## ■ Auto Answer Tone (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	<p>Select the tone to be played.</p> <ul style="list-style-type: none"> <li>• Ringtone when receiving an individual call. <a href="#">“Auto Answer (→page 237)”</a> must be set to "ON".</li> <li>• Ringback tone when placing an individual call. <a href="#">“Auto Answer (→page 237)”</a> must be set to "ON" at the destination station. (for IX-MV7-*)</li> </ul>
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Pre Tone 1

### ■ On Hold (for IX-MV7-\*)

Description	Select the tone to be played while On-Hold.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	On Hold

### ■ Key Received (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*))

Description	Configure the tone to send to the destination station when the door release key entered using a keypad on the destination station (station performing a door release operation) matches the authentication key of this station (station connected to the electrical lock). The tone will be heard on the destination station.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

## ■ Error (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the tone to be played when error has occurred.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	Error

### 9.3.3 Mic Select

Description	Not used.
-------------	-----------

### 9.3.4 Headset Specification (for IX-MV7-\*)

Description	Set the device to be connected to the headset jack.
Settings	<ul style="list-style-type: none"> <li>• Mic Device</li> <li>• Headset Device</li> </ul>
Default values	Mic Device

### 9.3.5 Audio Output (for Master) (for IX-MV7-\*)

Description	Set using External speaker for Ringtone, Paging Pretone and Paging.
Settings	<ul style="list-style-type: none"> <li>• External speaker output for Ringtone, Built-in Speaker for Communication</li> <li>• External speaker output for Paging Pretone, Built-in Speaker for Paging</li> <li>• External speaker output for Ringtone, Paging Pretone and Paging, Built-in Speaker for Communication</li> </ul>
Default values	External speaker output for Ringtone, Built-in Speaker for Communication



#### Note

- The tone will play from the speaker of the station even if audio is heard from the external speaker.

**9.3.6 Audio Output (for Door) (except IX-MV7-\*, IX-SS-2G, and IX-MV)**

Description	Set using Line Audio / External Speaker or Built-in Speaker while communicating and paging.
Settings	<ul style="list-style-type: none"> <li>• Built-in Speaker for Communication and Paging</li> <li>• Line Audio Output for Communication and Paging (External speaker output for Communication and Paging for IX-RS-*)</li> <li>• Built-in Speaker for Communication, Line Audio Output for Paging (External speaker output for Communication and Paging for IX-RS-*)</li> </ul>
Default values	Built-in Speaker for Communication and Paging

## 9.4 Communication (except IXW-MA)

Configure the settings for a call.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

Row
Previous
Next

Enter Number

Display

#	Station Information				Station Settings			
	Identification				Communication			
	Number	Name	Location	Station Type	Talk Timeout [sec]		Communication Start Tone	Force Touch-to-Talk
					Select	30-600 sec		
0001	0001	Master Stations1		IX-MV7-*	30-600 sec	60		Disable
0002	0002	Master Stations2		IX-MV7-*	30-600 sec	60		Disable
0003	0003	Master Stations3		IX-MV7-*	30-600 sec	60		Disable

Text in red are required settings.

### ■ Talk Timeout [sec]◆

Description	Set the communication timer when placing a call or answering a page. Communication timer when receiving a call is set at the destination station.
Settings	<ul style="list-style-type: none"> <li>Infinite (Except IX-MV): No timeout.</li> <li>30-600 sec: Configure between 30 to 600 sec (by 1 sec).</li> </ul>
Default values	60 sec

### ! Important

- During a communication with a VoIP Phone, this will be the shorter time of the time set for "Talk Timeout [sec]" and the call duration set on the VoIP Phone.

## ■ Communication Start Tone (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the tone to be played when communication starts.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

## ■ Force Touch-to-Talk (for IX-MV7-\* and IX-MV)

Description	Select Enable / Disable for Force Touch-to-Talk (Or Press-to-Talk) when starting communication in hands-free mode.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.5 Monitor (except IXW-MA, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure monitoring-related settings.

### ! Important

- Monitoring cannot be performed for IX-MV7-\*, IX-MV, or VoIP Phone.

#### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

#### Scan Monitor

Up to 50 monitoring number lines can be shown at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 columns.

**[Next]:** Display the next 50 columns.

**[Display]:** Enter the monitoring number and click **[Go]** to display the column for the monitoring number.

#### Move to Related Settings

Moves to the selected item within the same Settings screen.

Monitoring number

The screenshot shows the 'Station Settings' interface. At the top, there are several control panels: 'Row' with 'Previous', 'Next', and 'Display' buttons; 'Scan Monitor' with 'Previous', 'Next', 'Scan Monitor Number', 'Enter Scan Monitor', and 'Go' buttons; and 'Move to Related Settings' with a 'Monitor Timeout [sec]' dropdown menu. Below these is a table with columns for Station Information (Number, Name, Location, Station Type) and Station Settings (Monitor Timeout [sec], Scan Monitor, Type, Number, Station List, Camera Settings, Open C). The table lists stations 0001 through 0007. Station 0001 is highlighted in blue. A red box highlights the 'Scan Monitor' section of the table, and a red line connects it to the 'Monitoring number' label. Another red box highlights the 'Move to Related Settings' dropdown, and a red line connects it to the 'Move to Related Settings' label.

### 9.5.1 Monitor Timeout [sec] (for IX-MV7-\* and IX-MV) ◆

Description	Set the monitoring timer by station. Scan Monitor must be end manually.
Settings	<ul style="list-style-type: none"> <li>Infinite (For IX-MV7-*): No timeout.</li> <li>10-600sec: Set 10-600 sec by 1 sec.</li> </ul>
Default values	60 sec

## 9.5.2 Scan Monitor (for IX-MV7-\*)

Configure monitoring by automatically switching between several stations (except IX-MV7-\* and IX-MV) and network cameras at set intervals. The scan will be performed in registration order.

### ■ Type

Description	Select the Station Type.
Settings	<ul style="list-style-type: none"> <li>• IX Station</li> <li>• Network Camera</li> </ul>
Default values	-

### ■ Number

Description	Set the Station Number. Enter the Number or click <b>[Open]</b> to choose one. This cannot be selected for IX-MV7-*, IX-MV, IXW-MA or VoIP Phone.
Settings	3-5 digits
Default values	-

### ! Important

- Stations in which ["IP Address \(→page 180\)"](#) has not been configured cannot be configured to be monitored.

### ■ Camera Settings

Description	Set the Network Camera Number. Enter the number of the network camera set in <a href="#">"Open Network Camera List (→page 212)"</a> or click <b>[Network camera selection]</b> to choose one.
Settings	Select from the network cameras registered in <a href="#">"Open Network Camera List (→page 212)"</a> .
Default values	-

### ■ Dwell Time

Description	Set the dwell time to change destination for scan monitor.
Settings	<ul style="list-style-type: none"> <li>• 5 sec</li> <li>• 10 sec</li> <li>• 30 sec</li> </ul>
Default values	5 sec

## 9.5.3 Prevent Being Monitored (except IX-MV7-\* and IX-MV)

Description	Select ON / OFF to prevent being monitored.
Settings	<ul style="list-style-type: none"> <li>• ON</li> <li>• OFF</li> </ul>
Default values	OFF

#### 9.5.4 Monitored Notification (except IX-MV7-\* and IX-MV)

Description	Select the tone to be played when monitored by another station.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 221)”</a>.</li> </ul>
Default values	None

---

---

**9.5.5 Monitored LED Notification (except IX-MV7-\* and IX-MV)**

---

---

Description	Select ON / OFF for status LED notification (Blue flashing) while being monitored by another station.
Settings	<ul style="list-style-type: none"><li>• ON</li><li>• OFF</li></ul>
Default values	OFF

## 9.6 Master Station Display (for IX-MV7-\* and IX-MV)

Configure screen display-related settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

#	Station Information				Station Settings					
	Identification				Master Station Display					
	Number	Name	Location	Station Type	Brightness	Primary Video Source	Aspect Ratio	Time Format	Standby LED State	Keypad
0001	0001	Master Stations1		IX-MV7-*	6	IX Station	16:9		ON	ON
0002	0002	Master Stations2		IX-MV7-*	6	IX Station	16:9		ON	ON
0003	0003	Master Stations3		IX-MV7-*	6	IX Station	16:9		ON	ON
0004	0004	Master Stations4		IX-MV7-*	6	IX Station	16:9		ON	ON

### ■ Brightness

Description	Set the Brightness of Master station display.
Settings	1 (Dark) - 10 (Bright)
Default values	6

### ■ Primary Video Source (for IX-MV7-\*)

Description	Select the primary video source when showing 2 video stream simultaneously.
Settings	<ul style="list-style-type: none"> <li>IX Station</li> <li>Network Camera</li> </ul>
Default values	IX Station

### ■ Aspect Ratio (for IX-MV7-\*)

Description	Select the video aspect for primary video source.
Settings	<ul style="list-style-type: none"> <li>16:9</li> <li>4:3</li> </ul>
Default values	16:9

### ■ Time Format: (for IX-MV)

Description	Select the Time format.
Settings	<ul style="list-style-type: none"> <li>mm/dd/yyyy (12h)</li> <li>mm/dd/yyyy (24h)</li> <li>dd/mm/yyyy (12h)</li> <li>dd/mm/yyyy (24h)</li> <li>yyyy/mm/dd (12h)</li> <li>yyyy/mm/dd (24h)</li> </ul>
Default values	mm/dd/yyyy (12h)

**■ Standby LED State**

Description	Select ON / OFF for stand by status LED.
Settings	<ul style="list-style-type: none"><li>• ON</li><li>• OFF</li></ul>
Default values	ON

**■ Keypad (for IX-MV7-\*)**

Description	Select ON / OFF for whether to display the keypad used for door release and playing location messages.
Settings	<ul style="list-style-type: none"><li>• ON</li><li>• OFF</li></ul>
Default values	ON

## 9.7 Camera (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Configure camera settings.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

Row

#	Station Information				Station Settings <span style="color: red; font-size: small;">Text in red are required settings.</span>						
	Identification				Camera						
	Number	Name	Location	Station Type	Adjustment		Color Settings			White LED	
					Backlight Compensation	Low Light Sensitivity	Brightness:	Contrast:	Color:	Call / Communication	Monitorec
0011	0011	Video Stations1		IX-DV, IX-DVF(-*)	Disable	Disable				Enable	Disable
0012	0012	Video Stations2		IX-DV, IX-DVF(-*)	Disable	Disable				Enable	Disable
0013	0013	Video Stations3		IX-DV, IX-DVF(-*)	Disable	Disable				Enable	Disable

### 9.7.1 Adjustment

#### ■ Backlight Compensation

Description	During an outgoing call or monitoring, video with backlight compensation adjustment will be sent to the destination station. The adjustment can be removed through operation by the destination station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

#### ■ Low Light Sensitivity

Description	Send an image that low light sensitivity compensation was performed to the other station, when an outgoing call is made or the station is being monitored and the surrounding area is dark (such as at night). The compensation can be removed on the other station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.7.2 Color Settings (for IX-DA, IX-DF(-\*))

### Important

- If these settings are changed while video is displayed, the changes will not be reflected until the video is accessed again.

### ■ Brightness◆

Description	Set the Brightness for camera setting.
Settings	1 (Dark) to 100 (Bright)
Default values	50

### ■ Contrast◆

Description	Set the Contrast for camera setting.
Settings	1 (Weak) - 100 (Strong)
Default values	15

### ■ Color◆

Description	Set the Contrast for camera setting.
Settings	1 (Weak) to 100 (Strong)
Default values	50

## 9.7.3 White LED

### ■ Call / Communication

Description	Select Enable / Disable for white LED while calling or communicating in low light situation.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

### ■ Monitored

Description	Select Enable / Disable for white LED while being monitored in low light situation.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.8 Door Release Assignment (for IX-RS-\*)

Configure the connected station and door release key for door release during a call.

Configure each station for each group configured in [“Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 225\)”](#).

Select the group number to configure in **[Display Settings]**.

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click

**[Display]** to move the cursor to the entered row.

### Display Settings

Displays the selected group number setting information.

### Move to Related Settings

Moves to the selected item within the same Settings screen.

#	Station Information				Station Settings					
	Number	Name	Location	Station Type	Door Release Assignment					
					Group 01			Group 02		
	Number	Contact Assignment	Authentication Key	Number	Contact Assignment	Authentication		Contact Assignment	Authentication	
0041	0041	Handset Sub Statio	IX-RS-*	0001	Destination Station	4590	0002	Destination Station		
0042	0042	Handset Sub Statio	IX-RS-*	0001	Destination Station	4590	0002	Destination Station		
0043	0043	Handset Sub Statio	IX-RS-*	0001	Destination Station	4590	0002	Destination Station		
0044	0044	Handset Sub Statio	IX-RS-*	0001	Destination Station	4590	0002	Destination Station		

## ■ Contact Assignment

Description	Select which relay output will be used for door release during call.
Settings	<ul style="list-style-type: none"> <li>• Originating Station: Use origination station relay output for door release.</li> <li>• Destination Station: Use destination station relay output for door release.</li> </ul>
Default values	Destination Station

## ■ Authentication Key

Description	<p>When "Destination Station" is selected in "Contact Assignment," set the Authentication Key for door release.</p> <p>Authentication key must match with the destination station's authentication key, which is set in "Relay Output" - <a href="#">“Door Release Authorization (except IXW-MA) (→page 248)”</a> to allow door release.</p>
Settings	1-20 digits
Default values	Random characters (compatible with default value of "Relay Output" - "Door Release Authorization")

 Note

- If ["Create new system/import setting data \(→page 123\)"](#) - "Automatically configure door release for all stations?" was set to "No," the default value for "Authentication Key" will not be set.
- The default values for the Door Release Authorization and Authentication Key vary depending on the station type set in ["Create new system/import setting data \(→page 123\)"](#) - "IX Support Tool Settings."
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) not configured: 20 digits
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) configured: 4 digits

■ Door Release by IX-RS

Description	Select Enable / Disable for door release.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.9 Line Supervision (for IX-MV7-\*)

Configure settings related to Line Supervision and Device Check performed by IX-MV7-\*. Monitor a station other than a VoIP Phone registered in [“Station List \(→page 209\)”](#).

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

#	Station Information				Station Settings <span style="color: red;">Text in red are required settings.</span>							
	Identification				Line Supervision							
	Number	Name	Location	Station Type	Line Supervision Interval				Device Check Interval			
					Test Interval	Weekly	Hour	Minute	Test Interval	Weekly	Hour	Minute
0001	0001	Master Stations1		IX-MV7-*	OFF	Sun	00	00	OFF	Sun	00	00
0002	0002	Master Stations2		IX-MV7-*	OFF	Sun	00	00	OFF	Sun	00	00
0003	0003	Master Stations3		IX-MV7-*	OFF	Sun	00	00	OFF	Sun	00	00

### 9.9.1 Line Supervision Interval

#### ■ Test Interval

Description	Set the Line Supervision test interval.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• 15 sec</li> <li>• 20 min</li> <li>• 30 min</li> <li>• 60 min</li> <li>• Daily</li> <li>• Weekly</li> </ul>
Default values	OFF

#### ■ Weekly

Description	Set the day of the week when "Weekly" is selected in "Test Interval."
Settings	Sun - Sat
Default values	Sun

#### ■ Line Supervision Schedule

Description	Set the time when automatic Line Supervision starts. Set the time when "Daily" or "Weekly" is selected in "Test Interval."
Settings	00:00 - 23:59
Default values	00:00

## 9.9.2 Device Check Interval

### ■ Test Interval

Description	Set the Line Supervision test interval.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• 10 min</li> <li>• 20 min</li> <li>• 30 min</li> <li>• 60 min</li> <li>• Daily</li> <li>• Weekly</li> </ul>
Default values	OFF

### ■ Weekly

Description	Set the day of the week when "Weekly" is selected in "Test Interval."
Settings	Sun - Sat
Default values	Sun

### ■ Device Check Schedule

Description	Set the time when Device Check starts. Set the time when "Daily" or "Weekly" is selected in "Test Interval."
Settings	00:00 - 23:59
Default values	00:00

# 10. Maintenance

## 10.1 Firmware Update

Access our website at "<https://www.aiphone.net/>" to download the latest version of the firmware.

### ! Important

- To update the firmware, "[Association Settings \(→page 160\)](#)" must have been performed on the station to update, and the PC must be able to communicate with the system.
- If the firmware update is started while the station is operating (such as on a call), the operation will end and the firmware update will begin.
- If power is turned off while updating the firmware, the station may malfunction.
- The station will be inoperable while updating the firmware.
- When the firmware is updated, the station will be automatically restarted.

### Update Firmware

Select Firmware files:

IX-MV7-*	<input type="text"/>	Browse
IX-RS-*	<input type="text"/>	Browse
IX-DV, IX-DVF(-*)	<input type="text"/>	Browse
IX-SSA(-*)	<input type="text"/>	Browse
IX-EA, IX-EAU	<input type="text"/>	Browse
IX-FA	<input type="text"/>	Browse
IX-SS-2G	<input type="text"/>	Browse
IX-SPMIC	<input type="text"/>	Browse
IXW-MA	<input type="text"/>	Browse
IX-MV	<input type="text"/>	Browse
IX-DA, IX-DF(-*)	<input type="text"/>	Browse
IX-BA, IX-SS(-*)	<input type="text"/>	Browse

Select Station(s) to update:

To check the current firmware version, go to "Tool -> Station Search".

Station List						Text in red are required settings.
Select	Number	Name	Location	Station Type	Status	
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	

Select Station by Type:

All

▼

Select

Unselect

Update


2

1

3

**How to update the firmware**

1. Click **[Browse]** and select the firmware file to be downloaded for each station.
2. Select the station to update the firmware from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type for a batch selection and click **[Select]** or **[Unselect]**.
  - Stations for which "[Association Settings \(→page 160\)](#)" has not been performed cannot be selected.
3. Click **[Update]**.
  - The firmware update may take approximately ten minutes per station.
4. Click **[OK]**.
  - Click **[Cancel]** to back to the "Update Firmware" screen without updating the firmware.



5. Click **[OK]**.
  - The result is displayed in "Station List" > "Status."
    - In Process: The firmware is being updated.
    - Success: Update successful.
    - Failed: Update failed. Try updating again.

## 10.2 Initialization

When initializing the station, all settings go back to the default values, and the system log and incoming/outgoing call history are erased.

Stations are also deleted from the settings in IX Support Tool.

To initialize a station, start from "[Initialization \(→page 547\)](#)" in the Settings (Station View).

## 10.3 Settings File Backup

Download the setting file from the station and back it up.

### ! Important

- Setting files are downloaded via [“Association Settings \(→page 160\)”](#) on the downloading station. Files cannot be downloaded unless the PC can communicate with the system.
- When first configuring settings using a web browser, or when changing the configuration using a web browser after configuring settings using IX Support Tool, it may not be possible to download the setting files. In this case, download the setting files using a browser.

**Setting File Download**

Select the station(s) to download the Setting File(s):

Select	Number	Name	Location	Station Type	Status	Text in red are required settings.
<input checked="" type="checkbox"/>	0001	Master Stations1		IX-MV7-*	-	
<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	-	
<input type="checkbox"/>	0003	Master Stations3		IX-MV7-*	-	
<input type="checkbox"/>	0004	Master Stations4		IX-MV7-*	-	
<input type="checkbox"/>	0005	Master Stations5		IX-MV7-*	-	
<input type="checkbox"/>	0006	Master Stations6		IX-MV	-	
<input type="checkbox"/>	0007	Master Stations7		IX-MV	-	
<input type="checkbox"/>	0008	Master Stations8		IX-MV	-	

Select Station by Type: All [Select] [Unselect]


Select the file to download: [Settings] [Sounds] [Image] [Schedule]

### How to download setting files

1. Select the station to download the setting file from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type for a batch selection and click **[Select]** or **[Unselect]**.
  - Stations for which [“Association Settings \(→page 160\)”](#) has not been performed cannot be selected.
2. Download the file.
  - [Settings]**: Download only the setting file.
  - [Sounds]**: Download the setting file and audio file for a custom tone.
  - [Image]** (for IX-MV7-\*): Download the setting file and image file for the image on the reception screen.
  - [Schedule]** (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA): Download schedule setting files (for transfer, etc.). Schedules for IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) are downloaded from **[Settings]**.

**3.** Click **[OK]**.

- Click **[Cancel]** to return to the "Setting File Download" window without downloading.

**4.** Click **[OK]**.

- The file download result is displayed in "Station List" - "Status."
  - In Process: The file is in the process of downloading.
  - Success: Download is completed.
  - Failed: Download failed.
  - Unavailable: This is displayed when a file that cannot be uploaded to a station is selected to download in Step 2.
- Downloaded files are saved as follows in "aiphone" - "AIPHONE\_IX\_SupportTool" - "SystemData" within the folder specified during installation.
  - Setting file: "NewIXSystem(set system name).db"
  - Sound file: Saved as a WAV file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Image file: Saved as a PNG file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Schedule file: Saved inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)" as "SCHED\_CHIME.txt," "SCHED\_GROUP.txt," "SCHED\_OUTPUT.txt," "SCHED\_TRANSFER.txt," or "SCHED\_REC.txt" (the saved content differs depending on the station).

## 10.4 syslog (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

### Move row

Up to 50 station number rows can be displayed at a time. Switch the display as follows.

**[Previous]:** Display the previous 50 rows.

**[Next]:** Display the next 50 rows.

**[Display]:** Enter the station number and click **[Display]** to move the cursor to the entered row.

The screenshot shows a navigation control bar with a 'Row' label, 'Previous' and 'Next' buttons, an 'Enter Number' input field, and a 'Display' button. Below this is a table with the following structure:

#	Station Information				Maintenance		
	Identification				syslog		
	Number	Name	Location	Station Type	IP Address		Port
				IPv4 Address	IPv6 Address		
0001	0001	Master Stations1		IX-MV7-*			514
0002	0002	Master Stations2		IX-MV7-*			514
0003	0003	Master Stations3		IX-MV7-*			514

A note on the right side of the table states: 'Text in red are required settings.'

### ■ IPv4 Address

Description	Set the IPv4 address for syslog server.
Settings	1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)
Default values	-

### ■ IPv6 Address

Description	Set the IPv6 address for syslog server.
Settings	::FF:0-FE:FF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)
Default values	-

### ■ Port◆

Description	Set the port number of syslog server.
Settings	1-65535
Default values	514

# System Settings (Station View)

## Important

- Depending on the language settings of the station (IX-MV7-\*or IX-MV), the content of the settings may differ from this manual.
- The symbols indicate the following:
  - ◆: Indicates a required field. A value should be entered. Retain the default settings, unless a change is necessary.
  - ♣: The content of the settings item can be copied to other stations. For how to copy, refer to [“Copy settings \(Settings \(Station View\)\) \(→page 83\)”](#).

# 1. Station Information

## 1.1 Identification

Configure the station number, station name, and location of the station to register in the system. Up to 500 stations can be registered.

◆ Required Settings

**◆ Identification**

Number ◆

Name

Name (furigana)

Location

3-5 digits

1-24 alphanumeric characters

1-24 alphanumeric characters

### ! Important

- Always configure "[Language \(→page 158\)](#)" before setting "Identification."
- Enter the language configured in "[Language \(→page 158\)](#)". However, if the language displayed on the screen for IX-MV7-\* or IX-MV (configured on the station main unit) is different from that set in "[Language \(→page 158\)](#)", the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.
- Results when searching by station will be listed in order of station number.

### ■ Number◆

Description	Set an unique number for each station. The station number will be displayed on the screen of the destination during call, page, etc. This is also used to search stations by station number for IX-MV7-* and IX-MV.
Settings	3-5 digits
Default values	Start from 0001.

### ■ Name

Description	Set the station name. The station name will be displayed on the screen of the destination during call, page, etc. This is also used to search stations by station name for IX-MV7-* and IX-MV.
Settings	1-24 alphanumeric characters
Default values	IX-MV7-*, IX-MV: Master Station (Number); IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*): Video Station (Number); IX-SSA(-*), IX-SS-2G, IX-BA, IX-SS(-*): Audio Station (Number); IX-RS-*: Handset Sub Station (Number); IXW-MA: I/O Adaptor (Number)
Remarks	If left blank, station name will be the same as station number.

### ■ Location (except IXW-MA)

Description	Select the Location of the station. The location will be displayed on the screen of the destination during call, page, etc.
Settings	Select one from the Location registered in " <a href="#">Location (for IX-MV7-* and IX-MV) (→page 406)</a> ".
Default values	-

## 1.2 ID and Password

Set the ID and password for logging in via a web browser, and the ID and password for ONVIF/RTSP authentication.

**●ID and Password**

Administrator ID <b>◆◆</b>	<input type="text" value="admin"/>	1-32 alphanumeric characters (*1)
Administrator Password <b>◆◆</b>	<input type="password" value="*****"/>	1-32 alphanumeric characters (*1)
User ID <b>◆◆</b>	<input type="text" value="user"/>	1-32 alphanumeric characters (*2)
User Password <b>◆◆</b>	<input type="password" value="****"/>	1-32 alphanumeric characters (*2)
ONVIF ID <b>◆◆</b>	<input type="text" value="aiphone"/>	1-32 alphanumeric characters (*3)
ONVIF Password <b>◆◆</b>	<input type="password" value="*****"/>	1-32 alphanumeric characters (*3)
RTSP ID <b>◆◆</b>	<input type="text" value="aiphone"/>	1-32 alphanumeric characters (*4)
RTSP Password <b>◆◆</b>	<input type="password" value="*****"/>	1-32 alphanumeric characters (*4)

(\*1)Administrator ID or Password is default.  
 (\*2)User ID or Password is default.  
 (\*3)ONVIF ID or Password is default.  
 (\*4)RTSP ID or Password is default.  
 For security purposes, it is recommend to modify the default ID and Password.

### ■ Administrator ID◆◆

Description	Set the ID of the administrator account for logging in to the Web System Setting Server. For IX-MV7-*, configure the administrator ID used to access the station's Settings screen.
Settings	1-32 alphanumeric characters
Default values	admin

### ■ Administrator Password◆◆

Description	Set the Password of the administrator account for logging in to the Web System Setting Server. For IX-MV7-*, configure the administrator password used to access the station's Settings screen.
Settings	1-32 alphanumeric characters
Default values	admin

### ■ User ID◆◆

Description	Set the ID of the user account for logging in to the Web System Setting Server.
Settings	1-32 alphanumeric characters
Default values	user

### ■ User Password◆◆

Description	Set the Password of the user account for logging in to the Web System Setting Server.
Settings	1-32 alphanumeric characters
Default values	user

### ■ ONVIF ID (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))◆◆

Description	Set the ID to access this station from 3rd party products using ONVIF. The settings of IX-DA, IX-DF(-*) cannot be changed from their default values. (They are not shown in the Settings screen.)
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ ONVIF Password (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))◆♣

Description	Set the Password to access this station from 3rd party products using ONVIF. The settings of IX-DA, IX-DF(-*) cannot be changed from their default values. (They are not shown in the Settings screen.)
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ RTSP ID (for IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*)◆♣

Description	Set the ID to access this station from 3rd party products using RTSP.
Settings	1-32 alphanumeric characters
Default values	aiphone

### ■ RTSP Password (for IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*)◆♣

Description	Set the Password to access this station from 3rd party products using RTSP.
Settings	1-32 alphanumeric characters
Default values	aiphone



#### Note

- The "Administrator ID" and "User ID" cannot be identical.
- The ONVIF port number is "10080" and the RTSP port number is "554."
- To view video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) using a 3rd party product, refer to ["Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\) \(→page 397\)"](#).
- The ONVIF ID and ONVIF Password of IX-DA, IX-DF(-\*) can be changed on a 3rd party product. If changed on a 3rd party product, the Settings screen will not show the changed content.
- The "Administrator Password," "User Password," "ONVIF Password," and "RTSP Password " are displayed as "\*\*\*\*\*" on the screen.

## 1.3 Time

Set the date and time for each station.

### 1.3.1 Time Zone

#### ■ Select time zone♣

Description	Set the Time Zone.
Settings	Select from 99 regions
Default values	When a new system is created the following settings will be set to these defaults depending on the language selected. Japanese: (GMT+09:00) Osaka, Sapporo, Tokyo English: (GMT-08:00) Pacific Standard Time (US), Tijuana French: (GMT+01:00) Brussels, Madrid, Copenhagen, Paris Spanish: (GMT+01:00) Brussels, Madrid, Copenhagen, Paris Dutch: (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm Traditional Chinese: (GMT+08:00) Taipei Simplified Chinese: (GMT+08:00) Beijing, Chongqing, Hong Kong, Urumqi

### 1.3.2 Daylight Savings Time

#### ■ Enable automatic daylight savings time♣

Description	The daylight saving time is set automatically according by region selected in "Select Time Zone".
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No</li> </ul>
Default values	No

### 1.3.3 Date and Time


Enter the time for each station. Time is used for incoming calls, outgoing calls, and the system log.

**! Important**


- The time cannot be set unless the ["Association Settings \(→page 160\)"](#) is performed and the PC is connected to the same network as the station.

## How to configure the date and time

1. Select "Year," "Month," "Day," "Hour," "Minute," and "Second."
  - Click **[Sync with PC]** to synchronize with PC.
2. Click **[Apply]**.
  - If "Association Settings" has not been configured, the following screen will be shown.  
Click **[OK]** and use "[Association Settings \(→page 160\)](#)".



- If the PC cannot communicate with the system, the following screen will be shown.  
Click **[OK]**, and then ensure the PC can communicate with the system.



3. Click **[OK]**.

## 1.4 Expanded System

•Expanded System

"Expanded System" is a common setting. This setting will apply to all stations.  
The "Expanded System" cannot be changed from "Enable" to "Disable".  
If the system contains IX-MV, "Expanded System" cannot be set to "Enable".

Expanded System  Enable  Disable

Description	Not used.
-------------	-----------

# 2. Network Settings

## 2.1 IP Address

Configure the hostname, IP address, subnet mask, and default gateway for each station.

**! Important**

- When a setting related to the IP address is updated on a station, it will restart. In some cases, it may take up to 10 minutes for the station to start up.

+ Required Settings

**IP Address**

Changing IP Address settings will cause station to restart after Update is clicked. This will take a few minutes.

Hostname  1-64 alphanumeric characters

Static / DHCP +

IPv4  Static

IPv6  Static

---

**IPv4 Address**

IP Address +  .  .  .  1.0.0.1-223.255.255.254

Subnet Mask ++  .  .  .  128.0.0.0-255.255.255.255

Default Gateway +  .  .  .  1.0.0.1-223.255.255.254

---

**IPv6 Address**

IP Address  2000::0-3FFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or FD00::0-FDFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

Default Gateway +  ::FF:0-FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

**■ Hostname (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Description	Set the Hostname for each station. Hostname can be viewed instead of IP address on <a href="#">“Address Book (for IX-MV7-* and IX-MV) (→page 406)”</a> and <a href="#">“Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 419)”</a> (Use Hostname to call another stations.). Go to <a href="#">“DNS (→page 384)”</a> to set Hostname.
Settings	1-64 alphanumeric characters
Default values	-

**💡 Note**

- Communication from IX Support Tool to the stations use the IP address.

**■ Static / DHCP**

Description	Select Static or DHCP for the selected IP version.
Settings	For IPv4 <ul style="list-style-type: none"> <li>• Static</li> <li>• DHCP</li> </ul> For IPv6 <ul style="list-style-type: none"> <li>• Static</li> <li>• Stateless</li> <li>• DHCPv6</li> </ul>
Default values	• Static

**! Important**

- IPv4 and IPv6 cannot be mixed in the same system.
- When selecting "DHCP" for IPv4, configure the system so that the DHCP server assigns a Static IP Address to each station.
- When selecting "Stateless" for IPv6, do not change the prefix of the device so that it can transmit RA.
- When selecting "DHCPv6" for IPv6, configure the system so that the DHCP server assigns a Static IP Address to each station. DUID of the station is "00030001 + MAC address."
- When setting up a product from another manufacturer, such as a DHCP server, refer to its manual.

**2.1.1 IPv4 Address****! Important**

- If "[Static / DHCP](#) (→page 381)" was set to "DHCP," settings will not be applied to the station if the "IP Address," "Subnet Mask," and "Default Gateway" are entered.

**■ IP Address◆**

Description	Set the IP Address. The IP Address should be unique.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

**■ Subnet Mask◆◆**

Description	Set the Subnet Mask.
Settings	128.0.0.0 - 255.255.255.255
Default values	-

**■ Default Gateway◆**

Description	Set the Default Gateway.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

**2.1.2 IPv6 Address****! Important**

- If "[Static / DHCP](#) (→page 381)" is set to "Stateless" or "DHCPv6," settings will not be applied to the station even if the "IP Address" and "Default Gateway" settings are input.

**■ IP Address◆**

Description	Set the IP Address. The IP Address should be unique.
Settings	2000::0 - 3FFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or FD00::0 - FDFE:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

**Default Gateway**

Description	Set the Default Gateway.
Settings	::FF:0 - FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

## 2.2 DNS

When IPv4 or IPv6 is configured by Hostname for each item, or when using the email function configured in “[Email \(→page 463\)](#)” for IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*), a DNS server must be configured for name resolution.

The screenshot shows a configuration window titled 'DNS'. It contains two sections: 'Primary Server' and 'Secondary Server'. Each section has two input fields: 'IPv4' and 'IPv6'. The IPv4 fields are represented by four separate boxes for each octet. The IPv6 fields are single text boxes. To the right of each IPv4 field, the range '1.0.0.1-223.255.255.254' is displayed in red. To the right of each IPv6 field, the range '::FF:0-FE:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF' is displayed in red.

### 2.2.1 Primary Server

#### IPv4

Description	Set the IPv4 address for DNS Primary Server.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

#### IPv6

Description	Set the IPv6 address for DNS Primary Server.
Settings	::FF:0 - FE:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF
Default values	-

### 2.2.2 Secondary Server

#### IPv4

Description	Set the IPv4 address for DNS Secondary Server.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

#### IPv6

Description	Set the IPv6 address for DNS Secondary Server.
Settings	::FF:0 - FE:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF:FF
Default values	-

## 2.3 SIP (except IXW-MA)

Configure SIP settings.

**SIP**

---

**SIP Connections**

SIP Signaling Port ♦♦  1-65535

User Agent  1-36 alphanumeric characters

---

**SIP Server**

**Primary Server**

ID ♦  1-24 alphanumeric characters

Password ♦  1-24 alphanumeric characters

IPv4 Address ♦  1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)

IPv6 Address ♦  ::FF:0:FEFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)

Port ♦♦  1-65535

**Secondary Server**

ID ♦  1-24 alphanumeric characters

Password ♦  1-24 alphanumeric characters

IPv4 Address ♦  1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)

IPv6 Address ♦  ::FF:0:FEFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)

Port ♦♦  1-65535

**Tertiary Server**

ID ♦  1-24 alphanumeric characters

Password ♦  1-24 alphanumeric characters

IPv4 Address ♦  1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)

IPv6 Address ♦  ::FF:0:FEFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)

Port ♦♦  1-65535

---

**Miscellaneous**

Register Transmission Interval [sec] ♦♦  10-14400

DTMF digit interval timeout [sec] ♦♦  1-10

Call health check timer ♦♦   sec Do not transmit re-INVITE, 80-3600 sec

### 2.3.1 SIP Connections

#### ■ SIP Signaling Port♦♦

Description	Set the Port Number for SIP. Set the same port number for each station to communicate.
Settings	1 - 65535
Default values	5060

#### ■ User Agent (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Set the User Agent.
Settings	1-36 alphanumeric characters
Default values	—

### 2.3.2 SIP Server (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure integration with 3rd party SIP based PBX systems. Please contact your local Aiphone distribution for more information.

### 2.3.2.1 Primary Server

#### ■ ID♠

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

#### ■ Password♠

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

 **Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

#### ■ IPv4 Address♠

Description	Set the IPv4 address for SIP Primary Server. Go to " <a href="#">DNS (→page 384)</a> " to set Hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ IPv6 Address♠

Description	Set the IPv6 address for SIP Primary Server. Go to " <a href="#">DNS (→page 384)</a> " to set Hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ Port♠♠

Description	Set the Port Number for SIP Primary Server.
Settings	1 - 65535
Default values	5060

### 2.3.2.2 Secondary Server

#### ■ ID♠

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

#### ■ Password♠

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

**■ IPv4 Address**

Description	Set the IPv4 address for SIP Secondary Server. Go to <a href="#">"DNS (→page 384)"</a> to set Hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

**■ IPv6 Address**

Description	Set the IPv6 address for SIP Secondary Server. Go to <a href="#">"DNS (→page 384)"</a> to set Hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

**■ Port**

Description	Set the Port Number for SIP Secondary Server.
Settings	1-65535
Default values	5060

**2.3.2.3 Tertiary Server****■ ID**

Description	Configure the user ID for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**■ Password**

Description	Configure the user password for digest authentication with SIP server.
Settings	1-24 alphanumeric characters
Default values	-

**Note**

- The "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

**■ IPv4 Address**

Description	Set the IPv4 address for SIP Tertiary Server. Go to <a href="#">"DNS (→page 384)"</a> to set Hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

**■ IPv6 Address**

Description	Set the IPv6 address for SIP Tertiary Server. Go to <a href="#">"DNS (→page 384)"</a> to set Hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

## ■ Port♦♠

Description	Set the Port Number for SIP Tertiary Server.
Settings	1-65535
Default values	5060

### 2.3.3 Miscellaneous

## ■ Register Transmission Interval [sec] (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))♦♠

Description	Set the Transmission Interval to send Regist to SIP server.
Settings	10 - 14400sec
Default values	3600 sec

## ■ DTMF digit interval timeout [sec] (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))♦♠

Description	Configure the time to timeout signal reception, when a DTMF signal is not received from the VoIP Phone for a continuous period of time.
Settings	1 - 10sec
Default values	5 sec

## ! Important


- Configure the IP-PBX and VoIP Phone DTMF with outbound.

## ■ Call health check timer♦♠

Description	Set the timer to transmit re-INVITE while calling and monitoring.
Settings	<ul style="list-style-type: none"> <li>• Do not transmit re-INVITE: Do not detect communication errors.</li> <li>• 80-3600 sec: Select to set between 80-3600 sec (by 1 sec).</li> </ul>
Default values	90 sec

## 2.4 Multicast Address (for IX-MV7-\*, IX-MV, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

This must be configured if multicast is enabled in [“Group \(for Master\) \(for IX-MV7-\\* and IX-MV\) \(→page 414\)”](#), [“All Page \(for IX-MV7-\\* and IX-MV\) \(→page 452\)”](#), and [“Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 419\)”](#).



### Note

- A multicast address must be configured to utilize All Page.

#### for IX-MV7-\* and IX-MV

● **Multicast Address**

For Call / Paging

[[IPv4]  .  .  .  224.0.0.0-239.255.255.255

[[IPv6]  FF10::0-FF1F:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

#### for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)

● **Multicast Address**

For Call

[[IPv4]  .  .  .  224.0.0.0-239.255.255.255

[[IPv6]  FF10::0-FF1F:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF

#### ■ For Call / Paging (for IX-MV7-\* and IX-MV)

Description	Set the IPv4 or IPv6 Multicast Address. The Multicast Address should be unique.
Settings	[[IPv4]: 224.0.0.0 - 239.255.255.255 [[IPv6]: FF10::0 - FF1F:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

#### ■ For Call (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the IPv4 or IPv6 Multicast Address. The Multicast Address should be unique.
Settings	[[IPv4]: 224.0.0.0 - 239.255.255.255 [[IPv6]: FF10::0 - FF1F:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

## 2.5 Video (for IX-MV7-\*, IX-MV, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Configure video settings.

**Video**

---

**Video Encoder 1**

Items marked [H.264 / AVC] or [Motion-JPEG] apply only to their respective Coding System.

The "Video Encoder 1" RTP End Port should be greater than 90 digits from the RTP Start Port.

Video Codec:

Resolution:

Frame Rate [fps]:

Select Profile [H.264 / AVC]:

I-picture interval [H.264/AVC]:

Bit rate [kbps] [H.264 / AVC]:

Select Quality [Motion-JPEG]:

RTP Start Port:  1-65534

RTP End Port:  1-65535

---

**Video Encoder 2**

Items marked [H.264 / AVC] or [Motion-JPEG] apply only to their respective Coding System.

The "Video Encoder 2" RTP End Port should be greater than 10 digits from the RTP Start Port.

Second Video Encoder:  Enable  Disable

Video Codec:

Resolution:

Frame Rate [fps]:

Select Profile [H.264 / AVC]:

I-picture interval [H.264/AVC]:

Bit rate [kbps] [H.264 / AVC]:

Select Quality [Motion-JPEG]:

RTP Start Port:  1-65534

RTP End Port:  1-65535

---

**Master Station Video Setting**

Video Streaming:  Enable  Disable

Frame Rate [fps]:

Select Profile:

I-picture interval:  1-100

Bit rate [kbps]:

### 2.5.1 Video Encoder 1

Configure video settings when placing a call between stations, during communication, or when calling a VoIP phone. Configure video settings for IX-MV7-\* in ["Master Station Video Setting \(for IX-MV7-\\*\) \(→page 395\)"](#).

#### ■ Video Codec (for IX-DA, IX-DF(-\*))♣

Description	Select Video Codec.
Settings	<ul style="list-style-type: none"> <li>• H.264 / AVC</li> <li>• Motion-JPEG</li> </ul>
Default values	H.264 / AVC

 Note

- For IX-DV, IX-DVF(-\*), "Video Codec" is set to "H.264 / AVC" and cannot be changed.

**Resolution (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))** ♣

Description	Select the video resolution of Video Encoder 1.
Settings	<ul style="list-style-type: none"> <li>• 320×240 (QVGA)</li> <li>• 640×480 (VGA)</li> </ul>
Default values	IX-DV, IX-DVF(-*): 640×480 (VGA) IX-DA, IX-DF(-*): 320×240 (QVGA)

**Frame Rate [fps] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))** ♣

Description	Set the Frame Rate [fps] of Video Encoder 1.
Settings	1, 2 (for IX-DV, IX-DVF(-*)), 3, 5, 7.5, 10, 15, 20, 30 fps For IX-DA and IX-DF(-*), when the frame rate is set to 7.5, 10, 15, 20 or 30 fps, the frame Rate will be 5 fps after approx. 10 min of an outgoing call.
Default values	15 fps

 Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

**Select Profile [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))**

Description	Select the H.264/AVC Profile of Video Encoder 1.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

**I-picture interval [H.264/AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))** ◆

Description	Set the interval to send H.264/AVC I-picture of Video Encoder 1.
Settings	1 - 100
Default values	15

**Bit rate [kbps] [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))** ♣

Description	Set the H.264/AVC Bit Rate of Video Encoder 1.
Settings	32 (for IX-DV, IX-DVF(-*)), 64, 128, 256, 384, 512, 768, 1024, 2048 kbps
Default values	1024 kbps

 Note

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

■ Select Quality [Motion-JPEG] (for IX-DA, IX-DF(-\*))♣

Description	Select the Quality of Motion-JPEG of Video Encoder 1.
Settings	1 (low) - 10 (high)
Default values	6

■ RTP Start Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 1. Set the difference to 90 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65534
Default values	30000

■ RTP End Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 1. Set the difference to 90 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65535
Default values	31000

## 2.5.2 Video Encoder 2

Set when transmitting video using ONVIF.

To view video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) with a 3rd party product, refer to [“Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\) \(→page 397\)”](#).

### Important

- These settings may be changed by ONVIF-compliant 3rd party products, if utilized. Refer to the manual of the 3rd party product to be used.

### ■ Second Video Encoder (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select Enable / Disable for Second Video Encoder. Set to "Enable" to send the video using ONVIF.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

### ■ Video Codec (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the Video Codec of Video Encoder 2..
Settings	<ul style="list-style-type: none"> <li>• H.264 / AVC</li> <li>• Motion-JPEG</li> </ul>
Default values	H.264 / AVC

### ■ Resolution (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the video resolution of Video Encoder 2.
Settings	<ul style="list-style-type: none"> <li>• 320x240(QVGA)</li> <li>• 640x480(VGA)</li> <li>• 800x480(WVGA) (For IX-DV, IX-DVF(-*))</li> <li>• 1280x720(HD) (For IX-DV, IX-DVF(-*))</li> <li>• 1280x960(SXVGA) (For IX-DV, IX-DVF(-*))</li> </ul>
Default values	IX-DV, IX-DVF(-*): 1280x720(HD) IX-DA, IX-DF(-*): 320x240(QVGA)

### ■ Frame Rate [fps] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Set the Frame Rate [fps] of Video Encoder 2.
Settings	1, 2 (for IX-DV, IX-DVF(-*)), 3, 5, 7.5, 10, 15, 20, 30 fps For IX-DA and IX-DF(-*), when the frame rate is set to 7.5, 10, 15, 20 or 30 fps, the frame Rate will be 5 fps after approx. 10 min of an outgoing call.
Default values	IX-DV, IX-DVF(-*): 10 fps IX-DA, IX-DF(-*): 15 fps

### Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Profile [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Description	Select the H.264/AVC Profile of Video Encoder 2.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

### ■ I-picture interval [H.264/AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ◆

Description	Set the interval to send H.264/AVC I-picture of Video Encoder 2.
Settings	1 - 100
Default values	IX-DV, IX-DVF(-*): 10 IX-DA, IX-DF(-*): 15

### ■ Bit rate [kbps] [H.264 / AVC] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ♠

Description	Set the H.264/AVC Bit Rate of Video Encoder 2.
Settings	32 (for IX-DV, IX-DVF(-*)), 64, 128, 256, 384, 512, 768, 1024, 2048, 4096 (for IX-DV, IX-DVF(-*)), 8192 (for IX-DV, IX-DVF(-*)) kbps
Default values	IX-DV, IX-DVF(-*): 2048 kbps IX-DA, IX-DF(-*): 1024 kbps



#### Note

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

### ■ Select Quality [Motion-JPEG] (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)) ♠

Description	Select the Quality of Motion-JPEG of Video Encoder 2.
Settings	1 (low) - 10 (high)
Default values	6

### ■ RTP Start Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 2. Set the difference to 10 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65534
Default values	32000

### ■ RTP End Port◆

Description	Set the range of port numbers to transmit and receive RTP for Video Encoder 2. Set the difference to 10 or greater in the range of (RTP Start Port) - (RTP End Port).
Settings	1 - 65535
Default values	33000

### 2.5.3 Master Station Video Setting (for IX-MV7-\*)

Configure video settings for the IX-MV7-\* camera.

#### Important

- When sending video to an VoIP Phone, configure to the same video settings as the VoIP Phone.
- Video is not sent when making an outgoing call to a VoIP Phone.

#### ■ Video Streaming

Description	Select Enable / Disable for Video Streaming of IX-MV7-*. Video cannot be distributed to 3rd party products not compatible with ONVIF or to IX-MV. The Video Codec is H.264 / AVC.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

#### ■ Frame Rate [fps]♣

Description	Set the Frame Rate [fps].
Settings	0.5, 1, 2, 3, 5, 7.5, 10, 15, 20, 30 fps
Default values	15 fps

#### Note

- The frame rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

#### ■ Select Profile

Description	Set the profile for Video Streaming.
Settings	<ul style="list-style-type: none"> <li>• Baseline</li> <li>• Main</li> <li>• High</li> </ul>
Default values	Main

#### ■ I-picture interval◆

Description	Select the interval to send I-picture for Video Streaming.
Settings	1 - 100
Default values	15

#### ■ Bit rate [kbps]♣

Description	Select the bit rate [kbps].
Settings	32, 64, 128, 256, 384, 512, 768, 1024, 2048 kbps
Default values	1024 kbps



**Note**

- The bit rate may be lower than the set value depending on the video being sent, the number of recipient stations, and the network environment.

## 2.5.4 Using a 3rd party product to monitor video/audio from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*)

IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) support ONVIF Profile S and RTSP.

Video and audio of IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) can be monitored on a 3rd party product.

### ! Important

- Video from IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) camera cannot be viewed simultaneously by more than two 3rd party products.
- Audio will not be distributed if "[Audio Codec](#) (→page 398)" is set to "G.722."

### Configuring IX-DV, IX-DVF(-\*), and IX-DA so that video can be viewed on a 3rd party product.

1. Select "Enable" for "[Second Video Encoder \(for IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)](#) (→page 393)".
2. Configure video and audio settings.
  - Configure video to "[Video Encoder 2 \(→page 393\)](#)", and audio to "[Audio 2 RTP Start Port](#) (→page 400)" and "[Audio 2 RTP End Port](#) (→page 400)".

### ! Important

- Configure "[Video Encoder 2 \(→page 393\)](#)" according to the specification of the product.

3. Register IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*) with a third party product. Enter the following as necessary.
  - For IX-DV, IX-DVF(-\*)
    - ONVIF ID: Configure in "[ONVIF Password \(for IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)](#) (→page 377)".
    - ONVIF Password: Configure in "[RTSP Password \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\), IX-SS-2G, IX-RS-\\*\)](#) (→page 377)".
    - ONVIF communication port number: 10080
    - RTSP ID: Configure in "[RTSP ID \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\), IX-SS-2G, IX-RS-\\*\)](#) (→page 377)".
    - RTSP Password : Configure in "[RTSP Password \(for IX-DV, IX-DVF\(-\\*\), IX-SSA\(-\\*\), IX-SS-2G, IX-RS-\\*\)](#) (→page 377)".
    - RTSP communication port number: 554
  - For IX-DA, IX-DF(-\*)
    - ONVIF ID: aiphone
    - ONVIF Password: aiphone
    - ONVIF communication port number: 10080
    - RTSP ID: aiphone
    - RTSP Password : aiphone
    - RTSP communication port number: 554
  - For how to register, refer to the instruction manual of the product to be registered.

### ! Important

- "ONVIF ID" and "ONVIF Password" can be changed on the third party product.
- If changed on a third party product, IX-DA, IX-DF(-\*) will not show the changed content on IX Support Tool.

## 2.6 Audio (except IXW-MA)

Configure the settings for audio.

**Audio**

The Audio 1 RTP End Port should be greater than 210 digits from the RTP Start Port.  
 The Audio 2 RTP End Port should be greater than 10 digits from the RTP Start Port.  
 Changing Audio Codec from G.711(μ-law) / G.711(A-law) to G.722, or from G.722 to G.711(μ-law) / G.711(A-law) will cause station to restart after the settings have been uploaded to the stations. This will take a few minutes.

Audio Codec  G.711(μ-law)  G.711(A-law)  G.722

Audio RTP Transmission Interval [msec]  This setting is ignored when transmitting to multiple stations (paging, etc.)

RTP Idle Detection Time [sec]  10-180 sec

Audio 1 RTP Start Port  1-65534

Audio 1 RTP End Port  1-65535

Audio 2 RTP Start Port  1-65534

Audio 2 RTP End Port  1-65535

---

**Audio Buffer**

Packets Buffered at Audio Start

Maximum Packets Buffered  Maximum Packet Buffer must be larger than Audio Start Buffer.

### Audio Codec

Description	Select the Audio Codec.
Settings	<ul style="list-style-type: none"> <li>G.711 (μ-Law)</li> <li>G.711 (A-Law)</li> <li>G.722 (except IX-MV, IX-DA, IX-DF(-*), IX-BA and IX-SS(-*))</li> </ul>
Default values	G.711 (μ-Law)

## ! Important

- When changing from "G.711" to "G.722" or from "G.722" to "G.711," the station will restart when the change is applied. In some cases, it may take around 10 minutes to restart the station.
- Stations with different audio codecs (G.711 and G.722) selected cannot ring, call, monitor, or page each other.
- When changing "G.711" to "G.722" and "G.722" to "G.711," change the custom tones used for the following subcategories to audio files with appropriate audio sample rates. ["Custom Sound Registry \(except IXW-MA\) \(→page 416\)"](#)
  - "Call Origination" - ["Ringback Tone \(except IX-MV\) ♣ \(→page 423\)"](#)
  - "Call Origination" - ["Busy Tone \(except IX-MV\) ♣ \(→page 429\)"](#)
  - "Call Origination" - ["Error Tone \(Call Failed\) \(except IX-MV7-\\* and IX-MV\) ♣ \(→page 430\)"](#)
  - "Incoming Call" - ["Ringtone \(except IX-MV7-\\*, IX-MV\) ♣ \(→page 432\)"](#)
  - "Incoming Call" - ["Call Button \(for IX-MV7-\\* and IX-MV\) \(→page 433\)"](#)
  - "Incoming Call" - ["Option Input \(for IX-MV7-\\* and IX-MV\) \(→page 434\)"](#)
  - "Relay Output" - ["Door Release \(→page 445\)"](#)
  - "Relay Output" - ["Relay Control \(start\) \(except IX-DA, IX-DF\(-\\*\) and IX-BA, IX-SS\(-\\*\)\) \(→page 445\)"](#)
  - "Relay Output" - ["Relay Control \(end\) \(except for IX-DA, IX-DF\(-\\*\) and IX-BA, IX-SS\(-\\*\)\) \(→page 446\)"](#)
  - "Option Input Page" - ["Message File Name \(→page 454\)"](#)
  - "Network Camera Integration" - ["Event Tone \(for IX-MV7-\\*\) \(→page 459\)"](#)
  - "Network Camera Integration" - ["Event Tone \(for IX-MV\) ♣ \(→page 460\)"](#)
  - "Paging Settings" - ["Paging Pretone \(→page 461\)"](#)
  - "Communication Audio Messages" - "Start Communication" - ["Message \(→page 489\)"](#)
  - "Communication Audio Messages" - "Code Received" - ["Message \(→page 490\)"](#)
  - "Chime" - "Weekly Schedule" - ["Chime \(→page 492\)"](#)
  - "Chime" - "Daily Schedule" - ["Chime \(→page 494\)"](#)
  - "Speed Dials / Favorites" - "How to configure group message paging" - ["Message \(→page 522\)"](#)
  - "Speed Dials / Favorites" - "How to configure all message paging" - ["Message \(→page 523\)"](#)
  - "Volume / Tone" - ["Communication Timeout Notification \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 529\)"](#)
  - "Volume / Tone" - ["Communication End Pretone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 530\)"](#)
  - "Volume / Tone" - ["Call Queue Notification \(for IX-MV7-\\*\) ♣ \(→page 530\)"](#)
  - "Volume / Tone" - ["Paging Pretone \(for IX-MV7-\\* and IX-MV\) ♣ \(→page 531\)"](#)
  - "Volume / Tone" - ["Auto Answer Tone \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 531\)"](#)
  - "Volume / Tone" - ["On Hold \(for IX-MV7-\\*\) ♣ \(→page 532\)"](#)
  - "Volume / Tone" - ["Key Received \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 532\)"](#)
  - "Volume / Tone" - ["Error \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 533\)"](#)
  - "Communication" - ["Communication Start Tone \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) ♣ \(→page 535\)"](#)
  - "Monitor" - ["Monitored Notification \(except IX-MV7-\\* and IX-MV\) ♣ \(→page 537\)"](#)

## ■ Audio RTP Transmission Interval [msec] ♣

Description	Set the Audio RTP Transmission Interval. This setting is ignored when transmitting to multiple stations (paging, etc.)
Settings	20, 40, 60, 80, 100 msec
Default values	20 msec

### ■ RTP Idle Detection Time [sec]◆♠

Description	Set the time to detect RTP idle state for Audio. When Audio RTP is not received during communication, monitoring, or receiving a page, connection will be disconnected after the set time.
Settings	10 - 180 sec (by 1 sec)
Default values	10 sec

### ■ Audio 1 RTP Start Port◆

Description	Set the range of port numbers to transmit and receive Audio RTP, such as communication between IX systems. Set the difference to 210 or greater in the range of (Audio 1 RTP Start Port) - (Audio 1 RTP End Port).
Settings	1 - 65534
Default values	20000

### ■ Audio 1 RTP End Port◆

Description	Set the range of port numbers to transmit and receive Audio RTP, such as communication between IX systems. Set the difference to 210 or greater in the range of (Audio 1 RTP Start Port) - (Audio 1 RTP End Port).
Settings	1 - 65535
Default values	21000

### ■ Audio 2 RTP Start Port◆

Description	Set the range of port numbers to transmit and receive Audio RTP using ONVIF. Set the difference to 10 or greater in the range of (Audio 2 RTP Start Port) - (Audio 2 RTP End Port).
Settings	1 - 65534
Default values	22000

### ■ Audio 2 RTP End Port◆

Description	Set the range of port numbers to transmit and receive Audio RTP using ONVIF. Set the difference to 10 or greater in the range of (Audio 2 RTP Start Port) - (Audio 2 RTP End Port).
Settings	1 - 65535
Default values	23000

---

---

## 2.6.1 Audio Buffer

---

---

### ■ Packets Buffered at Audio Start

Description	Set the number of packets to accumulate before playing audio.
Settings	0 - 4
Default values	1

### ■ Maximum Packets Buffered

Description	Set the maximum number of packets that can be accumulated. If a packet is received beyond the set value, it is removed from the oldest packet. It should be greater than the number of <a href="#">"Packets Buffered at Audio Start" (→page 401)</a> .
Settings	2 - 10
Default values	3

## 2.7 Packet Priority

Configure the Packet Priority and VLAN for video, audio, and SIP packets.

### ! Important

- When a setting related to VLAN is updated at a station, it will restart. In some cases, it may take around 10 minutes for the station to start up.

### ■ TOS Value (Audio) (except IXW-MA)◆ ♠

Description	Set the Packet Priority (TOS Value) for Audio.
Settings	0x00 - 0xFF
Default values	0x00

### ■ TOS Value (Video) (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))◆ ♠

Description	Set the Packet Priority (TOS Value) for Video.
Settings	0x00 - 0xFF
Default values	0x00

### ■ TOS Value (SIP) (except IXW-MA)◆ ♠

Description	Set the Packet Priority (TOS Value) for SIP.
Settings	0x00 - 0xFF
Default values	0x00

### ■ VLAN Setting♠

Description	Select Enable / Disable for tagged VLAN.
Settings	<ul style="list-style-type: none"> <li>Disable</li> <li>Enable</li> </ul>
Default values	Disable

### ! Important

- When "VLAN Setting" is set to "Enable" and the configuration is applied to the station, ensure that the station cannot communicate with switches, PCs, and stations not configured on the VLAN.

**VLAN ID**

Description	Set the VLAN ID.
Settings	1 - 4094
Default values	1

**VLAN Priority**

Description	Set the VLAN priority.
Settings	0 (low) - 7 (high)
Default values	0

## 2.8 NTP

**NTP**

Enable NTP ▲  Yes  No Use

Synchronization Interval [hour] ▲▲  1-255 (by 1 hour)

---

**Primary Server**

Address ▲  [IPv4] 1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)

[IPv6] ::FF:0-FE:FF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)

Port ▲▲  1-65535

---

**Secondary Server**

Address ▲  [IPv4] 1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters)

[IPv6] ::FF:0-FE:FF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters)

Port ▲▲  1-65535

### 2.8.1 Enable NTP▲

Description	Select Yes / No Use to synchronize the time with an NTP server. If this is set to "Yes," be sure to configure the other items in <a href="#">"NTP (→page 404)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Yes</li> <li>• No Use</li> </ul>
Default values	No Use

### 2.8.2 Synchronization Interval [hour]◆▲

Description	Set the interval to synchronize with the NTP server.
Settings	1-255 hours (1 hour units)
Default values	24 hours

### 2.8.3 Primary Server

#### 2.8.3.1 Address▲

##### ■ IPv4

Description	Set the IPv4 address for NTP Primary Server. Go to <a href="#">"DNS (→page 384)"</a> to set hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

■ IPv6

Description	Set the IPv6 address for NTP Primary Server. Go to <a href="#">“DNS (→page 384)”</a> to set hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

2.8.3.2 Port ♦ ♣

Description	Set the port number for NTP.
Settings	1 - 65535
Default values	123

---



---

2.8.4 Secondary Server

---



---

2.8.4.1 Address ♣

■ IPv4

Description	Set the IPv4 address for NTP Secondary Server. Go to <a href="#">“DNS (→page 384)”</a> to set hostname.
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

■ IPv6

Description	Set the IPv6 address for NTP Secondary Server. Go to <a href="#">“DNS (→page 384)”</a> to set hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

2.8.4.2 Port ♦ ♣

Description	Set the port number for NTP.
Settings	1 - 65535
Default values	123

# 3. System Information

## 3.1 Location (for IX-MV7-\* and IX-MV)

Register a location.

For how to register a location, refer to [“Register location \(except IXW-MA\) \(→page 174\)”](#).

## 3.2 Address Book (for IX-MV7-\* and IX-MV)

Configure the IX-MV7-\* and IX-MV Address Book.

Calling, paging, monitoring, line monitoring, and malfunction monitoring can be performed for any station registered in the Address Book. Network cameras can be monitored and outgoing calls can be made to VoIP phones.

**! Important**

- Always configure [“Language \(→page 158\)”](#) before setting "Address Book."
- Enter the language configured in [“Language \(→page 158\)”](#). However, if the language displayed on the screen for IX-MV7-\* or IX-MV is different from that set in [“Language \(→page 158\)”](#), the characters on the station screen may appear incorrectly. To avoid this, enter information in the setting data using alphabetical characters only.

### 3.2.1 Station List

Register the stations in the Address Book.

List of stations that can be registered to the Address Book

**VoIP Phone Registration (→page 408)**  
Register the VoIP phone in the Address Book.

#	Select	Station Information				Network Settings		Network Camera
		Number	Name	Location	Station Type	IPv4 Address	IPv6 Address	
0001	<input type="checkbox"/>	0002	Master Stations2		IX-MV7-*	192.168.1.11		Network camera selection
0002	<input checked="" type="checkbox"/>	0003	Master Stations3		IX-MV7-*	192.168.1.12		Network camera selection
0003	<input checked="" type="checkbox"/>	0004	Master Stations4		IX-MV7-*	192.168.1.13		Network camera selection
0004	<input checked="" type="checkbox"/>	0005	Master Stations5		IX-MV7-*	192.168.1.14		Network camera selection
0005	<input checked="" type="checkbox"/>	0006	Master Stations6		IX-MV	192.168.1.15		Network camera selection
0006	<input checked="" type="checkbox"/>	0007	Master Stations7		IX-MV	192.168.1.16		Network camera selection
0007	<input checked="" type="checkbox"/>	0008	Master Stations8		IX-MV	192.168.1.17		Network camera selection
0008	<input checked="" type="checkbox"/>	0009	Master Stations9		IX-MV	192.168.1.18		Network camera selection
0009	<input checked="" type="checkbox"/>	0010	Master Stations10		IX-MV	192.168.1.19		Network camera selection
0010	<input checked="" type="checkbox"/>	0011	Video Stations1		IX-DV, IX-DVF(-)	192.168.1.20		Network camera selection

To register a VoIP Phone, go to Network Settings -> SIP and enter the IP address of the SIP Primary Server.

#	Select	Number	Name	Location	Network Camera

Details on VoIP phones registered in [“VoIP Phone Registration \(→page 408\)”](#) will be shown.

## ! Important


- Stations where ["IP Address \(→page 381\)"](#) is not configured cannot be registered to the Address Book.
- To access stations registered to the Address Book by hostname, configure "IP Address" - ["Hostname \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 381\)"](#) and ["DNS \(→page 384\)"](#).
- Results when searching by station will be listed in order of station number.

### How to create Station List

1. VoIP phones are registered in ["VoIP Phone Registration \(→page 421\)"](#).
2. Identify the station to be registered in the Address Book using "List of stations that can be registered to the Address Book," and then configure "Select."
  - Register stations in which "✓" has been selected to the Address Book. For IX stations, stations for which "SIP" was selected will be registered in the Address Book as VoIP phones.
  - By default, "✓ (register)" is set for all.

Click "Network Camera" (IX-MV7-\* only) - **[Network camera selection]** to select the network camera to associate. Network cameras configured in ["Network Camera List \(→page 409\)"](#) can be selected. The number of the selected network camera will be displayed.

If a network camera is associated with a station, the video from the network camera will be displayed when placing a call, during a communication, or when monitoring.




3. When done, click **[Update]**.
4. Click **[OK]**.

### 3.2.1.1 VoIP Phone Registration

Register the VoIP phone to the Address Book. When registering a VoIP phone, be sure to also configure [“SIP \(except IXW-MA\) \(→page 385\)”](#).

On the "Address Book" screen, click **[VoIP Phone Registration]**. The following window will be shown.

[“Register location \(except IXW-MA\) \(→page 174\)”](#)



#### How to perform VoIP Phone Registration

1. In the "Station List," enter the "Number♦," "Name," and "Location."
  - Number: 3-32 digits
  - Name: 1-24 alphanumeric characters
  - Location: Select a location registered in [“Register location \(except IXW-MA\) \(→page 174\)”](#).
2. Click **[Update]**.
  - Click **[Cancel]** to close the "VoIP Phone Registration" screen without registering a VoIP Phone.
  - The registered VoIP Phone is displayed on the Station List.

### 3.2.2 Network Camera List


IX-MV7-\* and IX-MV support the ONVIF interface standard "ONVIF profile S."

Video and audio of 3rd party network camera can be monitored on the IX-MV7-\*, IX-MV screen.

Register the network camera in the Address Book.

Up to 500 network cameras can be registered.

Configure [“Network Camera Integration \(for IX-MV7-\\* and IX-MV\) \(→page 456\)”](#) to configure event notification-related settings for the network camera.



Click **[Delete]**. The network camera will be deleted.

#### How to create Network Camera List

1. Register the network camera in [“Network Camera Registry \(→page 412\)”](#).
2. Identify the network camera to be registered in the Address Book using "List of network cameras that can be registered to the Address Book."
3. Click the cells ("Select," "PTZ Operation," and "Audio Monitoring") that correspond to Steps 2.
  - Select: Register network cameras with "✓" selected to the Address Book.
  - All items are "blank (unregistered)" by default.

#### ■ Camera Name◆

Description	Set the Network Camera Name.
Settings	1-24 alphanumeric characters
Default values	-

■ Hostname

Description	Set the hostname. Go to <a href="#">"DNS (→page 384)"</a> to set Hostname.
Settings	1-64 alphanumeric characters
Default values	-

■ IP Address (IPv4)

Description	Set the IPv4 address for Network camera.
Settings	1.0.0.1 - 223.255.255.254
Default values	-

■ IP Address (IPv6)

Description	Set the IPv6 address for Network camera.
Settings	::FF:0-FE:FF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF
Default values	-

■ ID◆

Description	Enter ID of the network camera.
Settings	1-32 alphanumeric characters
Default values	-

■ Password◆

Description	Enter Password of the network camera.
Settings	1-32 alphanumeric characters
Default values	-

 **Note**

• "Password" is displayed as "\*\*\*\*\*" in the Settings screen.

■ PTZ Operation

Description	Configure whether to allow network camera PTZ operation from the station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Enable</li> </ul>

## ■ Audio Monitoring

Description	Configure whether to allow monitoring of network camera audio from the station.
Settings	<ul style="list-style-type: none"><li>• Enable</li><li>• Disable</li></ul>
Default values	<ul style="list-style-type: none"><li>• Enable</li></ul>

### Note

- "Allow PTZ" and "Audio Monitoring" are set to "Enable" for IX-MV and cannot be changed.

**4.** When done, click **[Update]**.

**5.** Click **[OK]**.

### 3.2.2.1 Network Camera Registry


Registration cannot be performed if the PC is not connected to the same network as the network camera. Click **[Network Camera Selection]** to search a network camera. (Searching may take several minutes.) When searching is done, the network cameras connected in the network will be shown in the "Network Camera Search List."

**Important**

- Network camera registration is configured via ["Association Settings \(→page 160\)"](#) on at least one IX-MV7-\* or IX-MV station, and cannot be configured if the PC cannot communicate with the system (this is because, when registering a network camera, the network camera is searched through IX-MV7-\* or IX-MV).

**Note**

- When searching on the station, the numbers will be displayed in the order they were registered.



If the video profile cannot be obtained, nothing will be shown.

**How to register a new network camera**

- 1.** To search by specifying an IP address, select "Manual Network Camera Configuration," and enter the "IP Address (hostname) ♦," "ID♦," and "Password ♦" of the network camera.
- 2.** To select from the Network Camera Search List, select "Select from Network Camera Search List." Select the network camera(s) to register from the "Network Camera Search List" and then enter the "Hostname," "ID♦," and "Password♦."
  - When entering the Hostname, configure ["DNS \(→page 384\)"](#).
  - To search again, click **[Search]**. It is also possible change the search time.
- 3.** Click **[Get Network Camera Information]**.  
(Obtaining the video profile may take several minutes.)
  - When video profiles are successfully obtained, they will be shown in "Network Camera Information."
- 4.** Choose the video profile(s) to be registered from the list.
- 5.** Click **[Register]** to register a network camera.
- 6.** When done, click **[Update]**.
- 7.** Click **[OK]**.

### 3.3 Group (for Master) (for IX-MV7-\* and IX-MV)

Configure the group for group calls, group pages, and contact input calls.  
 Up to 50 groups per station (50 stations per group) can be registered.  
 Stations other than IXW-MA can be registered to groups.

#### ! Important

- Always configure [“Language \(→page 158\)”](#) before setting "Group (for Master)."
- Enter using the language configured in [“Language \(→page 158\)”](#). However, if the language displayed on the screen for IX-MV7-\* or IX-MV is different from that set in [“Language \(→page 158\)”](#), the characters on the station screen may appear incorrectly. To avoid this, enter information using alphabetical characters only.
- Only a single VoIP Phone can be registered to each group.
- All pages, groups pages, message pages, and external input pages cannot be sent to VoIP Phone.
- Stations [“IP Address \(→page 381\)”](#) has not been configured and that have not been registered in [“Address Book \(for IX-MV7-\\* and IX-MV\) \(→page 406\)”](#) cannot be registered to groups.
- Groups calls and calls by Option Input cannot be made to IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*).
- Groups calls and calls by Option Input cannot be made from IX-MV to IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, IX-RS-\*.
- Results when searching by station will be listed in order of group number.

1 Group Information

2 List of stations that can be registered to group

List of stations that can be registered to group

#### How to configure groups

1. Enter the following information in "Group Information."
  - Group Number: 01 - 99  
Group numbers must be unique.
  - Group Name: 1 - 24 alphanumeric characters
2. Identify the station to be registered from the "List of stations that can be registered to group."
3. Search for the group for registering the station in Step 2.

- 4.** Click the cells that correspond to Steps 2 and 3. Select an audio protocol and video protocol setting value for each, and register to a group.

The number of registered stations will be shown in "Total."

**Audio Protocol**

- Blank: Select to not register to a group.
- U: Belongs to group. Paging audio is transmitted in unicast.
- M: Belongs to group. Paging audio is transmitted in multicast.

**Video Protocol (only when IX-MV7-\* is both the station to configure and register)**

- Blank: Video will be transmitted as multicast.
- U: Video will be transmitted as unicast during group calls. Unicast can be used to send video to up to 20stations.
- M: Video will be transmitted as multicast during group calls.

The video protocol pull-down menu is shown when the audio protocol setting is selected.

All items are blank by default.

- 5.** When done, click **[Update]**.

- 6.** Click **[OK]**.

 **Important**

- If "M" is selected or "blank" is selected for the video protocol, be sure to configure ["Multicast Address \(for IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)" \(→page 389\)](#).
- For VoIP phones or stations in which "SIP" was selected in ["Station List \(→page 406\)"](#) ["Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 419\)"](#), "M" cannot be selected.

 **Note**

- When making a group call, the audio protocol will be set to "U" and cannot be changed.

### 3.4 Custom Sound Registry (except IXW-MA)

Register audio files to be used for ringback tones, ringtones, message paging, etc. The numbers of audio files that can be registered to each station are as follows.

Station Type	Information that can be saved to the station
IX-MV7-*	Max. 100 files (with 200 seconds and 8 Mbytes per file)
IX-MV	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-DA, IX-DF(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-DV, IX-DVF(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-SSA(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-SS-2G	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-BA, IX-SS(-*)	Max. 100 files (total length of within 200 seconds and 8 Mbytes)
IX-RS-*	Max. 100 files (total length of within 200 seconds and 8 Mbytes)

Sound file format

- File Type: .wav
- Sample Size: 16 bits
- Sample Rate: 8 kHz (if "Audio Codec (→page 398)" is "G.711 (μ-Law)" or "G.711 (A-Law)"), 16 kHz (if "Audio Codec (→page 398)" is "G.722")
- Channel: 1 (monaural)
- File Name: 1-82 alphanumeric characters (without file extensions)

For IX-MV7-\*, search for audio files used for message paging by file name by entering either a letter or number as the first character.



Note

- If using a file for a ringback tone, ringtone, or network camera event tone, add a period of silence in the .wav file if the tone is to be intermittent.
- Sample files of custom tones are provided on our website (<https://www.aiphone.net/product/>) for download and use as audio sources.

**How to register an audio file**

- 1.** Click **[Browse]** at the end of the row for the station in which the file is to be registered.
- 2.** Select the audio file to register, and click **[Open]**.
- 3.** Information on the selected audio file will be shown.
  - Name: Shows the file name of the audio file. Up to 24 alphanumeric characters will be shown. The name will be shown as the setting value when configuring the ringback tone etc. If the file name of the audio file exceeds the character limit above, it will only partially be shown.
  - Browse for .wav file: The audio file reference destination is shown.
- 4.** When done, click **[Update]**.
- 5.** Click **[OK]**.

**How to delete a custom tone**

- 1.** Check the **[Delete]** box of the audio file to delete.
- 2.** Click **[Update]**.
- 3.** Click **[OK]**.


**Note**

- "Name" can be deleted from the Settings screen by selecting "[Upload Settings To Station \(→page 145\)](#)" - "Sounds" to upload the setting file, and then deleting the audio file from the station.

# 4. Call Settings

## 4.1 Station Information (for IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G)

Configure the call button function.



### ■ Call Button Function

Description	Select the Call button Function when call button is pressed (for IX-RS-*: Call/Talk button).
Settings	<ul style="list-style-type: none"> <li>• Call: Outgoing call</li> <li>• Call, Cancel Call, End Communication: Out going call, Cancel outgoing call, End Communication</li> <li>• Call, Answer Call, End Communication: Outgoing call, Answer call or page, End communication</li> </ul>
Default values	Call

**Note**

- Contact input calls and communication switched from a contact input call cannot be ended by pressing the Call button (IX-RS-\*: Call/Talk button).

## 4.2 Called Stations (Master Stations) (for IX-MV7-\* or IX-MV)

A call destination does not have to be set up. Any intercom station registered in [“Station List \(→page 406\)”](#) can be called.

### 4.3 Called Stations (Door/Sub Stations) (except IX-MV7-\*, IX-MV, and IXW-MA)

Configure the group to call when a call is made using the call button or via contact input.

- Stations other than IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*): Up to 20 stations can be configured in a single group, and up to 10 groups can be configured.
- IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), (for placing a call button call): Up to 20 stations can be configured in a single group, and only a single group can be configured.
- IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*) (for placing a contact input call): Up to 20 stations can be configured in a single group, and up to nine groups can be configured.

Any station other than IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), IXW-MA can be registered as a call recipient.

#### ! Important

- An IX-RS, IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) must be registered under Called Stations (Door/Sub Stations) to use Door Release while in communication with IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*). An IX-RS cannot place a call to IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) even IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) is under Called Stations (Door/Sub Stations.)

**VoIP Phone Registration** (→page 421)  
Register the VoIP phone as a call recipient.

Group Number

**Called Stations (Door/Sub Stations)**

U = Unicast, M = Multicast  
If designating "M", multicast IP addresses must be configured for the station(s).  
To register a VoIP Phone, go to Network Settings -> SIP and enter the IP address of the SIP Primary Server.  
Only one VoIP Phone can be set per group.

Option Input # 1 Group 01 VoIP Phone Registration

#	Number		IPv4 Address	IPv6 Address	Station Type	Protocol	Delete
01	0001	<span>Open</span>	192.168.1.10		IX-MV7-*	U	<span>Delete</span>
02	0002	<span>Open</span>	192.168.1.11		IX-MV7-*	U	<span>Delete</span>
03	0003	<span>Open</span>	192.168.1.12		IX-MV7-*	U	<span>Delete</span>
04	0004	<span>Open</span>	192.168.1.13		IX-MV7-*	U	<span>Delete</span>
05	0005	<span>Open</span>	192.168.1.14		IX-MV7-*	U	<span>Delete</span>
06	0006	<span>Open</span>	192.168.1.15		IX-MV	U	<span>Delete</span>
07	0007	<span>Open</span>	192.168.1.16		IX-MV	U	<span>Delete</span>
08	0008	<span>Open</span>	192.168.1.17		IX-MV	U	<span>Delete</span>

Click to delete the registration.

#### ! Important

- Stations in which "IP Address (→page 381)" is not configured cannot be registered as destinations.
- If the station registered to the call destination is anything other than IX-MV7-\* or IX-MV, one of the following must be configured to receive incoming calls.
  - Set to "Call, Answer Call, End Communication" in "Call Button Function (→page 418)".
  - Configure "Option Input" - "Function (→page 437)" to "Answer Call / Page."
- Do not register the same station to a group more than once.
- Only one VoIP Phone can be registered to each group.

#### How to configure destinations (Door/Sub Stations)

1. Select the group to configure from "Group Number."  
The Settings screen for the selected group will be displayed.
  - Use the following groups when configuring IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*) destinations.
    - Group used to place a call by operating this device/pressing the call button: "Group 10"
    - Groups used to place a call by Option Input: "Group 01 - 09"

2. Select the settings and register the station to the group.
  - For group number 01 for stations other than IX-DA, IX-DF(-\*) or IX-BA, IX-SS(-\*) and for group number 10 for IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*), Stations number 1 - 20 are registered beforehand in IX-MV7-\* and IX-MV will be set to "U" ahead of time.
3. When done, click **[Update]**.
4. Click **[OK]**.

#### ■ Number

Description	Configure the stations to be registered as a call destination (Number). Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-32 digits
Default values	-

#### ■ Protocol (except IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*))

Description	Configure the protocol used for outgoing calls.
Settings	<ul style="list-style-type: none"> <li>• U: The station will be registered in the call destination. An outgoing call is transmitted as unicast.</li> <li>• M: Station will be registered in the call destination. Video is transmitted as multicast for an outgoing call. This can be configured if the originating station is IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*) and the destination station is IX-MV7-*, IX-MV.</li> <li>• SIP: Select this to call an IX station as a VoIP phone.</li> </ul>
Default values	U

#### Important

- If "M" is selected, be sure to configure ["Multicast Address \(for IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)"](#) ([→page 389](#)).

#### How to delete a call destination.

1. Click **[Delete]** for the desired station.
2. Click **[Update]**.
3. Click **[OK]**.

### 4.3.1 VoIP Phone Registration

Register the VoIP Phone in Called Stations (Door/Sub Stations). When registering a VoIP Phone, be sure to configure ["SIP \(except IXW-MA\) \(→page 385\)"](#).

On the "Called Stations (Door/Sub Stations)" screen, click **[VoIP Phone Registration]**. The following window will be shown.



#### VoIP Phone registration

1. In the "Station List," enter the "Number♦," "Name," and "Location."
  - Number: 3-32 digits
  - Name: 1-24 alphanumeric characters
  - Location: Select a location registered in ["Register location \(except IXW-MA\) \(→page 174\)"](#).
2. Click **[Update]**.
  - Click **[Cancel]** to close the "VoIP Phone Registration" screen without registering a VoIP phone.

## 4.4 Call Origination (except IXW-MA)

Configure outgoing call settings.

### 4.4.1 Call Origination Advanced Settings

#### How to configure call destination advanced settings

1. Select the call method to configure in "Call Button / Option Input #."
  - "Call Button (except IX-MV)": Displays settings related to outgoing calls linked that placed by the call button.
  - Option Input 1 - 6: Displays settings related to outgoing calls when "Call" is selected for Option Input" - ["Function \(→page 437\)"](#).

Setting for the selected call method will be displayed.

2. Configure the setting of each item.
3. When done, click **[Update]**.
4. Click **[OK]**.

#### ■ Call Method (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the Call Method to change call destinations automatically by time delay or schedule.
Settings	<ul style="list-style-type: none"> <li>• Standard Destination: Do not change call destination automatically. IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are fixed to "Standard Destination" and cannot be changed.</li> <li>• Change Destination by Time Delay: Change destination group from <a href="#">"Destination by Time Delay Settings (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*)) (→page 424)"</a> after <a href="#">"Destination Dwell Time[sec] (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 425)"</a>. Up to 8 groups can be used.</li> <li>• Change Destination by Schedule: Change destination group by <a href="#">"Schedule Settings (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 426)"</a>.</li> </ul>
Default values	Standard Destination

■ Ringback Tone (except IX-MV) ♠

Description	Select the sound to be played by the station when placing a call. For IX-MV7-*, this will also sound when monitoring.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*) IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	<p>Call Button</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• Except IX-MV7-*: Call Pattern 1</li> </ul> <p>Option Input 1</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• Except for IX-MV7-*: Call Pattern 2</li> </ul> <p>Option Input 2</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 3</li> </ul> <p>Option Input 3</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 4</li> </ul> <p>Option Input 4</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Call Pattern 4</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 5</li> </ul> <p>Option Input 5</p> <ul style="list-style-type: none"> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Call Pattern 6</li> </ul> <p>Option Input 6</p> <ul style="list-style-type: none"> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*): Tremolo Sound</li> </ul>

■ Call Timeout (except "Call Button" - IX-MV)

Description	Set the Call Timeout for outgoing call.
Settings	<ul style="list-style-type: none"> <li>• 10-600sec: Select to set between 10-600 sec (by 1 sec).</li> <li>• Infinite: Keep calling until call is answered.</li> </ul>
Default values	60sec



Note

- For "Call Button", the outgoing call time for IX-MV is set on the station.

## ■ Ringback Tone Count [time(s)] (except "Call Button" IX-MV) ♣

Description	Set the play count of ringback tone for outgoing call.
Settings	<ul style="list-style-type: none"> <li>• 1 - 20 times</li> <li>• Infinite: The ring back tone continues to play for the amount of time set in <a href="#">"Call Timeout (except "Call Button" - IX-MV) (→page 423)"</a>.</li> </ul>
Default values	Infinite



### Note

- For "Call Button", the ringtone count for IX-MV is set on the station.

## ■ Call Destination ("Option Input 1 - 4" - for IX-MV7-\* and IX-MV)

Description	Configure the call destination group and call priority. Enter the group number directly, or click <b>[Open]</b> to select a group.
Settings	<ul style="list-style-type: none"> <li>• Call Destination: 01 - 99. Select from groups registered in <a href="#">"Group (for Master) (for IX-MV7-* and IX-MV) (→page 414)"</a>.</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Call Destination: —</li> <li>• Priority: Normal</li> </ul>

## ■ Standard Mode Settings (except IX-MV7-\* and IX-MV)

Description	Select the destination group when "Standard Destination" is selected in <a href="#">"Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 422)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Call Destination: 01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 419)"</a>.</li> <li>The call group number for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*) is fixed to "10" and cannot be changed for "Call Button," or can be selected from "01 - 09" for "Option Input 1."</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	Call Button <ul style="list-style-type: none"> <li>• Call Destination: 01 (IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are "10")</li> <li>• Priority: Normal</li> </ul> Option Input 1 - 5 <ul style="list-style-type: none"> <li>• Call Destination — (01 for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Priority: Normal</li> </ul> Option Input 6 <ul style="list-style-type: none"> <li>• Call Destination: 01</li> <li>• Priority: Urgent</li> </ul>

## ■ Destination by Time Delay Settings (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))

Description	Configure the call priority for the call group to switch when <a href="#">"Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 422)"</a> is set to "Change Destination by Time Delay." Up to 8 groups can be configured, and it will switch between groups in order by the time configured in "Destination Dwell Time[sec]."
Settings	<ul style="list-style-type: none"> <li>• Call Destination: 01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 419)"</a>.</li> <li>• Priority: Normal/Priority/Urgent</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• Call Destination: -</li> <li>• Priority: Normal</li> </ul>

**Destination Dwell Time[sec] (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))◆**


Description	Set the delay time to change the call destination when "Change Destination by Time Delay" is selected in " <a href="#">Call Method (except IX-MV7-*, IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))</a> " ( <a href="#">→page 422</a> )".
Settings	10-600sec / 1 sec step
Default values	30 sec

**4.4.1.1 Schedule Settings (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Configure when ["Call Method \(except IX-MV7-\\*, IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 422\)"](#) is set to "Change Destination by Schedule."

**How to configure the Weekly Schedule**

Configure the switch time for the call destination, the call destination group, and the call priority each day from Sunday to Saturday. 12 schedules can be set for each day.



- 1.** Configure "Start Time," "End Time," "Call Destination," and "Priority" for each day.
- 2.** When done, click **[Update]**.
- 3.** Click **[OK]**.

**■ Start Time**

Description	Set the time to start changing the call destination.
Settings	00:00 - 23:59
Default values	-

**■ End Time**

Description	Set the time to stop changing the call destination. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

**■ Call Destination**

Description	Set the call destination to change within the schedule.
Settings	01 - 10. Select from groups registered in <a href="#">"Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 419)"</a> .
Default values	-

**■ Priority**


Description	Set the priority of calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

**How to delete the Weekly Schedule**

1. Return the settings to their default values and click **[Update]**.
2. Click **[OK]**.

**How to configure Daily Schedule**

Configure the switch time for the destination, the call group, and the call priority in units of one day. A schedule one year from the set day can be configured. 12 schedules can be set for each day.



1. Select the day to set a schedule from "Calendar."
2. Configure "Start Time," "End Time," "Call Destination," and "Priority," and click **[Add]**.
3. When done, click **[Update]**.
4. Click **[OK]**.

**■ Start Time**

Description	Set the time to start changing the call destination.
Settings	00:00 - 23:59
Default values	-

**■ End Time**

Description	Set the time to stop changing the call destination. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

■ Call Destination

Description	Set the call destination to change within the schedule.
Settings	01 - 10. Select from groups registered in <a href="#">“Called Stations (Door/Sub Stations) (except IX-MV7-*, IX-MV, and IXW-MA) (→page 419)”</a> .
Default values	-

■ Priority

Description	Set the priority of calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

**How to delete Daily Schedule**

1. Select the day for which to delete a schedule from "Calendar."
2. Schedules for the selected day are displayed in the "Set Schedule List."
  - If a weekly schedule is configured for the selected day of the week, it will also be displayed.
3. Click **[Delete]** for the schedule to be deleted, and click **[Update]**.
  - Refer to [“How to delete the Weekly Schedule \(→page 427\)”](#) to delete a weekly schedule.

## 4.4.2 Tone Settings

Configure the busy tone and error tone when making an outgoing call.

**Tone Settings**

Busy Tone ▲ Busy Response Tone ▼  
(\*)Tone generated at door release destination station.

Error Tone (Call Failed) ▲ Error ▼  
(\*)Tone generated at door release destination station.

### ■ Busy Tone (except IX-MV)♣

Description	Select the sound to be played when call destination station is busy.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))

■ Error Tone (Call Failed) (except IX-MV7-\* and IX-MV)♣

Description	Select the sound to be played when outgoing call has failed.
Settings	<ul style="list-style-type: none"> <li>• None (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are Error Tone)</li> <li>• Pre Tone 1 (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Error (IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*) are Error Tone)

4.4.3 Call Restart Function



■ Call Restart Function (except IX-MV7-\* , IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select Enable / Disable for Call Restart Function. Call Restart Function: When the station is reset during an outgoing call, the outgoing call will be resumed automatically up to 2 times.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 4.5 Incoming Call (except IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Configure incoming call settings.

### 4.5.1 Call Answer Settings



#### ■ Auto Answer

Description	Select ON / OFF to automatically answer the individual call. Auto Answer: When receiving an individual call, answer automatically. When transferring a call, it must be answered manually.
Settings	<ul style="list-style-type: none"> <li>• ON: Auto Answer.</li> <li>• OFF: No Auto Answer.</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV, IX-RS-*: OFF</li> <li>• IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G: ON</li> </ul>

#### ! Important

- For IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G, if Auto Answer is set to "OFF," be sure to configure one of the following. If not configured, calls will not be received.
  - Set to "Call, Answer Call, End Communication" in ["Call Button Function \(→page 418\)"](#).
  - Configure "Option Input" - ["Function \(→page 437\)"](#) to "Answer Call / Page."

#### 💡 Note

- For IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*), Auto Answer is set to "ON" and cannot be changed.

## 4.5.2 Ringtone

Ringtone

Ringtone

(\*)Tone generated at door release destination.

Ringback Tone Count [time(s)]

Call Button

Originating Station	Normal	Priority	Urgent
0001 / 0002 / Master Stations2 / IX-MV7-*	Call Pattern 1	Call Pattern 1	Call Pattern 1
0002 / 0003 / Master Stations3 / IX-MV7-*	Call Pattern 1	Call Pattern 1	Call Pattern 1
0003 / 0004 / Master Stations4 / IX-MV7-*	Call Pattern 1	Call Pattern 1	Call Pattern 1
0004 / 0005 / Master Stations5 / IX-MV7-*	Call Pattern 1	Call Pattern 1	Call Pattern 1
0005 / 0006 / Master Stations6 / IX-MV	Call Pattern 1	Call Pattern 1	Call Pattern 1
0006 / 0007 / Master Stations7 / IX-MV	Call Pattern 1	Call Pattern 1	Call Pattern 1
0007 / 0008 / Master Stations8 / IX-MV	Call Pattern 1	Call Pattern 1	Call Pattern 1
0008 / 0009 / Master Stations9 / IX-MV	Call Pattern 1	Call Pattern 1	Call Pattern 1

Option Input

Originating Station	Normal	Priority	Urgent
0001 / 0002 / Master Stations2 / IX-MV7-*	Call Pattern 2	Call Pattern 2	Call Pattern 2
0002 / 0003 / Master Stations3 / IX-MV7-*	Call Pattern 2	Call Pattern 2	Call Pattern 2
0003 / 0004 / Master Stations4 / IX-MV7-*	Call Pattern 2	Call Pattern 2	Call Pattern 2
0004 / 0005 / Master Stations5 / IX-MV7-*	Call Pattern 2	Call Pattern 2	Call Pattern 2
0005 / 0006 / Master Stations6 / IX-MV	Call Pattern 2	Call Pattern 2	Call Pattern 2
0006 / 0007 / Master Stations7 / IX-MV	Call Pattern 2	Call Pattern 2	Call Pattern 2
0007 / 0008 / Master Stations8 / IX-MV	Call Pattern 2	Call Pattern 2	Call Pattern 2
0008 / 0009 / Master Stations9 / IX-MV	Call Pattern 2	Call Pattern 2	Call Pattern 2

Call Button Ringtone Count [time(s)]

Option Input Ringtone Count [time(s)]

### ■ Ringtone (except IX-MV7-\*, IX-MV)▲

Description	Select the ringtone to be played for incoming call.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Call Pattern 3

## ■ Ringback Tone Count [time(s)] (except IX-MV7-\*)<sup>▲</sup>

Description	Set the play count of ringtone for incoming call.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

## ■ Call Button (for IX-MV7-\* and IX-MV)

Description	Select the ringtone for incoming call. Ringtone can be set per each source station. IX-MV7-*: Ringtone can be set per priority. IX-MV: Same for all priority. Set ringtone to "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• None (IX-MV7-* only)</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-MV: Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-MV: Error Tone)</li> <li>• Pre Tone 1 (IX-MV7-* only)</li> <li>• Pre Tone 2 (IX-MV7-* only)</li> <li>• Pre Tone 3 (IX-MV7-* only)</li> <li>• Communication End Pretone (IX-MV7-* only)</li> <li>• Call Queue Notification (IX-MV7-* only)</li> <li>• Waiting Reply Tone (IX-MV7-* only)</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Call Pattern 1

## ■ Option Input (for IX-MV7-\* and IX-MV)

Description	Select the ringtone for incoming call by Option Input. The ringtone can be set per each source station. IX-MV7-*: The ringtone can be set per priority. IX-MV: Same for all priorities. Set the ringtone to "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• None (IX-MV7-* only)</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (IX-MV: Busy Tone)</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (IX-MV: Error Tone)</li> <li>• Pre Tone 1 (IX-MV7-* only)</li> <li>• Pre Tone 2 (IX-MV7-* only)</li> <li>• Pre Tone 3 (IX-MV7-* only)</li> <li>• Communication End Pretone (IX-MV7-* only)</li> <li>• Call Queue Notification (IX-MV7-* only)</li> <li>• Waiting Reply Tone (IX-MV7-* only)</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Call Pattern 2

## ■ Call Button Ringtone Count [time(s)] (for IX-MV7-\*)♣

Description	Set the play count of ringback tone for incoming call from call button.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

## ■ Option Input Ringtone Count [time(s)] (for IX-MV7-\*)♣

Description	Set the play count of ringback tone for incoming call from the option input.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Keep ringing until the call is answered or canceled.</li> <li>• 1 - 20 times</li> </ul>
Default values	Infinite

4.5.3 VoIP Phone (except IX-MV)

VoIP Phone

VoIP Phone Call Priority

■ VoIP Phone Call Priority

Description	Select the call priority from VoIP phones.
Settings	<ul style="list-style-type: none"><li>• Normal</li><li>• Priority</li><li>• Urgent</li></ul>
Default values	Normal

# 5. Option Input/Relay Output Settings

## 5.1 Option Input

Configure the input terminal settings for each station. The number of input terminals varies by station.

### 5.1.1 Option Input Advanced Settings

Select the Option Input Number to configure for **[Call Button / Option Input #]**. The selected Option Input setting information will be displayed (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), and IXW-MA).

#### 5.1.1.1 Name (except for IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Set the Name of the Option Input.
Settings	1-24 alphanumeric characters
Default values	-

5.1.1.2 Function

Description	Configure the contact input functions. The functions that can be selected differ depending on the station.
Settings	<ul style="list-style-type: none"> <li>• No Function</li> <li>• Call (except IXW-MA): Call to destination. Be sure to also configure "Option Input 1 - 6" in <a href="#">"Call Origination (except IXW-MA) (→page 422)"</a>.</li> <li>• Answer Call / Page (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA): Answer incoming call or page.</li> <li>• Paging (for IX-MV7-*): Page to destination. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 453)"</a>.</li> <li>• Message Page (for IX-MV7-*): Send message to destination. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 453)"</a>.</li> <li>• External Input Page (for IX-MV7-*): Page using an external sound source. Only one input terminal may be configured. Be sure to also configure <a href="#">"Option Input Page (for IX-MV7-*) (→page 453)"</a>.</li> <li>• Turn LCD On (for IX-MV7-*): Turn LCD backlight of IX-MV7-* on.</li> <li>• Relay Latch Reset (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G): Reset latch relay output using the option input. "Relay Latch Reset" is selected in "Option Input" - "Function" and "Latch Output" is selected in "Relay Output" - <a href="#">"Function (→page 440)"</a>.</li> <li>• Bathroom Indicator Reset (for IXW-MA): Not used.</li> <li>• API (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)): Send CGI command set by <a href="#">"API 1 (→page 438)"</a> and <a href="#">"API 2 (→page 438)"</a>.</li> </ul>
Default values	No Function

5.1.1.3 Type

Description	Select the type of the option input.
Settings	<ul style="list-style-type: none"> <li>• Make</li> <li>• Break</li> </ul>
Default values	Make

5.1.1.4 Detection Time

■ Detection Time Range

Description	Select the Detection Time Range for Option Input.
Settings	<ul style="list-style-type: none"> <li>• 0 (Immediate): Detect at input less than 200 msec.</li> <li>• 200 - 2000 [msec]</li> <li>• 3 - 600 [sec]</li> </ul>
Default values	0 (Immediate)

 **Note**

- The Detection Time Range for IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*) is "200-2000 [msec]" and cannot be changed.

■ Detection Time◆

Description	Configure the contact input search time within the range set in "Detection Time Range."
Settings	<p>The settings will be configured as follows according to the information set in "Detection Time Range."</p> <ul style="list-style-type: none"> <li>• If set to 0 (Immediate): Configuration unnecessary.</li> <li>• If set to 200 - 2000 [msec]: Configure from 200 - 2000 msec (by 100 msec).</li> <li>• If set to 3 - 600 [sec]: Configure from 3 - 600 sec (by 1 sec).</li> </ul>
Default values	-

**5.1.1.5 API (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))****■ API 1**

Description	Enter the CGI command sent when "API" is selected in <a href="#">"Function (→page 437)"</a> .
Settings	1-128 alphanumeric characters
Default values	-

**■ API 2**

Description	Enter the CGI command sent when "API" is selected in <a href="#">"Function (→page 437)"</a> .
Settings	1-128 alphanumeric characters
Default values	-

## 5.2 Relay Output

Configure the output terminal settings for each station. The number of output terminals varies by station.

**! Important**

- The four relay output methods are shown below. Redundant configuration is possible for each output terminal. If multiple commands occur during a single relay output, the last command will take priority.
  - Function selected in [“Function \(→page 440\)”](#)
  - [“Option Relay Control \(except IX-MV, IX-DA, IX-DF\(-\\*\), IX-BA, and IX-SS\(-\\*\)\) \(→page 442\)”](#)
  - [“Schedule Settings \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 447\)”](#)
  - [“CGI Integration \(→page 473\)”](#)

### 5.2.1 Relay Output Advanced Settings

The relay output setting information selected in **[Relay Output #]** will be shown. (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), and IXW-MA)

● Relay Output

Relay Output # Relay Output 1

Name  1-24 alphanumeric characters

Function

No Function

Status Output

Status Output	Normal	Priority	Urgent
Outgoing Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Communication	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Outgoing Page	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Page	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Monitored	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

External Audio Output (\*) Relay output while using Line Audio Output.

Door Release

Latch Output (\*) Only Relay Output 1 or 2 can be selected.

Latch Output	Normal	Priority	Urgent
Outgoing Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Communication	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Latch Reset Trigger Event  Option Input  End Communication

Bathroom Indicator

Contact Change SIF Event

SIF Origination Station Number   3-5 digits

(\*) Contact Change SIF Event is associated with Change Contact of Relay Output 1 from SIF Origination Station.  
 (\*) When set to blank, it will perform in association with the contact change of Relay Output 1 on all SIF command originating stations.

Contact Input Call / Communication State

Option Relay Control  Enable  Disable [Set the Door Release Authorization here.](#)

Output Time Range

0 (Momentary)

200-2000 [msec]

3-600 [sec]

Output Time [msec/sec] \*  200-2000 msec / 200 msec step

(\*) Only valid when Relay Output function is set to Door Release or is controlled by CGI.  
 (\*) Output Time is fixed to 10 sec when the Relay Output is controlled by CGI and the Output Time Range is set to 0 (momentary).  
 (\*) Setting invalid when Relay Output is controlled by Option Relay Control.

Door Release Authorization

Authentication Key

(\*) 1-20digits  
 (\*) Authentication Key must match between communicating stations to enable Door Release.

Sound Settings

Door Release

(\*) Tone generated at door release destination station.

Relay Control (start)

(\*) Tone generated at door release destination station.

Relay Control (end)

(\*) Tone generated at door release destination station.

### 5.2.1.1 Name (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Set the name of the Relay Output.
Settings	1-24 alphanumeric characters
Default values	-

### 5.2.1.2 Function

Description	Select the function of the Relay Output. Different function can be selected depending on the station type.
Settings	<ul style="list-style-type: none"> <li>• No Function</li> <li>• Status Output (except IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*), and IXW-MA): Relay Output during the status. The details setting can be set in <a href="#">"How to configure Status Output (→page 440)"</a>.</li> <li>• External Audio Output (for IX-DV, IX-DVF(-*), IX-DA, IX-DF(-*), IX-SSA(-*), IX-BA, IX-SS(-*)): Relay output during Line audio output. Contact continues to output while audio is playing. This operates when "Volume / Tone" - <a href="#">"Audio Output (for Door) (except IX-MV7-*, IX-SS-2G, and IX-MV) (→page 534)"</a> is set to something other than "Built-in Speaker for Communication and Paging."</li> <li>• Door Release (except for IXW-MA): Relay output when door release is activated or, entering the authentication key using keypad of the station or the VoIP Phone. Configure the output time in <a href="#">"Output Time (→page 524)"</a>.</li> <li>• Latch Output (for IX-RS-*, IX-DV, IX-DVF(-*), IX-SSA(-*), IX-SS-2G): Latch relay output by event trigger. Continue to output until latch reset trigger input. Ignore set <a href="#">"Output Time [msec / sec]♦ (→page 443)"</a>. Configuration can be set in <a href="#">"How to configure Latch Output (→page 441)"</a>.</li> <li>• Contact Input Call / Communication State (for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*)): Relay output during the contact input call and communication until reset. The contact will continue to output during operation.</li> <li>• Bathroom Indicator (for IXW-MA): Not used.</li> <li>• Contact Change SIF Event (for IXW-MA): Relay output when Contact Change SIF Event is received from another station. Output Time is the same as Option Input Detection Time or Relay Output Time of the SIF command originating station. Set in "SIF" - "Transmission Trigger" - <a href="#">"Change contact (→page 477)"</a>.</li> </ul>
Default values	Relay Output 1 <ul style="list-style-type: none"> <li>• Except IXW-MA: Door Release</li> <li>• IXW-MA: No Function</li> </ul> Relay Output 2 - 10 <ul style="list-style-type: none"> <li>• No Function</li> </ul>



#### Note

- If "Automatically configure door release for all stations?" is set to "No" in ["Create new system/import setting data \(→page 123\)"](#), the default value for "Relay Output 1 (except IXW-MA)" will be "No Function."

#### How to configure Status Output

If ["Function \(→page 440\)"](#) is set to "Status Output," select the operating state for when the relay output occurs. This can be selected for each operation priority (multiple selections allowed).

The operating states that can be selected vary by station type.

Status Output	Normal	Priority	Urgent
Outgoing Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Communication	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Outgoing Page	<input type="checkbox"/>		<input type="checkbox"/>
Incoming Page	<input type="checkbox"/>		<input type="checkbox"/>
Monitored	<input checked="" type="checkbox"/>		

 **Note**

- For "Outgoing Page" and "Incoming Page," relay output is performed even during message paging and external input paging.
- For "Monitored," relay output is performed even during scan monitoring.

**How to configure Latch Output**

If ["Function \(→page 440\)"](#) is set to "Latch Output," select the operating state for when the relay output occurs. This can be selected for each operation priority (multiple selections allowed). Choose from two restoration methods for relay output.

- Option Input (default value): Reset Latch Output by the Option Input.
- End Communication: Reset Latch Output by ending communication or the option input.

All items are set to "Option Input" by default.

To reset by Option Input, be sure to configure "Relay Latch Reset" in "Option Input" - ["Function \(→page 437\)"](#).

Latch Output	Normal	Priority	Urgent
Outgoing Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Communication	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Latch Reset Trigger Event       Option Input       End Communication

**How to configure Contact Change SIF Event**

If ["Function \(→page 440\)"](#) is set to "Contact Change SIF Event", select the station for interlocking with Contact Change SIF Event of Relay Output 1.

Contact Change SIF Event

SIF Origination Station Number   3-5 digits

(\*)Contact Change SIF Event is associated with Change Contact of Relay Output 1 from SIF Origination Station.  
 (\*)When set to blank, it will perform in association with the contact change of Relay Output 1 on all SIF command originating stations.

**■ Number**

Description	Set SIF Origination Station Number. Enter the station number or select station from the list.
Settings	3-32 digits
Default values	-

5.2.1.3 Option Relay Control (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*))

Description	<p>Select Enable / Disable for Option Relay Control when using the speed dial of IX-MV7-* to control the output.</p> <p>If set to "Enable," contact will be output according to the "Speed Dials / Favorites" - <a href="#">"How to configure Option Relay Control (for IX-MV7-*) (→page 524)"</a> setting.</p> <p>If "How to configure optional relay" - <a href="#">"TLS (→page 524)"</a> was set to "Enable" for the station that be controlled, also configure <a href="#">"Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 449)"</a>.</p> <p>For IXW-MA, this can be controlled as an optional relay if set to "Enable" only when <a href="#">"Function (→page 440)"</a> is set to "No Function." The output time will be the output time configured on IX-MV7-*.</p>
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### 5.2.1.4 Output Time Range

Description	Select the Output Time Range for relay output if " <a href="#">Function (→page 440)</a> " is set to "Door Release" or if the output terminal is controlled via " <a href="#">CGI Integration (→page 473)</a> ".
Settings	<ul style="list-style-type: none"> <li>• 0 (Momentary) (for IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)): Outputs while an output command is received. However, this is set to 10 sec and cannot be changed if a relay output command is received via CGI.</li> <li>• 200-2000 [msec]</li> <li>• 3-600 sec (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))</li> <li>• 3-300 sec (for IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*))</li> </ul>
Default values	200-2000 [msec]

#### Important

- If set to "0 (Momentary)," the operation when the door on the other station is released will be as follows.  
IX-MV7-\* or IX-RS-\*: When the Door Release button is pressed or Authentication Key is input by the keypad, a relay output command is sent and the output command ends immediately. The output command will not continue even if the Door Release button is held.  
IX-MV: The relay output command continues while the Door Release button is pressed, and ends once it is released.

### ■ Output Time [msec / sec]◆

Description	Set the Output Time within the range selected in " <a href="#">Output Time Range (→page 443)</a> ".
Settings	<p>The settings will be configured as follows according to the information configured in "<a href="#">Output Time Range (→page 443)</a>".</p> <ul style="list-style-type: none"> <li>• If set to 0 (Momentary): Configuration unnecessary.</li> <li>• If set to 200-2000 [msec]: Configure from 200 - 2000 msec (by 200 msec).</li> <li>• If set to 3-600 sec: Configure from 3 - 600 sec (by 1 sec).</li> <li>• If set to 3-300 sec: Configure from 3 - 300 sec (by 1 sec).</li> </ul>
Default values	400 [msec]

### 5.2.1.5 Door Release Authorization (except IXW-MA)

Description	Set the Authentication Key when "Door Release" is selected in " <a href="#">Function (→page 440)</a> " for releasing the door that is connected to the station. When the "Authentication Key" is confirmed, the relay output will be activated. Configure "Door Release" - " <a href="#">Authentication Key (→page 455)</a> ". This will also be the authentication key used to release the door using the numerical keypad on IX-MV7-* or a VoIP phone.
Settings	<ul style="list-style-type: none"> <li>• Except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*): 1-20 digits</li> <li>• IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*): 1-4 digits</li> </ul>
Default values	<p>This will vary depending on the setting value configured in "<a href="#">Create new system/import setting data (→page 123)</a>" - "IX Support Tool Settings."</p> <ul style="list-style-type: none"> <li>• IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*) not configured: 20 random digits</li> <li>• IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*) configured: 4 random digits</li> </ul>

 Important

- Configure the Authentication Key using 1 to 4 digits to release when using the IX-MV.
- Configure a different Authentication Key for each output terminal. (The same key cannot be used.)
- Configure an Authentication Key that is different from the Authentication Key configured in "Communication Audio Messages" - "[Code \(→page 490\)](#)" and "[Option Relay Control Authentication Key \(except IX-MV, IX-DA, IX-DF\(-\\*\), and IX-BA, IX-SS\(-\\*\)\) \(→page 449\)](#)". If the setting is the same, multiple functions might operate.
- To release the door using the numerical keypad, enter "\*\*\*Authentication Key\*" on the IX-MV7-\* or VoIP Phone numerical keypad (if the Authentication Key is "0000" enter "\*\*\*0000\*").

## 5.2.1.6 Sound Settings (except IX-MV and IXW-MA)

## ■ Door Release

Description	Select the Door Release sounds to be played.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3 (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Operation Sound

## ■ Relay Control (start) (except IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*))

Description	Select the sound to be played when Option Relay is activated.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	None

## ■ Relay Control (end) (except for IX-DA, IX-DF(-\*) and IX-BA, IX-SS(-\*))

Description	Select the sound to be played when Option Relay is deactivated.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	None


5.2.1.7 Schedule Settings (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

**! Important**

- Regardless of the configuration in "Function (→page 440)", the relay will continue to output during the time period set in the schedule. However, if a door release operation or other command occurs during the relay output, the last command will be given priority, and the relay output will stop even if it is still within the time set in the schedule.

**How to Configure the Weekly Schedule**

Configure the time to perform relay output for each day of the week from, Sunday to Saturday. 12 schedules can be set for each day.



1. Configure "Start Time" and "End Time" for each day.
2. After done, click **[Update]**.
3. Click **[OK]**.

**Start Time**

Description	Set the time to start the relay output.
Settings	00:00 - 23:59
Default values	-

**End Time**


Description	Set the time to end the relay output. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

**How to delete the Weekly Schedule**

1. Return settings to their default values, and click **[Update]**.

### How to configure Daily Schedule

Configure the time at which relay output will be performed, in units of one day. A schedule one year from the set day can be configured. 12 schedules can be set for each day.



1. Select the day to set a schedule from "Calendar."
2. Configure "Start Time" and "End Time," and click **[Add]**.
3. When done, click **[Update]**.
4. Click **[OK]**.

## ■ Start Time

Description	Set the time to start the relay output.
Settings	00:00 - 23:59
Default values	-

## ■ End Time

Description	Set the time to end the relay output. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

### How to delete Daily Schedule

1. Select the day for which to delete a schedule from "Calendar."
2. Schedules for the selected day are displayed in the "Set Schedule List."
  - If a weekly schedule is configured for the selected day of the week, it will also be displayed.
3. Click **[Delete]** for the schedule to be deleted, and click **[Update]**.
  - Refer to ["How to delete the Weekly Schedule \(→page 447\)"](#) to delete a weekly schedule.
4. Click **[OK]**.

### 5.2.2 Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	If <a href="#">"Option Relay Control (except IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*)) (→page 442)"</a> is set to "Enable" and "Speed Dials / Favorites" - <a href="#">"TLS (→page 524)"</a> is set to "Enable" on the requesting station, configure the key used to decrypt encrypted communication. If this matches the "Option Relay Control Key" of the station that performs the operation, the Relay Output may be controlled. To use this, be sure to configure "Speed Dials / Favorites" - <a href="#">"Option Relay Control Key (→page 525)"</a> .
Settings	1-20 digits
Default values	-



#### Note

- Only one Option Relay Control Authentication Key can be set for each station. It will be shared with multiple Relay Output.

# 6. Paging Settings

## ! Important

- All pages, groups pages, message pages, and external input pages cannot be sent to VoIP Phone.

### 6.1 Paging Origination (for IX-MV7-\* and IX-MV)

Configure settings related to outgoing paging.

◆ Required Settings

◆Paging Origination

Paging Timeout [sec] ◆◆	<input type="text" value="30"/>	10-600 sec
Paging Wait Timer [sec] ◆◆	<input type="text" value="10"/>	1-20sec
Urgent Page Response	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	
Lock Paging	<input type="radio"/> Enable <input checked="" type="radio"/> Disable	

#### ■ Paging Timeout [sec] ◆ ♠

Description	Set the time for outgoing paging duration.
Settings	10-600sec / 1 sec step
Default values	30 sec

#### ■ Paging Wait Timer [sec] (for IX-MV7-\*) ◆ ♠

Description	Set the time to wait for a response from all destination stations when outgoing paging is activated. Paging starts after this time without a response form all destination.
Settings	1-20sec (by 1 sec)
Default values	10 sec

## ! Important

- A page may not be sent to a station if a response is received after "Paging Wait Timer [sec]" elapses. If multiple stations receive pages, configure a longer Paging Wait Timer.

## 💡 Note

- The Paging Wait Timer for IX-MV is set to "10 sec" and cannot be changed.

#### ■ Urgent Page Response (for IX-MV7-\*)

Description	Select Enable / Disable for the paging destination station can answer the urgent page.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

 **Important**

- If the station being called is IX-MV, end operations can be performed even if Urgent Page Response is set to "Enable."

**■ Lock Paging (for IX-MV7-\*)**

Description	Select Enable / Disable to lock paging function.
Settings	<ul style="list-style-type: none"> <li>• Enable: Page button will be hidden</li> <li>• Disable</li> </ul>
Default values	Disable

 **Note**

- Configure the pretone when a page is received in "Volume / Tone" - ["Paging Pretone \(for IX-MV7-\\* and IX-MV\) ⚡ \(→page 531\)"](#).

## 6.2 All Page (for IX-MV7-\* and IX-MV)

When paging all stations, the default setting is set to multicast. When unicast is required, configure the following settings.

Address Book Station List

•All Page

Multicast is utilized for All Page function (by default) and must be configured for the stations.  
 Max. 50 stations can be paged using unicast transmission. Select stations for unicast transmission.

Station List	1	Unicast 2
0001 / 0002 / Master Stations2 / / IX-MV7-*		<input checked="" type="checkbox"/>
0002 / 0003 / Master Stations3 / / IX-MV7-*		<input type="checkbox"/>
0003 / 0004 / Master Stations4 / / IX-MV7-*		<input type="checkbox"/>
0004 / 0005 / Master Stations5 / / IX-MV7-*		<input type="checkbox"/>
0005 / 0006 / Master Stations6 / / IX-MV		<input type="checkbox"/>
0006 / 0007 / Master Stations7 / / IX-MV		<input type="checkbox"/>
0007 / 0008 / Master Stations8 / / IX-MV		<input type="checkbox"/>
0008 / 0009 / Master Stations9 / / IX-MV		<input type="checkbox"/>
0009 / 0010 / Master Stations10 / / IX-MV		<input type="checkbox"/>
0010 / 0011 / Video Stations1 / / IX-DV, IX-DVF(-*)		<input type="checkbox"/>
0011 / 0012 / Video Stations2 / / IX-DV, IX-DVF(-*)		<input type="checkbox"/>

### ! Important

- Unicast can reach up to 50 stations. If you need to page more than 50 stations are to be paged at once, use multicast.
- When paging stations in multicast, configure "[Multicast Address \(for IX-MV7-\\*, IX-MV, IX-DV, IX-DVF\(-\\*\), IX-DA, IX-DF\(-\\*\)\)](#) ([→page 389](#))".


### How to configure All Page

1. Search for stations to transmit via unicast from "Station List."
2. Place a check in the cell corresponding to Step1.
  - Unchecked: Multicast transmission
  - Checked: Unicast transmission
  - By default, all are set to "Unchecked" (multicast transmission).
3. After done complete, click **[Update]**.
4. Click **[OK]**.

### 6.3 Option Input Page (for IX-MV7-\*)

Configure contact input paging.

Configure if "Paging," "Message Page," and "External Input Page" are selected in "Option Input" - ["Function" \(→page 437\)](#)".



#### ■ Destination

Description	Set the destination group for paging.
Settings	<ul style="list-style-type: none"> <li>All Page: Page all stations that are registered in the address book.</li> <li>Group: Page the group that is set in "Group Number."</li> </ul>
Default values	All Page

#### ■ Group Number

Description	Set the destination group for paging. Enter the group number, or click <b>[Open]</b> to select group.
Settings	01 - 99, or select from groups registered in <a href="#">"Group (for Master) (for IX-MV7-* and IX-MV)" (→page 414)</a> ".
Default values	-

#### ■ Priority

Description	Set the priority for paging.
Settings	<ul style="list-style-type: none"> <li>Normal</li> <li>Urgent</li> </ul>
Default values	Normal

■ Message File Name

Description	Select the message to be sent for message paging. Available when "Message Page" is selected in "Option Input" - <a href="#">"Function (→page 437)"</a> .
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	None

■ Play Count [time(s)]

Description	Set the play count for message paging.
Settings	1 - 20 times
Default values	1 time

# 7. Function Settings

## 7.1 Door Release (for IX-MV7-\* and IX-MV)

### 7.1.1 Door Release Assignment

Configure the connected station and the authentication key to release the door during a call.

For IX-RS-\* settings, refer to [“Door Release Assignment \(for IX-RS-\\*\) \(→page 543\)”](#).

Station List	Contact Assignment	Authentication Key 1-20 digits
0001 / 0002 / Master Stations2 / IX-MV7-*	Destination Station	9274
0002 / 0003 / Master Stations3 / IX-MV7-*	Destination Station	2503
0003 / 0004 / Master Stations4 / IX-MV7-*	Destination Station	1721
0004 / 0005 / Master Stations5 / IX-MV7-*	Destination Station	2151
0005 / 0006 / Master Stations6 / IX-MV	Destination Station	8138
0006 / 0007 / Master Stations7 / IX-MV	Destination Station	5493
0007 / 0008 / Master Stations8 / IX-MV	Destination Station	9712
0008 / 0009 / Master Stations9 / IX-MV	Destination Station	8943
0009 / 0010 / Master Stations10 / IX-MV	Destination Station	8720
0010 / 0011 / Video Stations1 / IX-DV IX-DVE(-)	Destination Station	7543

### ■ Contact Assignment

Description	Select which relay output will be used for door release during call or monitoring.
Settings	<ul style="list-style-type: none"> <li>• Originating Station: Use origination station relay output for door release.</li> <li>• Destination Station: Use destination station relay output for door release.</li> </ul>
Default values	Destination Station

### ■ Authentication Key

Description	When "Destination Station" is selected in "Contact Assignment", set the Authentication Key for door release. Authentication key must match with the destination station's authentication key, which is set in "Relay Output" - <a href="#">“Door Release Authorization (except IXW-MA) (→page 443)”</a> to allow door release.
Settings	<ul style="list-style-type: none"> <li>• IX-MV7-*: 1-20 digits</li> <li>• IX-MV: 1-4 digits</li> </ul>
Default values	Random characters (compatible with default value of "Relay Output" - "Authentication Key")

#### Note

- If "Automatically configure door release for all stations?" was set to "No" in [“Create new system/import setting data \(→page 123\)”](#), a default value of "Authentication Key" will not be configured.
- The default values for the authentication key and door release key vary depending on the station type set in "IX Support Tool Settings" of [“Create new system/import setting data \(→page 123\)”](#).
  - System without IX-MV, IX-DA, or IX-BA: 20 digits.
  - System with IX-MV, IX-DA, or IX-BA: 4 digits
- If the destination station's Authentication Key is four characters or longer, the Door Release Key for IX-MV will release the door if the first four digits match.

## 7.2 Network Camera Integration (for IX-MV7-\* and IX-MV)


Configure network camera profile (video profile) and event related settings.  
 To configure the settings, register a network camera in the Address Book of the IX-MV7-\* or IX-MV which will receive the event in "Address Book" - ["How to create Network Camera List \(→page 409\)"](#).

**! Important**

- For network camera event registration, ["Association Settings \(→page 160\)"](#) must be configured for the IX-MV7-\* or IX-MV. If the programming PC is not connected to the same network or cannot communicate with multicast transmission, it is not possible to configure. (this is because network camera events are obtained over multicast via IX-MV7-\* or IX-MV when registering network camera events).

### 7.2.1 Profile Setting

Configure when changing the profile selected when a network camera is registered in "Address Book" - ["How to create Network Camera List \(→page 409\)"](#).



If no network camera is registered, this will not be shown.

#### ■ Profile


Description	Select the profile of the network camera. On the first screen, the profile that was selected when registering the network camera will be displayed. Refer to the manual of the network camera for the details.
Settings	-
Default values	-

### 7.2.2 Event Registration

Configure the network camera event to register in IX-MV7-\* or IX-MV.  
 When the registered event is received, network camera monitoring will be performed and the notification tone will be played, or the outgoing call command will be sent to the set Call Origination (for IX-MV7-\*).


#### How to configure network camera event setup

The network camera event must be registered.  
 Click **[Open Network Camera Event Registry]**. The "Open Network Camera Event Registry" window will be shown.



1. Select the station to register the network camera event from "Station List."
2. Select the network camera(s) to monitor events from "Network Camera List" (multiple selections allowed).
  - Network cameras registered in the Address Book in "Address Book" - ["How to create Network Camera List \(→page 409\)"](#) will be shown.
3. Click **[Get Network Camera Events]**. (Obtaining the events may take several minutes.)
  - Once events are successfully obtained, they will be shown in "Event List."
4. Select the events to monitor from "Event List." (Multiple selections allowed)
  - For details on events, refer to the manual of the network camera.

5. Click **[Register]** to register the event.
  - The network cameras and events registered in event registry will be shown.
  - Click **[Cancel]** to back to the "Network Camera Integration" screen without registering the event.



If no event is registered, this will not be shown.

### ■ Event

Description	Displays topics (events) registered in <a href="#">"How to configure network camera event setup (→page 456)"</a> . To delete the registered event, click <b>[Update]</b> with "Event" set as blank. For details of the Event, refer to the manual of the network camera.
Settings	-
Default values	-

### ■ Function (for IX-MV7-\*)

Description	Select the function when receive the topic from the network camera.
Settings	<ul style="list-style-type: none"> <li>• Monitor: Play the notification tone and begin network camera monitoring.</li> <li>• Call: Place an outgoing call from the station configured in <a href="#">"Call Origination (for IX-MV7-*) (→page 459)"</a>. Configure <a href="#">"ID (for IX-MV7-*) (→page 459)"</a>, <a href="#">"Password (for IX-MV7-*) (→page 459)"</a>, and <a href="#">"Call Origination (for IX-MV7-*) (→page 459)"</a> <a href="#">"Call Destination (for IX-MV7-*) (→page 460)"</a> <a href="#">"Priority (for IX-MV7-*) (→page 460)"</a>.</li> </ul>
Default values	-

## ■ Event Tone (for IX-MV7-\*)

Description	Select the tone to be played when receiving event from the network camera.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Call Pattern 3

## ■ ID (for IX-MV7-\*)

Description	If "Call" is set in <a href="#">"Function (for IX-MV7-*) (→page 458)"</a> , configure the administrator ID of the station set in <a href="#">"Call Origination (for IX-MV7-*) (→page 459)"</a> .
Settings	1-32 alphanumeric characters
Default values	-

## ■ Password (for IX-MV7-\*)

Description	If "Call" is set in <a href="#">"Function (for IX-MV7-*) (→page 458)"</a> , configure the administrator password of the station set in <a href="#">"Call Origination (for IX-MV7-*) (→page 459)"</a> .
Settings	1-32 alphanumeric characters
Default values	-



### Note

- "Password" will be displayed as "\*\*\*\*\*" in the Settings screen.

## ■ Call Origination (for IX-MV7-\*)

Description	<p>If "Call" is set in <a href="#">"Function (for IX-MV7-*) (→page 458)"</a>, configure from which station to make the outgoing call.</p> <p>Enter the station number directly, or click <b>[Open]</b> to select a station.</p> <p>For the configured station, set <a href="#">"CGI Functionality (→page 473)"</a> to "Enable."</p>
Settings	Select from the stations registered in <a href="#">"Address Book (for IX-MV7-* and IX-MV) (→page 406)"</a> . IXW-MA cannot be selected.
Default values	-

## ■ Call Destination (for IX-MV7-\*)

Description	Configure the destination station number or group number when the station configured in <a href="#">“Call Origination (for IX-MV7-*) (→page 459)”</a> makes an outgoing call.
Settings	Number: 3-5 digits Group Number: 01 - 99
Default values	-

## ■ Priority (for IX-MV7-\*)

Description	Select the call priority when the station configured in <a href="#">“Call Origination (for IX-MV7-*) (→page 459)”</a> makes an outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

## ■ Event Tone (for IX-MV)♣

Description	Select the tone to be played when receiving event from the network camera. The tone will be the same for all network cameras and events registered in the station.
Settings	<ul style="list-style-type: none"> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Call Pattern 3

## ■ Play count of Event Tone♣

Description	Set the play count for Network Camera Event Tone when <a href="#">“Function (for IX-MV7-*) (→page 458)”</a> is set to "Monitor." The ringtone count will be the same for all network cameras and events registered to the station. If "Call" is set, the ringtone count for the event notification tone will be 1 only.
Settings	<ul style="list-style-type: none"> <li>• Infinite: Play the ringtone while receiving an event that occurred on the network camera.</li> <li>• 1 - 20 times</li> </ul>
Default values	1 time

## 7.3 Paging Settings (except for IX-MV7-\*, IX-MV, or IXW-MA)

Configure incoming page settings.

The screenshot shows a configuration window for 'Paging Settings'. Under the 'Paging Pretone' section, there is a dropdown menu currently displaying 'Pre Tone 2'.

### 7.3.1 Paging Pretone Setting

#### ■ Paging Pretone

Description	Select the Paging Pretone.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 2 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 3 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 4 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 5 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Pattern 6 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Tremolo Sound (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Busy Response Tone (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• On Hold (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Operation Sound (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Error (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3 (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone (except IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>. (Except for IX-DA, IX-DF(-*) and IX-BA, IX-SS(-*).)</li> </ul>
Default values	Pre Tone 2

#### ! Important

- Configure a tone with a shorter duration than the paging pretone on the paging origination station. Configuring a longer tone might prevent the station from receiving audio when paging begins.

## 7.4 Bathroom Call (for IXW-MA)

This function cannot be used outside Japan.

## 7.5 Email

Configure this section when email notification of station operation is required.

Be sure to configure [“DNS \(→page 384\)”](#) for IX-MV, IX-DA, IX-DF(-\*), IX-BA, and IX-SS(-\*).

### 7.5.1 Server Settings

#### ■ SMTP Server♣

Description	Set the SMTP server. When choosing an IPv4 address, enter the IP address or the hostname. For an IPv6 address, configure using the IP address (except IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*)) or hostname. Configure this if connecting by hostname. If a hostname is used, configure <a href="#">“DNS (→page 384)”</a> .
Settings	1 - 255 alphanumeric characters
Default values	-

#### ■ SMTP Port♣♣

Description	Set the port number for SMTP.
Settings	1 - 65535
Default values	25

#### ■ SMTP Encryption♣

Description	Select the encryption type for SMTP.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• TLS</li> <li>• STARTTLS</li> </ul>
Default values	OFF

## 7.5.2 Authentication Settings

Authentication Settings

SMTP Authentication •

Mode •

ID •  1-64 alphanumeric characters

Password •  1-64 alphanumeric characters

### ■ SMTP Authentication♣

Description	Select ON / OFF for SMTP Authentication.
Settings	<ul style="list-style-type: none"> <li>• ON</li> <li>• OFF</li> </ul>
Default values	OFF

### ■ Mode♣

Description	Select the SMTP Authentication Mode.
Settings	<ul style="list-style-type: none"> <li>• LOGIN</li> <li>• CRAM-MD5</li> </ul>
Default values	LOGIN

### ■ ID♣

Description	Set the ID for SMTP authentication.
Settings	1-64 alphanumeric characters
Default values	-

### ■ Password♣

Description	Set the Password for SMTP authentication.
Settings	1-64 alphanumeric characters
Default values	-

**Note**

- "Password" will be displayed as "\*\*\*\*\*" on the screen.

### 7.5.3 Email Addresses

Email Addresses	
Destination 1 	<input type="text"/> 1-64 alphanumeric characters
Destination 2 	<input type="text"/> 1-64 alphanumeric characters
Destination 3 	<input type="text"/> 1-64 alphanumeric characters
Source Address 	<input type="text"/> 1-64 alphanumeric characters

#### ■ Destination 1

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

#### ■ Destination 2

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

#### ■ Destination 3

Description	Set the destination email address.
Settings	1-64 alphanumeric characters
Default values	-

#### ■ Source Address

Description	Set the source email address.
Settings	1-64 alphanumeric characters
Default values	-

### 7.5.4 Email Event Trigger

Set the email event trigger which initiates the message sending process. Configure the email event trigger for each destination address.

**Email Event Trigger**

Event	Destination Address		
	(1)	(2)	(3)
Outgoing Normal Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Normal Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Outgoing Priority Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Priority Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Outgoing Urgent Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Incoming Urgent Call	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Door Release Activated	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Call Failed	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Error	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Station Restarted	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
SD Card Error	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Recording Memory Full	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Line Supervision (Passed)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Line Supervision (Failed)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

[UTF-8] used for "Subject" encoding, the subject may be incorrectly decoded depending on mail server.

Event	Subject <small>1-64 alphanumeric characters</small>
Outgoing Normal Call	<input type="text"/>
Incoming Normal Call	<input type="text"/>
Outgoing Priority Call	<input type="text"/>
Incoming Priority Call	<input type="text"/>
Outgoing Urgent Call	<input type="text"/>
Incoming Urgent Call	<input type="text"/>
Door Release Activated	<input type="text"/>
Call Failed	<input type="text"/>
Latch Reset	<input type="text"/>
Error	<input type="text"/>
Station Restarted	<input type="text"/>
SD Card Error	<input type="text"/>
Recording Memory Full	<input type="text"/>
Line Supervision (Passed)	<input type="text"/>
Line Supervision (Failed)	<input type="text"/>
Device Check (Passed)	<input type="text"/>
Device Check (Failed)	<input type="text"/>

#### ■ Outgoing Normal Call (except IXW-MA)

Description	Send email when an outgoing call is placed at "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

#### ■ Incoming Normal Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Description	Send email when an incoming call is received at "Normal" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Outgoing Priority Call (except IXW-MA)**

Description	Send email when an outgoing call is placed at "Priority" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Incoming Priority Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)**

Description	Send email when an incoming call is received at "Priority" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Outgoing Urgent Call (except IXW-MA)**

Description	Send email when an outgoing call is placed at "Urgent" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Incoming Urgent Call (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)**

Description	Send email when an incoming call is received at "Urgent" priority.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Door Release Activated (for IX-MV7-\*, IX-MV, and IX-RS-\*)**

Description	Send email when Door Release is activated.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Call Failed (except IXW-MA)**

Description	Send email when outgoing call has failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ **Latch Reset (IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G only)**

Description	Send email when reset latch relay output. ("Latch Output" is selected in "Relay Output" - <a href="#">"Function (→page 440)".</a> )
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Error

Description	Send email when a communication error has occurred.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Station Restarted

Description	Send email when the station has reset.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ SD Card Error (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send email when a microSD access error is detected. If the error is detected continuously, mail will not be sent an additional time.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Recording Memory Full (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	<p>Send email when a microSD card meets following criteria. If the error is detected continuously, mail will not be sent an additional time.</p> <ul style="list-style-type: none"> <li>• When <a href="#">“Prevent Overwrite” (→page 486)</a> is set to "Enable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 950</li> <li>– Storage capacity remaining 5%</li> </ul> </li> <li>• When <a href="#">“Prevent Overwrite” (→page 486)</a> is set to "Disable" <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 999</li> <li>– Storage capacity remaining 0%</li> </ul> </li> </ul>
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Line Supervision (Passed) (for IX-MV7-\*)

Description	Send email when Line Supervision is passed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Line Supervision (Failed) (for IX-MV7-\*)

Description	Send email when Line Supervision is failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ Device Check (Passed) (for IX-MV7-\*)

Description	Send email when Device Check is passed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ Device Check (Failed) (for IX-MV7-\*)

Description	Send email when Device Check is failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ Subject

Description	Set the Subject of email per Event Trigger. This will be used for all recipient addresses.
Settings	1-64 alphanumeric characters
Default values	-

**!** Important

- "UTF-8" encoding is used for "Subject." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

**7.5.5 Periodic Log Transmission (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))**

Configure settings related to sending periodic logs. These can be configured for each recipient email address.

Periodic Log Transmission			
Settings	Destination Address		
	(1)	(2)	(3)
Periodic Log Transmission	Disable	Disable	Disable
Periodic Log Transmit Time	00 Hour 00 Minute	00 Hour 00 Minute	00 Hour 00 Minute
Periodic Log Transmit Interval	1Day	1Day	1Day
Periodic Log Transmission Subject			

■ Periodic Log Transmission

Description	Select Enable / Disable for send station log periodically.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

■ Periodic Log Transmit Time

Description	Set the time to send the periodic log.
Settings	00:00 - 23:59
Default values	00:00

### ■ Periodic Log Transmit Interval

Description	Select the interval to send the periodic log.
Settings	1 Day - 7 Day
Default values	Daily

### ■ Periodic Log Transmission Subject


Description	Set the email subject for Periodic Log Transmission. This is used for all destination addresses.
Settings	1-64 alphanumeric characters
Default values	-

### Important

- "UTF-8" encoding is used for "Periodic Log Transmission Subject." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

### 7.5.6 Send Test Email (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Send a test email to the address specified in ["Email Addresses \(→page 465\)"](#).  
 Click **[Send]** to send a test email to the configured address.



#### Important

- To send a test email, ["Association Settings \(→page 160\)"](#) must have been configured, and the programming PC must be able to communicate with the system.

Example of sending an email message:

When sending a test email from the station (Station Number: 001, Station Name: Intercom Station 1, Location: Office).

From	△△△△@△△△△△.com
Date and time	11/20/2018 15:22
To CC	xxxx@xxxxx.com
Subject	001 Intercom Station 1 Test Email
Text	Test Email sent at "20181120 15:22:46."  Station Number: "001" Station Name: [Intercom Station 1] Station location: [Office]

#### Important

- "UTF-8" encoding is used for "Subject," "Periodic Log Transmission Subject," and "Image Filename." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

### 7.5.7 Additional Settings (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

**Additional Settings**

[UTF-8] used for "Attachment Image Filename" encoding, the filename may be garbled depending on mail server.

Attach Image +  Enable  Disable If set to [Enable], an image will be attached when sending "Normal Call", "Priority Call", or "Urgent Call".

Image Filename +  Video Door Station Only  
1-64 alphanumeric characters

#### ■ Attach Image♣

Description	Select Enable / Disable to send an image with the email when "Outgoing Normal Call", "Outgoing Priority Call" and "Outgoing Urgent Call" is selected in <a href="#">"Email Event Trigger (→page 466)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

#### ■ Image Filename♣


Description	Set the filename of a image file when "Attach Image" is enabled.
Settings	1-64 alphanumeric characters
Default values	-

**! Important**

- "UTF-8" encoding is used for "Image Filename." Depending on the email client, the characters may appear incorrectly. To avoid this, set the encoding method to "UTF-8."

## 7.6 CGI Integration

For the details of CGI functionality, contact the local Aiphone representative.



### ■ CGI Functionality

Description	Select Enable / Disable for CGI functionality.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ! Important

- CGI controls may fail when multiple CGI commands are received.

## 7.7 SIF Integration

For the details of SIF functionality, contact the local Aiphone representative.



### 7.7.1 SIF Functionality

Description	Select Enable / Disable for SIF functionality.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable


### 7.7.2 SIP URI Format (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select Enable / Disable when SIP URI Format is used for station destination. If set to "Enable," TERMID cannot be used.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### 7.7.3 SIF Settings (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure SIF recipient and communication settings. 16 SIF settings can be set.

SIF Settings						
#	Program Type 0000-1111 *	IPv4 1.0.0.1-223.255.255.254 or hostname(1-64 alphanumeric characters) *	IPv6 ::FF:0:FEFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname(1-64 alphanumeric characters) *	Destination Port 1-65535 *	SSL *	Connection *
01						
02						
03						
04						
05						
06						
07						
08						
09						
10						



#### Note

- There are two ways to configure SIF communication: manually configuring settings or uploading a file in [“SIF Communication Settings \(sif.ini\) \(→page 484\)”](#). The latest setting will take priority.

#### ■ Program Type♠

Description	Set the Program Type for SIF.
Settings	0000-1111 If this is set to "0000," "0001," or "0011," the <a href="#">“Transmission Trigger (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 477)”</a> setting will be disabled.
Default values	-

#### ■ IPv4♠

Description	Set the SIF IPv4 destination address. Go to <a href="#">“DNS (→page 384)”</a> to set Hostname..
Settings	1.0.0.1 - 223.255.255.254 or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ IPv6♠

Description	Set the SIF IPv6 destination address. Go to <a href="#">“DNS (→page 384)”</a> to set Hostname.
Settings	::FF:0 - FEFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF:FFFF or hostname (1-64 alphanumeric characters)
Default values	-

#### ■ Destination Port♠

Description	Set the Port Number for destination.
Settings	1-65535
Default values	-

■ SSL♣


Description	Select Enable / Disable for SSL.
Settings	<ul style="list-style-type: none"><li>• Disable</li><li>• Enable</li></ul>
Default values	-

■ Connection♣

Description	Select Socket / HTTP for connection.
Settings	<ul style="list-style-type: none"><li>• Socket</li><li>• HTTP</li></ul>
Default values	-

### 7.7.4 Transmission Trigger (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure the SIF sending trigger when [“Program Type” \(→page 475\)](#) is set to “0010” and “0100 - 1111.” This can be configured for each recipient.



#### ■ Begin Outgoing Call (except IXW-MA)

Description	Send SIF command when outgoing call is placed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

#### ■ Begin Communication (Source) (except IXW-MA)

Description	Send SIF command when beginning communication.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

#### ■ Door Release Indication (for IX-MV7-\* and IX-RS-\*)

Description	Send SIF command when door release request is sent.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

#### ■ End Communication (except IXW-MA)

Description	Send SIF command when ending communication.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

#### ■ Change contact

Description	Send SIF command when Option Input contact or Relay Output contact is changed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Unit error

Description	Send SIF command when communication error has occurred.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Begin broadcast (for IX-MV7-\*)

Description	Send SIF command when paging is started.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ End broadcast (for IX-MV7-\*)

Description	Send SIF command when paging has ended.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Begin Transfer (for IX-MV7-\*)

Description	Send SIF command when communication begins after transferring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ End Transfer (for IX-MV7-\*)

Description	Send SIF command when communication ends after transferring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Periodical Transmission

Description	Periodically send the station status using SIF command. The interval is set in <a href="#">“Periodical Transmission (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 483)”</a> .
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

## ■ Initialization Notice

Description	Send SIF command when the station is booted.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Outgoing Call (except IXW-MA)**

Description	Send SIF command when ending a outgoing call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Incoming Call (except IXW-MA)**

Description	Send SIF command when beginning a incoming call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Incoming Call (except IXW-MA)**

Description	Send SIF command when ending a incoming call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Latch Reset (except IX-MV7-\* and IXW-MA)**

Description	Send SIF command by reset latch relay output. ("Latch Output" is selected in "Relay Output" - <a href="#">"Function (→page 440)"</a> .)
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Change Call Destination (except IXW-MA)**

Description	Send SIF command when changing call destination by delay time or schedule, or making an absent transfer, delay transfer or schedule transfer by the destination station.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Call Failure (except IXW-MA)**

Description	Send SIF command when failed to place a call.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Incoming Transfer Call (for IX-MV7-\*)**

Description	Send SIF command when beginning Absent Transfer, Delay Transfer or Schedule Transfer.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin On Hold (for IX-MV7-\*)**

Description	Send SIF command when beginning a call on hold.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End On Hold (IX-MV7-\* only)**

Description	Send SIF command when ending a call on hold.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Incoming Page (except IXW-MA)**

Description	Send SIF command when beginning a incoming page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Incoming Page (except IXW-MA)**

Description	Send SIF command when ending a incoming page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Paging Failure (for IX-MV7-\*)**

Description	Send SIF command when failed to send a page.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Monitoring (for IX-MV7-\*)**

Description	Send SIF command when beginning monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Monitoring (for IX-MV7-\*)**

Description	Send SIF command when ending monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Monitoring Failure (for IX-MV7-\*)**

Description	Send SIF command when failed monitoring.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Monitored (except IX-MV7-\* and IXW-MA)**

Description	Send SIF command when beginning being monitored.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Monitored (except IX-MV7-\* and IXW-MA)**

Description	Send SIF command when ending being monitored.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Communication (Destination) (except IXW-MA)**

Description	Send SIF command when beginning a communication.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Begin Privacy (for IX-MV7-\*)**

Description	Send SIF command when beginning privacy mode.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ End Privacy (for IX-MV7-\*)**

Description	Send SIF command when ending privacy mode.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

**■ Keypad Input (for IX-MV7-\*)**

Description	Send SIF command when entering number using a keypad.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Speed Dial Input (for IX-MV7-\*)

Description	Send SIF command when pressing a speed dial button.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Begin Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when beginning recording.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ End Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when ending recording.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Recording Memory Full (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	<p>Send SIF command when a microSD card meets following criteria. If the error is detected continuously, SIF command will not be sent an additional time.</p> <ul style="list-style-type: none"> <li>• When <a href="#">"Prevent Overwrite" (→page 486)</a> is set to "Enable." <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 950</li> <li>– Storage capacity remaining 5%</li> </ul> </li> <li>• When <a href="#">"Prevent Overwrite" (→page 486)</a> is set to "Disable." <ul style="list-style-type: none"> <li>– Recorded recordings exceeds 999</li> <li>– Storage capacity remaining 0%</li> </ul> </li> </ul>
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Passed Line Supervision (for IX-MV7-\*)

Description	Send SIF command when the result of Line Supervision is passed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Failed Line Supervision (for IX-MV7-\*)

Description	Send SIF command when the result of Line Supervision is failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

### ■ Passed Device Check (for IX-MV7-\*)

Description	Send SIF command when the result of Device Check is passed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ Failed Device Check (for IX-MV7-\*)

Description	Send SIF command when the result of Device Check is failed.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ SD Card Error (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Send SIF command when a microSD access error is detected.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ SIP Registration Failure (except IXW-MA)

Description	Send SIF command when REGISTER request for SIP server has a failure.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

■ Network Camera Event (for IX-MV7-\*)

Description	Send SIF command when receiving event from the network camera.
Settings	<ul style="list-style-type: none"> <li>• Checked: Send</li> <li>• Unchecked: Do not send</li> </ul>
Default values	Unchecked: Do not send

7.7.5 Periodical Transmission (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))



■ Periodical Transmission Interval◆

Description	Set the interval to send the station status periodically using SIF command in <a href="#">“Periodical Transmission (→page 478)”</a> .
Settings	<ul style="list-style-type: none"> <li>• If set to 1[sec]-59[sec]: Set from 1 - 59 sec (by 1 sec).</li> <li>• If set to 0[min]-1440[min]: Set from 0 - 1440 min (by 1 min).</li> </ul>
Default values	0 min (do not send)

## 7.7.6 SIF File Management



### ! Important

- To upload a SIF setting file, [“Association Settings \(→page 160\)”](#) must be preformed in the uploading station. And the programming PC and the station must be connected to the same network.

### ■ SIF Communication Settings (sif.ini)

Description	Upload or download the content in <a href="#">“SIF Settings (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 475)”</a> with "sif.ini." Upload: Click <b>[Browse]</b> , select a file, and click <b>[Upload]</b> . Download: Click <b>[Download]</b> to save the file.
Settings	-
Default values	-


### ■ SIF Parameter Settings (sif\_conf.ini)

Description	Use "sif_conf.ini" to upload or download SIF details if <a href="#">“Program Type♣ (→page 475)”</a> is set to "0000," "0001," or "0011." Upload: Click <b>[Browse]</b> to select a file, and then click <b>[Upload]</b> . Download: Click <b>[Download]</b> to save a file.
Settings	-
Default values	-

## 7.8 Record (for IX-MV7-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Configure settings related to video and audio recording. If there is no video, configure only audio recording. When recording audio during a call, audio will be recorded from both sides. The following SD standards are required to record video and audio.

Standards	Memory Capacity	Format	Speed Class
microSDHC	Max. 32 GB	FAT32	SD speed class 10
microSDXC (for IX-MV7-*)	Max. 128 GB	exFAT	SD speed class 10 UHS speed class 1



### ! Important

- A microSD card is not included with this station.
- The device may not operate correctly depending on the microSD card.
- If the card contains data other than video/audio files, it may not have enough space to record video/audio.
- Depending on the size of the image, recording with the network camera may not be possible.

### 💡 Note

- A maximum of 999 video/audio files can be saved. However, this may vary depending on the size of the video/audio files and the capacity of the microSD card.
- Line Supervision and Device Check results are also saved to the microSD card.
- Aiphone assumes no responsibility for microSD cards. Please be aware of this in advance.

### ■ Record Mode (for IX-DV, IX-DVF(-\*), IX-SSA(-\*)) ♣

Description	Select the Record Mode.
Settings	<ul style="list-style-type: none"> <li>• No Recording</li> <li>• Event Recording: Automatically record when the trigger set in "Record Event" has occurred.</li> <li>• 24/7 Recording: Keep recording 24/7 while station is operating normally.</li> </ul>
Default values	No Recording

## ■ Record Event

Description	Configure the trigger in use to start recording video/audio automatically. For stations other than IX-MV7-*, "Record Mode" must be set to "Event Recording."
Settings	Select from the following. (Multiple selections allowed) <ul style="list-style-type: none"> <li>• Not selected: Video/audio is not automatically recorded.</li> <li>• Incoming Call (for IX-MV7-*): Record start when station receives Incoming Call. If a call is automatically answered, recording will start when communication starts.</li> <li>• Communication (Master) (for IX-MV7-*): Recording starts when communication begins.</li> <li>• Monitor (for IX-MV7-*): Recording starts when monitoring begins. Recording is not possible during Scan Monitor.</li> <li>• Outgoing Call (for IX-DV, IX-DVF(-*), IX-SSA(-*)): Video recording will start when a call is placed. Audio recording will start once the outgoing call is answered. For IX-SSA(-*), audio recording will start once the outgoing call is answered.</li> <li>• Communication (Door) (for IX-DV, IX-DVF(-*), IX-SSA(-*)): Recording starts when communication begins.</li> <li>• Monitored (for IX-DV, IX-DVF(-*), IX-SSA(-*)): Recording starts when station is Monitored. Recording is not possible during Scan Monitor.</li> <li>• Schedule (for IX-DV, IX-DVF(-*), IX-SSA(-*)): Record during schedule set in <a href="#">"Weekly Schedule (→page 488)"</a>.</li> </ul>
Default values	Not selected

### Important

- If "Schedule" is selected, video/audio recording will continue for the time configured in ["Weekly Schedule \(→page 488\)"](#), regardless of what is configured for other triggers.

## ■ Recorded Device (IX-MV7-\* only)

Description	Set the Recorded Device when IX-MV7-* is displaying video from an IX Station and a Network Camera simultaneously.
Settings	<ul style="list-style-type: none"> <li>• IX Station: Record IX Station video and audio.</li> <li>• Network Camera: Record Network Camera video and IX station audio.</li> </ul>
Default values	IX Station

## ■ Prevent Overwrite♣

Description	Set prevent overwriting the old recorded file, when the number of saved video/audio files, the entire storage space of the microSD card, or the video/audio recording storage space of the microSD card is full.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## ■ Video Recording File Length♣

Description	Select the recording file length to split recording. Once recording has reached this time, a new recording file will be made automatically.
Settings	<ul style="list-style-type: none"> <li>• 5 min</li> <li>• 10 min</li> <li>• 20 min</li> <li>• 40 min</li> <li>• 60 min</li> </ul>
Default values	10 min

**Note**

- If the Video Recording File Length is changed during recording video/audio, the setting will not be applied until the recording is completed.

**■ Event Recording Timer (for IX-MV7-\*)<sup>♣</sup>**

Description	Set the recording duration when the event trigger has occurred.
Settings	<ul style="list-style-type: none"> <li>• Disable: Does not stop until the operating status ends or the record button is tapped.</li> <li>• 5 sec</li> <li>• 10 sec</li> <li>• 30 sec</li> </ul>
Default values	Disable

**■ Manual Recording (for IX-MV7-\*)<sup>♣</sup>**

Description	Select Enable / Disable for manual recording.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

**■ Audio Recording (for IX-MV7-\*, IX-DV, IX-DVF(-\*))<sup>♣</sup>**


Description	Select Enable / Disable for audio recording with video.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

## 7.8.1 Schedule Settings (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

### 7.8.1.1 Weekly Schedule

Configure this when "Schedule" is selected in ["Record Event \(→page 486\)"](#).

Configure the video and audio recording time for each day from Sunday to Saturday. Up to 12 schedules can be set for each day.



#### How to configure a Weekly Schedule

1. Configure "Start Time" and "End Time" for each day of week.
2. When done, click **[Update]**.
3. Click **[OK]**.

#### ■ Start Time

Description	Set the Start Time to begin recording.
Settings	00:00 - 23:59
Default values	-

#### ■ End Time

Description	Set the End Time to stop recording. If this is set earlier than "Start Time," the end time will be for the following day.
Settings	00:00 - 23:59
Default values	-

#### How to delete a Weekly Schedule

1. Return the settings to their default values and click **[Update]**.
2. Click **[OK]**.

## 7.9 Communication Audio Messages (for IX-RS-\*, IX-DV, IX-DVF(-\*), IX-SSA(-\*), IX-SS-2G)

Configure communication audio message.

Communication Audio Messages: Send messages to destination station when beginning communication or by keypad input from the other station (IX-MV7-\*).

•Communication Audio Messages

Start Communication  
None

Code Received

#	Code 1-20 digits	Message
1		None
2		None
3		None
4		None

### 7.9.1 Start Communication

#### ■ Message

Description	Select the message to be sent to destination station when beginning communication.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	None

## 7.9.2 Code Received

Configure the message to be sent when the code is received. Four patterns can be set for the received code and message.

### Code

Description	Set the code to play message by keypad input from IX-MV7-*
Settings	1-20 digits
Default values	-



### Note

- Enter " \* Authentication Key \*" on the numerical keypad (if the Authentication Key is "0000" enter " \* 0000 \*").

### Message


Description	Set the code to play message by keypad input from IX-MV7-*
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	None

## 7.10 Chime (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA)

Configure the chime tone to be played from this station linked with the set schedule.

### 7.10.1 Weekly Schedule

Configure the start time and chime tone to play for each day of the week, from Sunday to Saturday. 50 schedules can be set for each day.



#### How to configure a Weekly Schedule

1. Configure "Start Time" and "Chime" for each day of week.
2. When done, click **[Update]**.
3. Click **[OK]**.

#### ■ Start Time

Description	Set the Time to ring Chime.
Settings	00:00 - 23:59
Default values	-

## ■ Chime

Description	Set the sound for chime.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	None

### How to delete a Weekly Schedule

1. Return the settings to their default values and click **[Update]**.
2. Click **[OK]**.

### 7.10.2 Daily Schedule

Configure the start time and the chime tone in units of one day.

A schedule one year from the set day can be configured. 50 schedules can be set for each day.

**Daily Schedule**

Calendar

0/50 Registered

Start Time:  Hour  Minute

Chime:

Add (\*)Press "Add" button to register.

Friday, November 9 Chime Schedule List (Daily, Weekly)

Chime Schedule List

#	Type	Start Time	Chime	Delete
001				
002				
003				
004				
005				
006				
007				
008				
009				
010				
011				
012				
013				

#### How to configure Daily Schedule

1. Select the day to set a schedule from "Calendar."
2. Configure "Start Time" and "Chime," and click **[Add]**.
3. When done, click **[Update]**.
4. Click **[OK]**.

■ Start Time

Description	Set the Time to ring Chime.
Settings	00:00 - 23:59
Default values	-

■ Chime

Description	Set the sound for chime.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	None

**How to delete Daily Schedule**

1. Select the day for which to delete a schedule from "Calendar."
2. Schedules for the selected day are displayed in the Chime "Set Schedule List."
  - If a weekly schedule is configured for the selected day of the week, it will also be shown.
3. Click **[Delete]** for the schedule that you want to delete, and click **[Update]**.
  - Refer to [“How to delete a Weekly Schedule \(→page 492\)”](#) to delete a weekly schedule.
4. Click **[OK]**.

## 7.11 CSR


Generate the signature request (CSR) submitted when a request is made to the Server Certificate Authority (CA)

### ! Important

- To generate a signature request, "[Association Settings \(→page 160\)](#)" must have been completed on the station to generate the request, and the PC must be able to communicate with the system.

#### How to generate a CSR

- Input each item.
- Click **[Create]**.
- Click **[OK]**.
  - Click **[Cancel]** to back to the Settings screen without generating the CSR.



- Specify the save location and store your created file in it.
  - The default file name is "CSR." This file name must be changed.
- Click **[OK]**.

#### ■ Country

Description	Set the country name.
Settings	The two-letter code
Default values	-

#### ■ State/County/Region

Description	Set the State/County/Region.
Settings	1-128 alphanumeric characters
Default values	-

■ City/Locality

Description	Set the City/Locality.
Settings	1-128 alphanumeric characters
Default values	-

■ Organization

Description	Set the organization name.
Settings	1-128 alphanumeric characters
Default values	-

■ Organizational Unit

Description	Set the department name.
Settings	1-64 alphanumeric characters
Default values	-

■ Common Name

Description	Set the common name.
Settings	1-64 alphanumeric characters
Default values	The station's IP address is listed.

## 7.12 SSL Certificate

Upload the Server Certificate received from the Certificate Authority (CA) as well as the CA certificate.

•SSL Certificate

Server Certificate


CA Certificate

### ! Important

- To upload an SSL certificate, "[Association Settings \(→page 160\)](#)" must have been completed on the station, and the PC must be able to communicate with the system.
- When uploading the SSL certificate, restart the station. This may take approx. 10 minutes in total. The station will not function until complete.
- The server certificate must be uploaded when uploading a CA certificate.

### How to upload SSL Certificates

1. Click **[Browse]** in the Server Certificate to select a file.
2. If required, click **[Browse]** in the CA Certificate to select a file.
3. Click **[Upload]**.
4. Click **[OK]**, and upload the Server Certificate and CA Certificate files.
  - When uploading is completed, the station will restart.
  - Click **[Cancel]** to back to the Settings screen without uploading the file.



5. Click **[OK]**.

## 7.13 IEEE 802.1X (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure the settings for IEEE802.1X Authentication.

### ! Important

- Authentication may be impossible if there is a time difference between the authentication server and station.
- Upload the certificate prior to configuration.
- To upload/delete an IEEE802.1X certificate, [“Association Settings \(→page 160\)”](#) must have been completed on the station to upload/delete, and the PC must be able to communicate with the system.
- When changes to IEEE802.1X settings are updated on the station, or after uploading a certificate, restart the station. Restart may take up to 10 minutes in total. The station will not operate until restart is complete.

### ■ IEEE 802.1X

Description	Select Enable / Disable for IEEE802.1X function.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### ■ EAP♠

Description	Select the EAP method for IEEE802.1X authentication when <a href="#">“IEEE 802.1X (→page 498)”</a> is set to "Enable".
Settings	<ul style="list-style-type: none"> <li>• TLS</li> <li>• PEAP</li> </ul>
Default values	TLS

### ■ EAP User Name♠

Description	Set the EAP User Name.
Settings	1 - 32 alphanumeric characters
Default values	-

### ■ EAP Password♠


Description	Set the EAP Password when "EAP" is set to "PEAP".
Settings	1 - 32 alphanumeric characters
Default values	-

 Note

- "EAP Password" is shown as "\*\*\*\*\*" in the Settings screen.

**How to upload IEEE802.1X certificates**

1. Click **[Browse]** next to the Certificate Authority to select a file.
2. If "**EAP** (→page 498)" is set to "TLS," click **[Browse]** next to the Client Certificate to select a file.
3. If "**EAP** (→page 498)" is set to "TLS," click **[Browse]** next to Client Private Key to select a file.
4. Click **[Upload]**.
5. Click **[OK]** and upload each file.
  - When uploading is completed, the station will restart.
  - Click **[Cancel]** to back to the Settings screen without uploading the file.



6. Click **[OK]**.

**How to delete IEEE802.1X certificates**

1. Click **[Delete]** to delete the uploaded file.
2. Click **[OK]**.

## 7.14 Display Mode (for IX-MV7-\*)

Configure IX-MV7-\* Master UI Mode, for both Standard and Receptionist modes.

### 7.14.1 Master UI Mode

**•Display Mode**

Changing Display Mode settings will cause station to restart after Update is clicked. This will take a few minutes.

Master UI Mode       Standard       Receptionist

Description	Set the User Interface Mode.
Settings	<ul style="list-style-type: none"> <li>• Standard: All functions can be used.</li> <li>• Receptionist: Only outgoing call can be used. Refer to <a href="#">"Receptionist Mode (→page 502)"</a> for detail settings.</li> </ul>
Default values	Standard

**! Important**


- When the "Master UI Mode" setting is applied to the station it will restart. This may take up to 10 minutes and the station cannot be used until it has finished restarting.

### 7.14.2 Standard Mode

Standard Mode

Home Screen  Option 1  Option 2

#### ■ Home Screen

Description	Select the layout of top image when " <a href="#">Master UI Mode (→page 500)</a> " is set to "Standard."
Settings	<ul style="list-style-type: none"> <li>• Option 1:                      </li> <li>• Option 2:                      </li> </ul>
Default values	Option 1

### 7.14.3 Receptionist Mode

Configure Receptionist Mode screen if ["Master UI Mode \(→page 500\)"](#) was set to "Receptionist."

**! Important**

- In receptionist mode, the following operations are limited.
  - Calling can only be done in the method configured in ["Button Function \(→page 508\)"](#).
  - Auto Answer is enabled even if ["Auto Answer \(→page 431\)"](#) was set to "OFF." However, the call will not be received if ["Reject Incoming Call \(→page 509\)"](#) was set to "Enable."
  - For "Option Input" - ["Function \(→page 437\)"](#), only "Call" and "Turn LCD On" are valid.



#### 7.14.3.1 Color Scheme



Description	Select the Color Scheme of Receptionist Mode.
Settings	<p>Example where "Layout 1" was set in <a href="#">"Screen Layout (→page 503)"</a></p> <ul style="list-style-type: none"> <li>• Light:             <div style="text-align: center; margin: 10px 0;"> </div> </li> <li>• Dark:             <div style="text-align: center; margin: 10px 0;"> </div> </li> </ul>
Default values	Light

7.14.3.2 Screen Layout


Screen Layout     Layout 1     Layout 2     Layout 3

Description	Select the Screen Layout of top image for Receptionist Mode.
Settings	<p>Example where "Light" was set in <a href="#">"Color Scheme (→page 502)"</a></p> <ul style="list-style-type: none"> <li>• Layout 1:                      </li> <li>• Layout 2:                      </li> <li>• Layout 3:                      </li> </ul>
Default values	Layout 1


## Customizing each screen layout

The layout of each characters screen's, images, and button displays can be customized.  
 The following spaces are customized by configuring [“Company Information \(→page 505\)”](#) [“Greeting Information \(→page 506\)”](#) [“Images \(→page 507\)”](#) [“Button Function \(→page 508\)”](#).


Layout 1



Layout 2



Layout 3



### 7.14.3.3 Company Information

Company Information

Name  0-40 alphanumeric characters

Text Size  12-24

Bold  OFF  ON

Text Color  Option 1  Option 2

#### ■ Name

Description	Enter the Company Information.
Settings	0-40 alphanumeric characters
Default values	—

#### ■ Text Size◆

Description	Set the text size of Company Information.
Settings	12 - 24 pt (by 1pt)
Default values	12pt


#### ■ Bold

Description	Select ON / OFF for Bold text.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• ON</li> </ul>
Default values	OFF

#### ■ Text Color

Description	Set the text color of Company Information.
Settings	<ul style="list-style-type: none"> <li>• Option 1 "Black" if "Light" was set in <a href="#">"Color Scheme (→page 502)"</a>. "White" if "Dark" was set.</li> <li>• Option 2 "Blue" if <a href="#">"Color Scheme (→page 502)"</a> was set to "Light." "Orange" if "Dark" was set.</li> </ul>
Default values	Option 1

### 7.14.3.4 Greeting Information



#### ■ Greeting

Description	Enter Greeting text.
Settings	0-100 alphanumeric characters (Up to 10 line breaks can be inserted.)
Default values	-

#### ■ Text Size◆

Description	Set the text size of Greeting.
Settings	12 - 70 pt (by 1 pt)
Default values	12pt

#### ■ Bold

Description	Select ON / OFF for Bold text.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• ON</li> </ul>
Default values	OFF

#### ■ Text Color

Description	Set the text color of Company Information.
Settings	<ul style="list-style-type: none"> <li>• Option 1 "Black" if "Light" was set in <a href="#">"Color Scheme (→page 502)"</a>. "Blue" if "Dark" was set.</li> <li>• Option 2 "Blue" if <a href="#">"Color Scheme (→page 502)"</a> was set to "Light." "Orange" if "Dark" was set.</li> </ul>
Default values	Option 1

### 7.14.3.5 Images

Upload the image file to be shown on the reception screen. Upload an image file that matches the layout set in [“Screen Layout \(→page 503\)”](#). Refer to [“Customizing each screen layout \(→page 504\)”](#) for the recommended resolution of the image file for each screen's layout.

Images

To upload Image to the station, upload image file using "Upload Settings To Station".

Company Image	<input type="text"/>	<input type="button" value="Browse"/>	<input type="checkbox"/> Delete
Greeting Image	<input type="text"/>	<input type="button" value="Browse"/>	<input type="checkbox"/> Delete
Receptionist Image	<input type="text"/>	<input type="button" value="Browse"/>	<input type="checkbox"/> Delete

#### ■ Company Image

Description	Register an image file to be displayed in Image Space 1. Supported file format <ul style="list-style-type: none"> <li>Message File Name: within 20 characters (excluding extension).</li> <li>File format: png</li> <li>Resolution                         <ul style="list-style-type: none"> <li>Width: 400 - 800 pixels</li> <li>Height: 80 - 480 pixels</li> </ul> </li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Supported file format: png Delete: Place a check in <b>[Delete]</b> .
Default values	-

#### ■ Greeting Image

Description	Register an image file to be displayed in Image Space 2. Supported file format <ul style="list-style-type: none"> <li>Message File Name: within 20 characters (excluding extension).</li> <li>File format: png</li> <li>Resolution                         <ul style="list-style-type: none"> <li>Width: 400 - 800 pixels</li> <li>Height: 80 - 480 pixels</li> </ul> </li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Delete: Place a check in <b>[Delete]</b> .
Default values	-

#### ■ Receptionist Image

Description	Register an image file to be displayed in Variable Space. Supported file format <ul style="list-style-type: none"> <li>Message File Name: within 20 characters (excluding extension).</li> <li>File format: png</li> <li>Resolution                         <ul style="list-style-type: none"> <li>Width: 400 - 800 pixels</li> <li>Height: 80 - 480 pixels</li> </ul> </li> </ul>
Settings	Register: Click <b>[Browse]</b> to select a file. Delete: Place a check in <b>[Delete]</b> .
Default values	-

### 7.14.3.6 Button Function

Configure the buttons to be shown on the reception screen and their function. Refer to [“Customizing each screen layout \(→page 504\)”](#) for configuration.

Button Function		
Button 1	<input type="text" value="Hide"/>	
Button 2	<input type="text" value="Hide"/>	
Button 3	<input type="text" value="Hide"/>	
Button 4	<input type="text" value="Hide"/>	
Button Name for Group Call	<input type="text"/>	1-24 alphanumeric characters
Button Name for Select By Name	<input type="text"/>	1-24 alphanumeric characters
Button Name for Select By List	<input type="text"/>	1-24 alphanumeric characters
Button Name for Enter Number	<input type="text"/>	1-24 alphanumeric characters

#### ■ Button 1

Description	Set the function of Button 1.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by <a href="#">“Group Call Destination (→page 509)”</a>.</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

#### ■ Button 2

Description	Configure the function of Button 2.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by <a href="#">“Group Call Destination (→page 509)”</a>.</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

#### ■ Button 3

Description	Configure the function of Button 3.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by <a href="#">“Group Call Destination (→page 509)”</a>.</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

#### ■ Button 4

Description	Configure the function of Button 4.
Settings	<ul style="list-style-type: none"> <li>• Group Call: Call group number set by <a href="#">“Group Call Destination (→page 509)”</a>.</li> <li>• Select By Name: Select destination station by name.</li> <li>• Select By List: Select destination station by list.</li> <li>• Enter Number: Enter destination station number by keypad.</li> <li>• Hide: Button is not displayed.</li> </ul>
Default values	Hide

### ■ Button Name for Group Call

Description	Configure the name of the button when "Group Call" is selected for "Button 1" through "Button 4." If there is more than one "Group Call" set, they share the name.
Settings	1-24 alphanumeric characters
Default values	-

### ■ Button Name for Select By Name

Description	Configure the name of the button when "Select By Name" is selected for "Button 1" through "Button 4." If there is more than one "Select By Name" set, they share the name.
Settings	1-24 alphanumeric characters
Default values	-

### ■ Button Name for Select By List

Description	Configure the name of the button when "Select By List" is selected for "Button 1" through "Button 4." If there is more than one "Select By List" set, they share the name.
Settings	1-24 alphanumeric characters
Default values	-

### ■ Button Name for Enter Number

Description	Configure the name of the button when "Enter Number" is selected for "Button 1" through "Button 4." If there is more than one "Enter Number" set, they share the name.
Settings	1-24 alphanumeric characters
Default values	-

#### 7.14.3.7 Group Call Destination

Group Call Destination   01-99

Description	Configure the call destination group number when a button is pressed, if "Group Call" was selected for "Button 1" through "Button 4." If "Group Call" is set for multiple buttons, they will all share the same call destination group. Enter the group number directly, or click <b>[Open Group List]</b> to choose a group.
Settings	01 - 99
Default values	-

#### 7.14.3.8 Reject Incoming Call

Reject Incoming Call  Enable  Disable

Description	Select Enable / Disable for incoming calls in Receptionist Mode.
Settings	<ul style="list-style-type: none"> <li>• Enable: Do not receive incoming calls.</li> <li>• Disable: Receive incoming calls.</li> </ul>
Default values	Disable

## 7.15 Bathroom Link

This function cannot be used outside Japan.

# 8. Transfer Settings

## 8.1 Absent Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for absent transfer.

Absent Transfer: If an incoming call is received during absent transfer, the incoming call can be automatically transferred to a transfer destination.

**For IX-MV7-\***

The screenshot shows the 'Absent Transfer' configuration page. At the top, there are radio buttons for 'Enable' and 'Disable', with 'Disable' selected. Below this is a 'Transfer Destination List' table with 10 rows. Each row has a '#' column and a 'Number' column (3-32 digits). To the right of the table is an 'Open' button. Below the table is a 'Re-Transfer Destination' field with an 'Open' button and a '3-32 digits' label.

#	Number 3-32 digits
01	
02	
03	
04	
05	
06	
07	
08	
09	
10	

Re-Transfer Destination: [ ] Open 3-32 digits

**For IX-MV**

The screenshot shows a zoomed-in view of the configuration for IX-MV. It highlights the 'Transfer Destination' field with the value '10' and an 'Open' button. Below it is another 'Transfer Destination' field with an 'Open' button and a '3-5 digits' label.

Transfer Destination: 10 [ ] Open

Transfer Destination: [ ] Open 3-5 digits

### ! Important

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which ["IP Address \(→page 381\)"](#) has not been configured cannot be configured as transfer destinations.

### ■ Absent Transfer

Description	Select Enable / Disable for Absent Transfer. The setting can also be changed with the button on the station. If "Transfer Destination List" ("Transfer Destination" for IX-MV) is not configured, this cannot be set to "Enable."
Settings	<ul style="list-style-type: none"> <li>• Enable: Set absent transfer.</li> <li>• Disable: Do not set absent transfer.</li> </ul>
Default values	Disable

■ Transfer Destination List (for IX-MV7-\*)

Description	Configure the transfer destination station (Number) for absent transfer. Up to 10 transfer destination stations can be configured. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the transfer will be made only to the station entered in "No.01." Click <b>[Open]</b> to choose a station. For IX-MV, a VoIP phone cannot be set as the transfer destination.
Settings	-
Default values	-

 **Important**

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

■ Transfer Destination (for IX-MV)

Description	Configure the transfer destination station (number) for absent transfer. Only one transfer destination station can be configured. Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-5 digits
Default values	-

■ Re-Transfer Destination (for IX-MV7-\*)

Description	Configure the transfer destination station (number) for absent re-transfer for a transferred call. Only a single station can be configured as the transfer destination. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the call will be received without transferring it again. Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-32 digits
Default values	-

## 8.2 Delay Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for delay transfer.

Delay Transfer: A call can be automatically transferred to another station after a certain period of time (delay time) elapses.

**For IX-MV7-\***

**Delay Transfer**

Delay Transfer  Enable  Disable

Delay Time [sec]  1-300 sec

Transfer Destination List

#	Number 3-32 digits	
01	<input type="text"/>	<input type="button" value="Open"/>
02	<input type="text"/>	
03	<input type="text"/>	
04	<input type="text"/>	
05	<input type="text"/>	
06	<input type="text"/>	
07	<input type="text"/>	
08	<input type="text"/>	
09	<input type="text"/>	
10	<input type="text"/>	

Re-Transfer Destination   3-32 digits

**For IX-MV**

10	<input type="text"/>	
----	----------------------	--

Transfer Destination   3-5 digits

### Important

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which ["IP Address \(→page 381\)"](#) has not been configured cannot be configured as transfer destinations.

### ■ Delay Transfer

Description	Select Enable / Disable for Delay Transfer. To enable Delay Transfer, set transfer or re-transfer destination. If "Transfer Destination List" ("Transfer Destination" for IX-MV) is not configured, this cannot be set to "Enable."
Settings	<ul style="list-style-type: none"> <li>• Enable: Delay transfer enabled.</li> <li>• Disable: Delay transfer disabled.</li> </ul>
Default values	Disable

## ■ Delay Time [sec]◆

Description	Set the delay time between receiving and transferring a call.
Settings	1-300 sec (by 1 sec)
Default values	30 sec

## ■ Transfer Destination List (for IX-MV7-\*)

Description	Configure the transfer destination station (Number) for delay transfer. Up to 10 transfer destination stations can be configured. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*) the transfer will be made only to the station entered in "No.01." Click <b>[Open]</b> to choose a station. For IX-MV, a VoIP phone cannot be set as the transfer destination.
Settings	-
Default values	-

## ! Important

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

## ■ Transfer Destination (for IX-MV)

Description	Configure the transfer destination station (number) for delay transfer. Only one transfer destination station can be configured. Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-5 digits
Default values	-

## ■ Re-Transfer Destination (for IX-MV7-\*)

Description	Configure the transfer destination station (number) for delay re-transfer for a transferred call. Only a single station can be configured as the transfer destination. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the call will be received without transferring it again. Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-32 digits
Default values	-

## 8.3 Schedule Transfer (for IX-MV7-\* and IX-MV)

Configure the settings for Schedule Transfer.

Schedule Transfer: A call can be automatically transferred to another station when a call comes in during the time period set up in [“Weekly Schedule \(→page 515\)”](#) and [“Daily Schedule \(for IX-MV7-\\*\) \(→page 517\)”](#).

•Schedule Transfer

The schedule is automatically sorted by Start Time after updating.  
To upload Weekly Schedule, Daily Schedule to the station, upload schedule file using "Upload Settings To Station".

Schedule Transfer  Enable  Disable

### ! Important

- When an incoming call is received from a VoIP Phone, the call will be received without transferring even when transfer is set. To transfer the call, configure transferring on the IP-PBX.
- Stations in which [“IP Address \(→page 381\)”](#) has not been configured cannot be configured as transfer destinations.
- Incoming calls will be transferred during the time period set in "Schedule Transfer," regardless of what was set in [“Absent Transfer \(for IX-MV7-\\* and IX-MV\) \(→page 511\)”](#) and [“Delay Transfer \(for IX-MV7-\\* and IX-MV\) \(→page 513\)”](#).

### ■ Schedule Transfer

Description	Select Enable / Disable for Schedule Transfer. To enable Schedule Transfer, set transfer or re-transfer destination. If <a href="#">“Weekly Schedule (→page 515)”</a> or <a href="#">“Daily Schedule (for IX-MV7-*) (→page 517)”</a> is not configured, this cannot be set to "Enable."
Settings	<ul style="list-style-type: none"> <li>• Enable: Schedule transfer enabled.</li> <li>• Disable: Schedule transfer disabled.</li> </ul>
Default values	Disable

### 8.3.1 Weekly Schedule

Configure the transfer destination and transfer time for every day from Sunday through Saturday.

For IX-MV7-\*, up to 12 schedules can be set for each day, and for the IX-MV, one schedule can be set for each day.

**For IX-MV7-\***

Weekly Schedule  
(\*Up to 12 schedules can be set per day)

#	Sun										Re-Transfer Destination	Start Time	End Time	Mon							
	Transfer Destination	No.01	No.02	No.03	No.04	No.05	No.06	No.07	No.08	No.09				No.10	Transfer Destination	No.01	No.02	No.03	No.04		
01	Open											Open					Open				
02	Open											Open					Open				
03	Open											Open					Open				
04	Open											Open					Open				
05	Open											Open					Open				
06	Open											Open					Open				
07	Open											Open					Open				
08	Open											Open					Open				
09	Open											Open					Open				
10	Open											Open					Open				
11	Open											Open					Open				

**For IX-MV**

Weekly Schedule  
(\*Up to 12 schedules can be set per day)

#	Transfer Destination	Sun		Mon		Tue		Wed		Thu		Fri		Sat
		Start Time	End Time	Start Time										
1	Open													

### How to configure the Weekly Schedule

1. IX-MV7-\*: Configure the "Transfer Destination," "Re-Transfer Destination," "Start Time," and "End Time" for each day of the week.

IX-MV: Configure "Transfer Destination," and "Start Time" and "End Time" for each day of week.

2. When done, click **[Update]**.
3. Click **[OK]**.

### ■ Transfer Destination

Description	<p>Configure the transfer destination station (Number) for a scheduled transfer.</p> <ul style="list-style-type: none"> <li>• IX-MV7-*: Up to 10 transfer destination stations can be configured for each of the 12 schedules, and for each day of the week. However, if the station making the outgoing call is an IX-MV, IX-DA, IX-DF(-*), or IX-BA, IX-SS(-*), the transfer will only be made to the station entered in "No.01."</li> <li>• IX-MV: Only a single transfer destination station can be set for each day of the week. A VoIP phone cannot be set as the transfer destination.</li> </ul> <p>Enter Number manually, or click <b>[Open]</b> to choose a station.</p>
Settings	<p>IX-MV7-*: 3-32 digits IX-MV: 3-5 digits</p>
Default values	-

### ! Important

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

### ■ Re-Transfer Destination (for IX-MV7-\*)

Description	<p>Configure the transfer destination when performing a schedule transfer again for a transferred call. Only a single station can be configured as the transfer destination for each of the 12 schedules for each day of the week. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the call will be received without transferring it again.</p> <p>Enter Number manually, or click <b>[Open]</b> to choose a station.</p>
Settings	3-32 digits
Default values	-

### ■ Start Time

Description	Set the Start Time to enable schedule transfer.
Settings	00:00 - 23:59
Default values	-

### ■ End Time


Description	Set the End Time to disable schedule transfer.
Settings	00:00 - 23:59
Default values	-

#### How to delete the Weekly Schedule

1. Return the settings to their default values and click **[Update]**.
2. Click **[OK]**.

### 8.3.2 Daily Schedule (for IX-MV7-\*)

Configure the transfer destination and time for each individual day.  
 A schedule one year from the set day can be configured. 12 schedules can be set for each day.



#### How to configure Daily Schedule

1. Select the day to configure a schedule from "Calendar."
2. Configure "Transfer Destination," "Re-Transfer Destination," "Start Time," and "End Time," and click **[Add]**.
3. When done, click **[Update]**.
4. Click **[OK]**.

#### ■ Transfer Destination

Description	Configure the transfer destination station (Number) for schedule transfer. Up to 10 transfer destination stations can be configured for each of the 12 schedules for each day of the week. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), he transfer will be made only to the station entered in "No.01." Click <b>[Open]</b> to choose a station.
Settings	-
Default values	-

**! Important**

- Do not configure multiple VoIP Phone. If multiple VoIP Phone are configured, calls will be transferred to only one VoIP Phone.

### ■ Re-Transfer Destination

Description	Configure the transfer destination station (Number) when performing schedule transfer again for a transferred call. Only a single station can be configured as the transfer destination for each of the 12 schedules on each day. However, if the station making the outgoing call is IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*), the call will be received without transferring it again. Enter Number directly, or click <b>[Open]</b> to choose a station.
Settings	3-32 digits
Default values	-

### ■ Start Time

Description	Set the Start Time to enable schedule transfer.
Settings	00:00 - 23:59
Default values	-

### ■ End Time

Description	Set the End Time to disable schedule transfer. If this is set earlier than "Start Time," End Time will be for the following day.
Settings	00:00 - 23:59
Default values	-

#### How to delete Daily Schedule

1. Select the day to delete a schedule from "Calendar."
2. Schedules for the selected day are displayed in the "Set Schedule List."
  - If a weekly schedule is configured for the selected day of the week, it will also be shown.
3. Click **[Delete]** for the schedule to delete, and click **[Update]**.
  - Refer to "[How to delete the Weekly Schedule \(→page 516\)](#)" to delete a weekly schedule.
4. Click **[OK]**.

## 8.4 Lock Transfer (for IX-MV7-\*)



Description	Select ON / OFF to Lock Transfer function. When set to "ON", transfer function cannot be changed by user account.
Settings	<ul style="list-style-type: none"> <li>• ON: Cannot be configured with user privileges.</li> <li>• OFF: Can be configured with user privileges.</li> </ul>
Default values	OFF

# 9. Station Settings

## 9.1 Speed Dials / Favorites (for IX-MV7-\* and IX-MV)

Configure the Speed Dial button settings for IX-MV7-\* and IX-MV.

### 9.1.1 Advanced Speed Dial Button Settings

Select the functions to assign to each Speed Dial button.  
Up to eight Speed Dial buttons can be set for IX-MV7-\*, and six for IX-MV.

#### How to configure the Speed Dial buttons

1. Select the Speed Dial button to configure in "Speed Dial #."
  - The settings of the selected Speed Dial button are displayed.
2. Configure each item.
3. When done, click **[Update]**.
4. Click **[OK]**.

9.1.1.1 Speed Dial Name (for IX-MV7-\*)

Description	Set the Speed Dial Name.
Settings	1-24 alphanumeric characters The entire name may not be shown on the station screen, depending on the number of characters.
Default values	-

 Important

- Enter button names in the language configure in "[Language \(→page 158\)](#)". However, if the language displayed on the screen for IX-MV7-\* differs from that set in "Language," characters on the station screen may appear incorrectly. To avoid this, enter information using alphabetical characters only.

9.1.1.2 Function

Description	Set the Speed Dial Function. Refer to " <a href="#">How to configure Individual Call (→page 520)</a> " for how to configure detailed functions.
Settings	<ul style="list-style-type: none"> <li>• No Function</li> <li>• Individual Call: Call individual station set in "Individual Call".</li> <li>• Group Call: Call group set in "Group Call".</li> <li>• Group Page: Page group set in "Group Page".</li> <li>• All Page: Page all stations.</li> <li>• Group Message Page (For IX-MV7-*): Page message to group set in "Group Message Page".</li> <li>• All Message Page (For IX-MV7-*): Page message to all stations..</li> <li>• Monitor (For IX-MV7-*): Monitor station set in "Monitor".</li> <li>• Network Camera Monitor (For IX-MV7-*): Monitor network camera set in "Network Camera Monitor".</li> <li>• Scan Monitor (For IX-MV7-*): Start scan monitor sequence set in "Station Settings - Monitor".</li> <li>• Option Relay Control (For IX-MV7-*): Relay Control set in "Option Relay Control". Relay output will not be controlled for IX-MV, IX-DA, IX-DF(-*), IX-BA, and IX-SS(-*).</li> </ul>
Default values	No Function

**How to configure Individual Call**

Configure this if "Individual Call" is set in "[Function \(→page 520\)](#)".

■ Number

Description	Set the destination station. Enter the Station Number or click <b>[Open]</b> to choose one. This cannot be configured for IXW-MA.
Settings	3-32 digits
Default values	-

 Important

- Stations in which the "[IP Address \(→page 381\)](#)" has not been configured cannot be configured as destinations.

■ Priority

Description	Set the Priority for the individual calls.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

**How to configure Group Call**

Configure if "Group Call" is set in ["Function \(→page 520\)"](#).

**■ Group Number**

Description	Set the destination group. Enter the group number directly, or click <b>[Open]</b> to choose a group.
Settings	01 - 99
Default values	-

**■ Priority**

Description	Set the priority of Group call.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Priority</li> <li>• Urgent</li> </ul>
Default values	-

**How to configure Group Page**

Configure if "Group Page" is set in ["Function \(→page 520\)"](#).

**■ Group Number**

Description	Set the destination group. Enter the group number directly, or click <b>[Open]</b> to choose a group.
Settings	01 - 99
Default values	-

**■ Priority**

Description	Set the priority of group page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

**How to configure All Page**

Configure if "All Page" is set in ["Function \(→page 520\)"](#).

**■ Priority**

Description	Set the priority of all page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

**How to configure Group Message Page (for IX-MV7-\*)**

Configure if "Group Message Page" is set in ["Function \(→page 520\)"](#).

**■ Group Number**

Description	Set the destination group. Enter the group number directly, or click <b>[Open]</b> to choose a group.
Settings	01 - 99
Default values	-

■ Message

Description	Select the message (audio file) to send during group message paging.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))

■ Priority

Description	Set the priority of group message page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

■ Play Count [time(s)]

Description	Set the message play count of group message page.
Settings	1 - 20 times
Default values	-

**How to configure All Message Page (for IX-MV7-\*)**

Configure if "All Message Page" is set in ["Function \(→page 520\)"](#).

**■ Message**

Description	Select the message (audio file) to send during all message paging.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))

**■ Priority**

Description	Set the priority of all message page.
Settings	<ul style="list-style-type: none"> <li>• Normal</li> <li>• Urgent</li> </ul>
Default values	-

**■ Play Count [time(s)]**

Description	Set the message play count of all message page.
Settings	1 - 20 times
Default values	-

**How to configure Monitor (for IX-MV7-\*)**

Configure if "Monitor" is set in ["Function \(→page 520\)"](#).

**■ Number**

Description	Set the destination station. Enter the Station Number or click <b>[Open]</b> to choose one. This cannot be configured for IX-MV7-*, IX-MV, IXW-MA or VoIP Phone.
Settings	3-5 digits
Default values	-

**! Important**

- Stations in which ["IP Address \(→page 381\)"](#) has not been configured cannot be configured to be monitored.

**How to configure Network Camera Monitor (for IX-MV7-\*)**


Configure if "Network Camera Monitor" is set in ["Function \(→page 520\)"](#).

**■ Network Camera**

Description	Set the destination Network Camera. Enter the number of the network camera set in <a href="#">"Network Camera List (→page 409)"</a> or click <b>[Network camera selection]</b> to choose one.
Settings	001 - 050
Default values	-

**How to configure Option Relay Control (for IX-MV7-\*)**


Configure if "Option Relay Control" is set in ["Function \(→page 520\)"](#).

**Note**

- When controlling relay output on multiple stations, processing may take some time and control may be delayed.

**■ Station List**

Description	Configure the station to control relay output. This cannot be configured for IX-MV, IX-DA, IX-DF(-*), IX-BA, IX-SS(-*). Click <b>[Open]</b> to choose a station. Multiple stations (infinite) can be selected.
Settings	The selected station is displayed.
Default values	-

**Important**

- Stations that the "IP Address" has not been configured cannot be configured as stations to perform control.

**■ Output Time**

Description	Select the Output Time Range for relay output, and set the Output Time within the range.
Settings	<ul style="list-style-type: none"> <li>• 0 (Momentary): Start Relay Output by pressing a Speed Dial button. Stop Relay Output by pressing again the Speed Dial button. Pressing the Speed Dial button again will stop relay output.</li> <li>• 200-2000 [msec]: Select this when configuring a value from 200 to 2000 msec (by 200 msec). Enter the time in "Output Time [msec / sec]◆."</li> <li>• 3-600 sec: Select this when configuring a value from 3 to 600 sec (by 1 sec). Enter the time in "Output Time [msec / sec]◆."</li> </ul>
Default values	0 (Momentary)

**■ TLS**

Description	Select Enable / Disable for TLS. When "Enable" is selected, set "Option Relay Control Key" and Relay Output" - <a href="#">"Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*)) (→page 449)"</a> .
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

**Important**

- If "TLS" is set to "Enable," this may take some time if there are multiple stations to control.

## ■ Option Relay Control Key

Description	Set the Option Relay Control Key. When matched with the Option Relay Control Authentication Key in "Relay Output" - " <a href="#">Option Relay Control Authentication Key (except IX-MV, IX-DA, IX-DF(-*), and IX-BA, IX-SS(-*))</a> ( <a href="#">→page 449</a> )", the relay output will activate.
Settings	1-20 digits
Default values	-

### 9.1.1.3 Lock (for IX-MV7-\*)

Description	Select ON / OFF to Lock Speed Dial setting. Once set to "ON", Speed Dial function cannot be changed by user account.
Settings	<ul style="list-style-type: none"> <li>• ON</li> <li>• OFF</li> </ul>
Default values	OFF

## 9.2 Privacy (for IX-MV7-\* and IX-MV)

Configure to prevent the other station from hearing/viewing audio or camera images, when [“Auto Answer”](#) (→page 431) is set to "ON."




### ■ Privacy♣

Description	Select Enable / Disable for Privacy function. The setting can also be changed on the station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.3 Volume / Tone (except IXW-MA)

Configure the sound settings, such as volume and ringtone.

### 9.3.1 Volume



#### ■ Handset Transmit (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the transmit volume using handset while communicating and paging.
Settings	1 (Low) - 10 (High)
Default values	10

#### ■ Handset Receive (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the receive volume using handset while communicating. Also sets ringback tone volume.
Settings	1 (Low) - 10 (High)
Default values	6

#### ■ Hands-free Transmit (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the hands-free transmit volume while communicating and paging.
Settings	1 (Low) - 10 (High)
Default values	10

#### ■ Hands-free Receive (for IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the hands-free receive volume while communicating and paging. Also sets ringback tone volume.
Settings	1 (Low) - 10 (High)
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV: 6</li> <li>• IX-RS-*: 10</li> </ul>

#### ■ Headset Jack Transmit (for IX-MV7-\*)

Description	Set the transmit volume using headset jack.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Headset Jack Receive (for IX-MV7-\*)

Description	Set the receive volume using the headset jack.
Settings	1 (Low) - 10 (High)
Default values	6

### ■ Transmit (except IX-MV7-\*, IX-RS-\*, and IX-MV)

Description	Set the transmit volume while communicating and being monitored.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Receive (except IX-MV7-\*, IX-RS-\*, IX-MV, IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Set the receive volume while communicating and paging. This sets the Ringback Tone volume, as well.
Settings	1 (Low) - 10 (High)
Default values	10

### ■ Receive (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Select the receive volume while communicating. Also sets ringback tone. The calling tone volume will be changed as well.
Settings	1 (Low) - 10 (High)
Default values	6

### ■ External Input

Description	Not used.
-------------	-----------

### ■ External Output (for IX-RS-\*)

Description	Select the transmit volume when using the external output.
Settings	1 (Low) - 10 (High)
Default values	6

### ■ VoIP Phone Volume Adjustment (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Description	Select the volume adjustment between VoIP Phone and IX stations.
Settings	<ul style="list-style-type: none"> <li>• -12dB from VoIP, +12dB to VoIP</li> <li>• -6dB from VoIP, +6dB to VoIP</li> <li>• No Adjustment</li> <li>• +6dB from VoIP, -6dB to VoIP</li> <li>• +12dB from VoIP, -12dB to VoIP</li> </ul>
Default values	No Adjustment

### ■ Ringtone

Description	Select the volume for Ringtone and Paging Pretone.
Settings	0 (Off), 1 (Low) - 10 (High)
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*, IX-MV, IX-DV, IX-DVF(-*), IX-SSA(-*): 6</li> <li>• IX-SS-2G, IX-RS-*, IX-DA, IX-BA, IX-SS(-*): 10</li> </ul>


■ Paging (for IX-DV, IX-DVF(-\*), IX-SSA(-\*))

Description	Set the volume while receiving page.
Settings	0 (Off), 1 (Low) - 10 (High)
Default values	6

■ Button Feedback (for IX-MV7-\* and IX-MV)

Description	Select Enable / Disable for Button Feedback tone.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	<ul style="list-style-type: none"> <li>• IX-MV7-*: Enable</li> <li>• IX-MV: Disable</li> </ul>

9.3.2 Tone



■ Communication Timeout Notification (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))♣

Description	Select the tone to be played when an outgoing call times out.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Error

■ Communication End Pretone (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))♣

Description	Select the tone to be played 10 sec before communication, paging or monitoring ends.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Communication End Pretone

■ Call Queue Notification (for IX-MV7(-\*))♣

Description	Select the tone to be played when receiving a call while communicating.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Call Queue Notification

## ■ Paging Pretone (for IX-MV7-\* and IX-MV) ♣

Description	Select the sound to be played when placing or receiving a page.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Pre Tone 2

### ! Important

- Configure the paging pretone with a longer duration than the paging pretone of the station receiving the page. Configuring a shorter tone might prevent audio from playing on the other station when paging starts. Configure the same tone as that of other IX-MV7-\* and IX-MV stations in the system.

## ■ Auto Answer Tone (except IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*)) ♣

Description	<p>Select the tone to be played.</p> <ul style="list-style-type: none"> <li>• Ringtone when receiving an individual call. <a href="#">"Auto Answer ♣ (→page 431)"</a> must be set to "ON".</li> <li>• Ringback tone when placing an individual call. <a href="#">"Auto Answer ♣ (→page 431)"</a> must be set to "ON" at the destination station. (for IX-MV7-*)</li> </ul>
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	Pre Tone 1

■ On Hold (for IX-MV7-\*)<sup>▲</sup>

Description	Select the tone to be played while On-Hold.
Settings	<ul style="list-style-type: none"> <li>• None (except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone (Busy Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error (Error Tone for IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 1(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 2(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Pre Tone 3(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Communication End Pretone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Call Queue Notification(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Waiting Reply Tone(Except IX-DA, IX-DF(-*), IX-BA, IX-SS(-*))</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	On Hold

■ Key Received (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*))<sup>▲</sup>

Description	Configure the tone to send to the destination station when the door release key entered using a keypad on the destination station (station performing a door release operation) matches the authentication key of this station (station connected to the electrical lock). The tone will be heard on the destination station.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	None

■ Error (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))<sup>♣</sup>

Description	Select the tone to be played when error has occurred.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	Error

■ Mic Select

Description	Not used.
-------------	-----------

■ Headset Specification (for IX-MV7-\*)

Description	Set the device to be connected to the headset jack.
Settings	<ul style="list-style-type: none"> <li>• Mic Device</li> <li>• Headset Device</li> </ul>
Default values	Mic Device

■ Audio Output (for Master) (for IX-MV7-\*)

Description	Set using External speaker for Ringtone, Paging Pretone and Paging.
Settings	<ul style="list-style-type: none"> <li>• External speaker output for Ringtone, Built-in Speaker for Communication</li> <li>• External speaker output for Page Pretone, Built-in Speaker for Paging</li> <li>• External speaker output for Ringtone, Paging Pretone and Paging, Built-in Speaker for Communication</li> </ul>
Default values	External speaker output for Ringtone, Built-in Speaker for Communication

 Note

- The tone will play from the speaker of the station even if audio is heard from the external speaker.

■ Audio Output (for Door) (except IX-MV7-\*, IX-SS-2G, and IX-MV)

Description	Set using Line Audio / External Speaker or Built-in Speaker while communicating and paging.
Settings	<ul style="list-style-type: none"> <li>• Built-in Speaker for Communication and Paging</li> <li>• Line Audio Output for Communication and Paging (External speaker output for Communication and Paging for IX-RS-*)</li> <li>• Built-in Speaker for Communication, Line Audio Output for Paging (External speaker output for Communication and Paging for IX-RS-*)</li> </ul>
Default values	Built-in Speaker for Communication and Paging

## 9.4 Communication (except IXW-MA)

Configure the settings for a call.

### ■ Talk Timeout [sec]◆♠

Description	Set the communication timer when placing a call. Communication timer when receiving a call is set at the destination station.
Settings	<ul style="list-style-type: none"> <li>• 30-600 sec: Configure between 30 to 600 sec (by 1 sec).</li> <li>• Infinite (Except IX-MV): No timeout.</li> </ul>
Default values	60 sec

**! Important**

- During a communication with a VoIP phone, this will be the shorter time of the time set for "Talk Timeout [sec]" and the call duration set on the VoIP phone.

### ■ Communication Start Tone (except IX-MV7-\*, IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))♠

Description	Select the tone to be played when communication starts.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">"Custom Sound Registry (except IXW-MA) (→page 416)"</a>.</li> </ul>
Default values	None

### ■ Force Touch-to-Talk (for IX-MV7-\* and IX-MV)


Description	Select Enable / Disable for Force Touch-to-Talk (Or Press-to-Talk) when starting communication in hands-free mode.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.5 Monitor (except IXW-MA, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*))

Configure the settings for the monitor function.

### ! Important

- Monitoring cannot be performed for IX-MV7-\*, IX-MV, or VoIP phones.



### 9.5.1 Monitor Timeout [sec] (for IX-MV7-\* and IX-MV) ♦♠

Description	Set the monitoring timer by station. Scan Monitor must be end manually.
Settings	<ul style="list-style-type: none"> <li>Infinite (For IX-MV7-*): No timeout.</li> <li>10-600 sec: Set 10-600 sec by 1 sec.</li> </ul>
Default values	60 sec

### 9.5.2 Scan Monitor (for IX-MV7-\*)

Configure monitoring by automatically switching between several stations (except IX-MV7-\* and IX-MV) and network cameras at set intervals. The scan will be performed in registration order.

#### ■ Type

Description	Select the Station Type.
Settings	<ul style="list-style-type: none"> <li>IX Station</li> <li>Network Camera</li> </ul>
Default values	-

#### ■ Number

Description	Set the Station Number. Enter the Number or click <b>[Open]</b> to choose one. This cannot be selected for IX-MV7-*, IX-MV, IXW-MA or VoIP Phone.
Settings	3-5 digits
Default values	-

**! Important**

- Stations in which [“IP Address \(→page 381\)”](#) has not been configured cannot be configured to be monitored.

**■ Network Camera Number**

Description	Set the Network Camera Number. Enter the number of the network camera set in <a href="#">“Network Camera List (→page 409)”</a> or click <b>[Network camera selection]</b> to choose one.
Settings	Select from the network cameras registered in <a href="#">“Network Camera List (→page 409)”</a> .
Default values	-

**■ Dwell Time**

Description	Set the dwell time to change destination for scan monitor.
Settings	<ul style="list-style-type: none"> <li>• 5 sec</li> <li>• 10 sec</li> <li>• 30 sec</li> </ul>
Default values	5 sec

**9.5.3 Prevent Being Monitored (except IX-MV7-\* and IX-MV)**

Description	Select ON / OFF to prevent being monitored.
Settings	<ul style="list-style-type: none"> <li>• ON: Prevent being monitored.</li> <li>• OFF: Allow monitoring</li> </ul>
Default values	OFF

**9.5.4 Monitored Notification (except IX-MV7-\* and IX-MV) ♣**


Description	Select the tone to be played when monitored by another station.
Settings	<ul style="list-style-type: none"> <li>• None</li> <li>• Call Pattern 1</li> <li>• Call Pattern 2</li> <li>• Call Pattern 3</li> <li>• Call Pattern 4</li> <li>• Call Pattern 5</li> <li>• Call Pattern 6</li> <li>• Tremolo Sound</li> <li>• Busy Response Tone</li> <li>• On Hold</li> <li>• Operation Sound</li> <li>• Error</li> <li>• Pre Tone 1</li> <li>• Pre Tone 2</li> <li>• Pre Tone 3</li> <li>• Communication End Pretone</li> <li>• Call Queue Notification</li> <li>• Waiting Reply Tone</li> <li>• Select a sound that is registered in <a href="#">“Custom Sound Registry (except IXW-MA) (→page 416)”</a>.</li> </ul>
Default values	None

**9.5.5 Monitored LED Notification (except IX-MV7-\* and IX-MV)**

Description	Select ON / OFF for status LED notification (Blue flashing) while being monitored by another station.
Settings	<ul style="list-style-type: none"><li>• ON</li><li>• OFF</li></ul>
Default values	OFF

## 9.6 Master Station Display (for IX-MV7-\* and IX-MV)

Configure screen display-related settings.



### ■ Brightness

Description	Set the Brightness of Master station display.
Settings	1 (Dark) - 10 (Bright)
Default values	6

### ■ Primary Video Source (for IX-MV7-\*)

Description	Select the primary video source when showing 2 video stream simultaneously.
Settings	<ul style="list-style-type: none"> <li>IX Station</li> <li>Network Camera</li> </ul>
Default values	IX Station

### ■ Aspect Ratio (for IX-MV7-\*)

Description	Select the video aspect for primary video source.
Settings	<ul style="list-style-type: none"> <li>16:9</li> <li>4:3</li> </ul>
Default values	16:9

### ■ Time Format (for IX-MV)♣

Description	Select the Time format.
Settings	<ul style="list-style-type: none"> <li>mm/dd/yyyy (12h)</li> <li>mm/dd/yyyy (24h)</li> <li>dd/mm/yyyy (12h)</li> <li>dd/mm/yyyy (24h)</li> <li>yyyy/mm/dd (12h)</li> <li>yyyy/mm/dd (24h)</li> </ul>
Default values	mm/dd/yyyy (12h)

### ■ Standby LED State♣

Description	Select ON / OFF for stand by status LED.
Settings	<ul style="list-style-type: none"> <li>ON</li> <li>OFF</li> </ul>
Default values	ON

**■ Keypad (for IX-MV7-\*)**

Description	Select ON / OFF for display Keypad to use for door release or playing location message.
Settings	<ul style="list-style-type: none"><li>• ON</li><li>• OFF</li></ul>
Default values	ON

## 9.7 Camera (for IX-DV, IX-DVF(-\*), IX-DA, IX-DF(-\*))

Configure camera settings.

### 9.7.1 Adjustment



#### ■ Backlight Compensation♣

Description	During an outgoing call or monitoring, video with backlight compensation adjustment will be sent to the destination station. The adjustment can be removed through operation by the destination station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable


#### ■ Low Light Sensitivity♣

Description	Send an image that low light sensitivity compensation was performed to the other station, when an outgoing call is made or the station is being monitored and the surrounding area is dark (such as at night). The compensation can be removed on the other station.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

### 9.7.2 Color Settings (for IX-DA, IX-DF(-\*))

#### ! Important

- If these settings are changed while video is displayed, the changes will not be reflected until the video is accessed again.



#### ■ Brightness◆

Description	Set the Brightness for camera setting.
Settings	1 (Dark) to 100 (Bright)
Default values	50

#### ■ Contrast◆

Description	Set the Contrast for camera setting.
Settings	1 (Weak) - 100 (Strong)
Default values	15

■ Color◆

Description	Set the Contrast for camera setting.
Settings	1 (Weak) to 100 (Strong)
Default values	50

9.7.3 White LED



■ Call / Communication♣

Description	Select Enable / Disable for white LED while calling or communicating in low light situation.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Enable

■ Monitored♣

Description	Select Enable / Disable for white LED while being monitored in low light situation.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.8 Door Release Assignment (for IX-RS-\*)

Configure the connected station and door release key for door release during a call.

Configure each station for each group configured in [“Called Stations \(Door/Sub Stations\) \(except IX-MV7-\\*, IX-MV, and IXW-MA\) \(→page 419\)”](#).

Group Number: Group 01

#	Number	Contact Assignment	Authentication Key 1-20 digits
01	0001	Destination Station	4590
02	0002	Destination Station	9274
03	0003	Destination Station	2503
04	0004	Destination Station	1721
05	0005	Destination Station	2151
06	0006	Destination Station	8138
07	0007	Destination Station	5493
08	0008	Destination Station	9712
09	0009	Destination Station	8943
10	0010	Destination Station	8720

Door Release by IX-RS:  Enable  Disable

### How to configure Door Release Assignment

1. Select the group number to configure from "Number."
  - Settings for the selected group number will be shown.
2. Configure each item.
3. When done, click **[Update]**.
4. Click **[OK]**.

### ■ Contact Assignment

Description	Select which relay output will be used for door release during call.
Settings	<ul style="list-style-type: none"> <li>• Originating Station: Use origination station relay output for door release.</li> <li>• Destination Station: Use destination station relay output for door release.</li> </ul>
Default values	Destination Station

### ■ Authentication Key

Description	When "Destination Station" is selected in "Contact Assignment," set the Authentication Key for door release. Authentication key must match with the destination station's authentication key, which is set in "Relay Output" - <a href="#">“Door Release Authorization (except IXW-MA) (→page 443)”</a> to allow door release.
Settings	1-20 digits
Default values	Random characters (compatible with default value of "Relay Output" - "Door Release Authorization")

 Note

- If ["Create new system/import setting data \(→page 123\)"](#) - "Automatically configure door release for all stations?" was set to "OFF," the default value for "Authentication Key" will not be set.
- The default values for the authentication key and door release key vary depending on the station type set in ["Create new system/import setting data \(→page 123\)"](#) - "IX Support Tool Settings."
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) not configured: 20 digits.
  - IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) configured: 4 digits

■ Door Release by IX-RS

Description	Select Enable / Disable for door release by IX-RS.
Settings	<ul style="list-style-type: none"> <li>• Enable</li> <li>• Disable</li> </ul>
Default values	Disable

## 9.9 Line Supervision (for IX-MV7-\*)

Configure settings related to Line Supervision and Device Check performed by IX-MV7-\*. Monitor a station other than a VoIP phone registered in [“Station List \(→page 406\)”](#).

Line Supervision			
Line Supervision Interval	OFF	Sun	Schedule available Weekly only.
Line Supervision Schedule	00 Hour	00 Minute	Schedule available Daily or Weekly only.
Device Check Interval	OFF	Sun	Schedule available Weekly only.
Device Check Schedule	00 Hour	00 Minute	Schedule available Daily or Weekly only.

### Line Supervision Interval

Description	Set the Line Supervision test interval.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• 15sec</li> <li>• 20 min</li> <li>• 30 min</li> <li>• 60 min</li> <li>• Daily</li> <li>• Weekly: Select from the day of week drop-down list</li> </ul>
Default values	OFF

### Line Supervision Schedule

Description	Set the time when automatic line monitoring starts. Set the time when is set to "Daily" or "Weekly" is selected in <a href="#">“Line Supervision Interval (→page 545)”</a> .
Settings	00:00 - 23:59
Default values	00:00

### Device Check Interval

Description	Set the Line Supervision test interval.
Settings	<ul style="list-style-type: none"> <li>• OFF</li> <li>• 10 min</li> <li>• 20 min</li> <li>• 30 min</li> <li>• 60 min</li> <li>• 1 day</li> <li>• Weekly: Select from the day of week drop-down list</li> </ul>
Default values	OFF

### Device Check Schedule

Description	Set the time when automatic failure monitoring starts. Set the time when "1 day" or "Daily" is selected in <a href="#">“Device Check Interval (→page 545)”</a> .
Settings	00:00 - 23:59
Default values	00:00

# 10. Maintenance

## 10.1 Firmware Update

Access our website at "<http://www.aiphone.net/>" to download the latest version of the firmware.

### ! Important

- To update the firmware, "[Association Settings \(→page 160\)](#)" must have been performed on the station to update, and the PC must be able to communicate with the system.
- If the firmware update is started while the station is operating (such as on a call), the operation will end and the firmware update will begin.
- If power is turned off while updating the firmware, the station may malfunction.
- The station will be inoperable while updating the firmware.
- When the firmware is updated, the station will be automatically restarted.

### •Firmware Update


To check the current firmware version, go to "Tool -> Station Search".

Browse

Firmware Update

### How to update the firmware

1. Click **[Browse]** and select the firmware file to be downloaded.
2. Click **[Firmware Update]**.
3. Click **[OK]**.
  - Click **[Cancel]** to back to the "Firmware Update" screen without updating the firmware.



4. Click **[OK]**.


### 💡 Note

- If updating fails, repeat the procedure.

## 10.2 Initialization

When initializing the station, all settings go back to the default values, and the system log and incoming/outgoing call history are erased.

Stations are also deleted from the settings in IX Support Tool.



### How to initialize


1. Click **[Initialization]** or **[Initialize User Settings]**.
  - Initialization: All settings will revert to their default values. The system log, outgoing/incoming call history, and recorded video/audio data on the microSD card will be cleared.
  - Initialize User Settings: Only the content of general user accounts are initialized.
2. Click **[OK]**.
  - Click **[Cancel]** to cancel the initialization.
3. Click **[OK]**.

### ! Important

- After selecting **[Initialization]**, the station will restart. This may take approx. 10 minutes in total. The station will not operate until the restart is complete.
- If initialization fails, the message "Error: Station initialization failed." will appear. If this happens, perform initialization again.

## 10.3 Settings File Backup

Download/upload setting files.




### 10.3.1 Setting File Download

Download the setting file from the station and back it up.

**! Important**

- Setting files are downloaded via [“Association Settings \(→page 160\)”](#) on the downloading station. Files cannot be downloaded unless the PC can communicate with the system.
- When first configuring settings using a web browser, or when changing the configuration using a web browser after configuring settings using IX Support Tool, it may not be possible to download the setting files. In this case, download the setting files using a browser.

Click **[Setting File Download]**. The Setting File Download window will be shown.



#### How to download setting files

1. Select the station to download the setting file from "Station List" (multiple selections allowed).
  - To select or unselect stations in a batch, choose the station type for a batch selection and click **[Select]** or **[Unselect]**.
  - Stations for which [“Association Settings \(→page 160\)”](#) has not been performed cannot be selected.

**2.** Download the file.

**[Settings]:** Download only the setting file.


**[Sounds]:** Download the setting file and audio file for a custom tone.

**[Image]** (for IX-MV7-\*): Download the setting file and image file for the image on the reception screen.

**[Schedule]** (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA): Download schedule setting files (for transfer, etc.). Schedules for IX-MV, IX-DA, IX-DF(-\*), or IX-BA, IX-SS(-\*) are downloaded from **[Settings]**.

**3.** Click **[OK]**.

- Click **[Cancel]** to return to the "Setting File Download" window without downloading.

**4.** Click **[OK]**.

- The file download result is displayed in "Station List" - "Status."
  - In Process: The file is in the process of downloading.
  - Success: Download is completed.
  - Failed: Download failed. Try downloading again.
  - Unavailable: This is displayed when a file that cannot be uploaded to a station is selected to download in Step 2.
- Downloaded files are saved as follows in "aiphone" - "AIPHONE\_IX\_SupportTool" - "SystemData" within the folder specified during installation.
  - Setting file: "NewIXSystem(Set System Name).db"
  - Sound file: Saved as a WAV file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Image file: Saved as a PNG file inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)"
  - Schedule file: Saved inside "(Set System Name)" - "Setting (Hidden Folder)" - "(Station Number)" as "SCHED\_CHIME.txt," "SCHED\_GROUP.txt," "SCHED\_OUTPUT.txt," "SCHED\_TRANSFER.txt," or "SCHED\_REC.txt" (the saved content differs depending on the station).


### 10.3.2 Setting File Upload

Upload setting files to a station.

**! Important**

- Setting files can only be uploaded to stations that have been associated ["Association Settings \(→page 160\)"](#). They cannot be uploaded unless the PC can communicate with the system.
- If a custom tone/image was registered, be sure to upload each file to the station in "Sounds" - "Image." The following will occur if only the setting file is uploaded.
  - The default tone will play when the operation that the custom tone was set is performed.
  - Images will not be displayed in receptionist mode.
  - "Download Settings From Station" will fail.
  - "Restore System Settings" will fail.

Click **[Setting File Upload]** and the Setting File Upload window will be shown.



#### How to upload setting files

- 1.** Select the station(s) to upload the setting file to from the "Station List."
  - To select or unselect stations in a batch, choose the station type and click **[Select]** or **[Unselect]**.
  - Stations that have not been associated cannot be selected.

## 2. Upload the file.

**[Settings]:** Upload only the setting file.


**[Sounds]:** Upload the setting file and audio file for a custom tone.

**[Image]** (for IX-MV7-\*): Upload the setting file and image file for the image on the reception screen.

**[Schedule]** (except IX-MV, IX-DA, IX-DF(-\*), IX-BA, IX-SS(-\*), and IXW-MA): Upload the schedule setting files (transfer, etc.). Schedules for IX-MV, IX-DA, IX-DF(-\*), and IX-BA, IX-SS(-\*) are uploaded from **[Settings]**.

## 3. Click **[OK]**.

- Click **[Cancel]** to back to "Setting File Upload" window without uploading the file.



## 4. Click **[OK]**.

- The file upload result is displayed in "Station List" - "Status."

In Process: The file is in the process of uploading.

Success: Upload is completed.

Failed: Upload failed. Try uploading again.

Unavailable: This is displayed when a file that cannot be uploaded to a station is selected in Step 2.





<https://www.aiphone.net/>

AIPHONE CO., LTD., NAGOYA, JAPAN

Issue Date: Feb.2019 © 0219 MQ 61340