




Wiring Guide - LiftMaster CSW200UL & CSW24UL



Liftmaster CSW200UL & CSW24UL



- Step 1 - Plug Nimbio PWR into Accessory Power
- Step 2 - Plug Nimbio NO into EXIT
- Step 3 - Plug Nimbio C into EXIT

