




# Wiring Guide - LiftMaster LA400



## Liftmaster LA400



- Step 1 - Plug Nimbio PWR into Accessory Power - ON
- Step 2 - Plug Nimbio NO into EXIT
- Step 3 - Plug Nimbio C into EXIT

