




OPERATOR WIRING DIAGRAM

MODEL: RSLG3500

FIELD WIRING TERMINAL	FUNCTION
0	PUSHBUTTON
1	COMMON
2	RADIO RELAY
3	24 VAC
4	PHOTOELECTRIC POWER
5	SIGNAL