




INSTALLATION SITUATIONS



(**)



- If you work with a magnetic lock you need to adjust the pretension to 675 mm
- Si vous travaillez avec une serrure magnétique, la précontrainte doit être ajustée sur 675mm
- Wanneer er met een magnetisch slot wordt gewerkt, moet de voorspanning aangepast worden naar 675 mm
- Wenn Sie mit einem Magnetschloss arbeiten, nehmen Sie 675 mm Vorspannung

LOCINOX®
WWW.LOCINOX.COM

Doc. Nr.:
MANU-000024

Locinox nv • Mannebeekstraat 21
B-8790 Waregem • Belgium - Europe
Tel. +32 (0)56 77 27 66 • Fax. +32 (0)56 77 69 26
E-mail: locinox@locinox.com






* M A N U - 0 0 0 0 2 4 *

LOCINOX®

WWW.LOCINOX.COM

CODE: SAMSON





INSTALLATION INSTRUCTIONS

