


## INSTALLATION INSTRUCTIONS FOR UP HILL SWING GATE HINGES


**STEP ONE:** Stand gate in the open position exactly how it will sit when it is open. With the hinges open to a right angle hold the top half of each hinge flat against the end rail of the gate and the bottom half against the post. (This will set the angle at which the hinges must be mounted to achieve the correct rise.) Now tack to post.

(Note: NOT TO GATE)



Clearance at end of gate should be at least one (1) inch more than required for settling.

**STEP TWO:** Now stand gate in closed position exactly as it sits in the opening. Tack top half of hinges to gate, making sure that tacks are strong enough to support the weight of the gate.



Now test. If gate has the clearance needed and it swings smoothly, weld hinges.