

ENFORCER®

**Model: SECOPAGE 35RD
SECOPAGE 35RV**

**Code-learning the receiver
for the SECOPAGE 35EV and
SECOPAGE 35E7**



The SECOPAGE 35RD (digital receiver) and SECOPAGE 35RV (digital receiver with vibrating function) must learn the transmitter's page code before it can receive signals from that transmitter. The receiver can learn the page codes of up to 3 transmitters using the following procedure:

1. Turn the receiver OFF. Then press and hold down the ON/OFF switch, and slide it to the ON position. The LED display will show "≡". Continue pressing and holding the button for about 3 seconds until the receiver beeps once. The LED display will flash "A" every 2 seconds. This means the receiver is ready to learn the page code from the "A" transmitter.
2. Trigger the transmitter (or press the manual page button). This sends the page signal to the receiver. The receiver will beep 5 times and the LED display will turn OFF to confirm it has received and learned the code.
The receiver will return to the standby state in about 4 minutes if it did not successfully learn the code.
3. To learn the page code from the "B" (second) transmitter, press the receiver's ON/OFF switch once so that the LED display turns to "b." Then repeat step 2. Repeat steps 3 and 2 again for the "C" (third) transmitter if needed.

NOTE — The receiver stores the transmitter codes in EEPROM. This memory is maintained even without power for a long period of time (over 1 year). The receiver does not need to re-learn the transmitter codes after battery replacement.

The stored transmitter codes cannot be erased. They can only be written over by another code learning sequence.

WARRANTY: The SECOPAGE 35RD and SECOPAGE 35RV are warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation pre-paid, to SECO-LARM. For complete details regarding the SECO-LARM warranty, please contact SECO-LARM.

NOTICE: The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors. Copyright © 2003 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.

SECO-LARM® U.S.A., Inc.

16842 Millikan Avenue, Irvine, CA 92606

Tel: 800-662-0800 / 949-261-2999 Fax: 949-261-7326

Website: www.seco-larm.com

E-mail: sales@seco-larm.com

CodingReceivers.pmd