


SD-993S-SB

Surface-mount bracket kit

SD-993S-UB

U-bracket (glass door) kit

▀ Bracket kits for SD-993B-SS Electric Shear Lock




SD-993S-SB



SD-993S-UB


FOR SURFACE MOUNTING (SD-993S-SB)

Surface-mount
(magnet and armature).
Use 2 x surface-mount brackets



The magnet assembly is in the bracket above the door, and the armature assembly is in the bracket on the door.

Flush-mount (magnet).
Surface-mount (door).
Use 1 x surface-mount bracket




The magnet assembly is flush to the door frame or header, and the armature assembly is in the bracket on the door.

SD-993S-SB includes:
2 x Surface-mount brackets
4 x Aluminum trim plates
3 x Blind nuts
3 x Hex screws
1 x Blind nut assembly

SD-993S-UB includes:
2 x U-brackets
8 x Aluminum spacers
4 x Hex screws
1 x Hex wrench

FOR GLASS DOOR MOUNTING (SD-993S-UB)

May require 1 or more SD-993S-SB and SD-993S-UB bracket kits, depending on the glass door configuration.



NOTES: One glass door with a glass frame illustrated above.

WARRANTY: This SECO-LARM product is warranted against defects in material and workmanship while used in normal service for a period of one (1) year from the date of sale to the original consumer customer. SECO-LARM's obligation is limited to the repair or replacement of any defective part if the unit is returned, transportation prepaid, to SECO-LARM.

This Warranty is void if damage is caused by or attributed to acts of God, physical or electrical misuse or abuse, neglect, repair, or alteration, improper or abnormal usage, or faulty installation, or if for any other reason SECO-LARM determines that such equipment is not operating properly as a result of causes other than defects in material and workmanship.

The sole obligation of SECO-LARM, and the purchaser's exclusive remedy, shall be limited to replacement or repair only, at SECO-LARM's option. In no event shall SECO-LARM be liable for any special, collateral, incidental, or consequential personal or property damages of any kind to the purchaser or anyone else.

NOTICE: The information and specifications printed in this manual are current at the time of publication. However, the SECO-LARM policy is one of continual development and improvement. For this reason, SECO-LARM reserves the right to change specifications without notice. SECO-LARM is also not responsible for misprints or typographical errors.

Copyright © 2006 SECO-LARM U.S.A., Inc. All rights reserved. This material may not be reproduced or copied, in whole or in part, without the written permission of SECO-LARM.